

eldes®

ESIM484

2G/4G ALARM AND MANAGEMENT SYSTEM

INSTALLATION MANUAL

Safety instructions


Please read and follow these safety guidelines in order to maintain safety of operators and people around:

- 2G/4G alarm and management system ESIM484 (later referred to as “the system” or “the device”) contains a built-in radio transceiver operating in 900/1800MHz 2G; 700/800/900/1800/2100/2600MHz 4G bands respectively.
- DO NOT use the system where it can be interfere with other devices and cause any potential danger.
- DO NOT use the system with medical devices.
- DO NOT use the system in hazardous environment.
- DO NOT expose the system to high humidity, chemical environment or mechanical impacts.
- DO NOT attempt to personally repair the system.
- System label is on the bottom side of the device.



2G/4G alarm system ESIM484 is a device mounted in limited access areas. Any system repairs must be done only by qualified, safety aware personnel.




The system must be powered by main 16-24V 50/60Hz ~3A max or 18-24V  3A max power supply which must be approved by LST EN 60950-1 standard and be easily accessible nearby the device. When connecting the power supply to the system, switching the pole terminals places does not have any affect.



Any additional devices linked to the system ESIM484 (computer, sensors, relays etc.) must be approved by LST EN 60950-1 standard.



The power supply can be connected to AC mains only inside installation room with automatic 2-pole circuit breaker capable of disconnecting circuit in the event of short circuit or over-current condition. Open circuit breaker must have a gap between connections of more than 3mm (0.12in) and the disconnection current 5A.



Mains power and backup battery must be disconnected before any installation or tuning work starts. The system installation or maintenance must not be done during stormy conditions



Backup battery must be connected via the connection which in the case of breaking would result in disconnection of one of battery pole terminals. Special care must be taken when connecting positive and negative battery terminals. Switching the pole terminals places is NOT allowed.



In order to avoid fire or explosion hazards the system must be used only with approved backup battery.



The device is fully turned off by disconnecting 2-pole switch off device of the main power supply and disconnecting backup battery connector.



Fuse F1 type - Slow Blown 4A. Replacement fuses have to be exactly the same as indicated by the manufacturer.



If you use I security class computer for setting the parameters it must be connected to earth.

Contents

1. GENERAL INFORMATION	8
1.1. Functionality	8
1.2. Compatible Device Overview	8
1.3. Default Parameters and Ways of Parameter Configuration	8
2. Technical Specifications	16
2.1. Electrical and Mechanical Characteristics	16
2.2. Main Unit, LED Indicator and Connector Functionality	17
2.3. Wiring Diagrams	18
3. INSTALLATION	24
4. GENERAL OPERATIONAL DESCRIPTION	28
5. CONFIGURATION METHODS	29
5.1. SMS Text Messages	29
5.2. EKB2 LCD Keypad	29
5.3. EKB3/EKB3W/EWKB4 LED Keypads	30
5.4. Eldes Utility	30
5.5. System configuration by USB cable	31
6. SMS PASSWORD AND INSTALLER CODE	32
7. SYSTEM LANGUAGE	33
8. USER PHONE NUMBERS	34
8.1. User Phone Number Names	35
8.2. Initiate system's remote connection from any phone number	35
9. DATE AND TIME	36
9.1. Time Synchronization	37
10. MASTER AND USER CODES	38
10.1. Master and User Code Names	40
11. IBUTTON KEYS	41
11.1. Adding and Removing iButton Keys	41
11.2. iButton Key Names	42
12. ARMING AND DISARMING	43
12.1. Free of Charge Phone Call	44
12.2. SMS Text Message	44
12.3. EKB2 Keypad and User/Master Code	45
12.4. EKB3 Keypad and User/Master Code	47
12.5. EKB3W/EWKB4 Keypads and User/Master Code	49
12.6. iButton Key	51
12.7. EWK2 Wireless Key fob	52
12.8. Arm-Disarm by Zone	53
12.9. Automatic Arm/Disarm by Schedule	53
12.10. Disabling and Enabling Arm/Disarm Confirmation SMS	53
13. EXIT AND ENTRY DELAY	55
14. ZONES	57
14.1. Zone Numbering	57
14.2. Zone Expansion	57
14.3. 10-Zone Mode	57
14.4. ATZ (Advanced Technology Zone) Mode	58
14.5. Zone Type Definitions	58
14.6. Zone Attributes	59
14.7. Bypassing and Activating Zones	63
14.8. Zone Names	63
14.9. Disabling and Enabling Zones	64
14.10. Viewing Zone State	65
15. STAY MODE	66
16. TAMPERS	67
16.1. Tamper Names	68
17. ALARM INDICATIONS AND NOTIFICATIONS FOR USER	69
17.1. Enabling and Disabling Alarm Notifications	70
17.2. Audio Files and Introduction Audio	72
18. PROGRAMMABLE (PGM) OUTPUTS	73
18.1. PGM Output Numbering	73
18.2. PGM Output Type	73
18.3. PGM Output Control Options	73

18.4. PGM Output Expansion.....	73
18.5. PGM Output Names.....	74
18.6. Disabling and Enabling PGM Outputs.....	74
18.7. Turning PGM Outputs ON and OFF.....	74
18.8. Automated Control Events (PGM Output Control and System Control).....	76
18.8.1. Automated Control by Schedule.....	77
18.8.2. Automated Control by Condition Event.....	77
18.9. Wireless PGM Output Type Definitions.....	77
19. WIRELESS DEVICES.....	78
19.1. Pairing, Removing and Replacing Wireless Device.....	79
19.2. Wireless Device Information.....	80
19.3. Wireless Signal Status Monitoring.....	80
19.4. Disabling and Enabling Siren if Wireless Signal is Lost.....	83
19.5. EKB3W/EWKB4 - Wireless LED Keypad.....	83
19.6. EWF1/EWF1C0 - Wireless Smoke/CO Detector.....	85
19.7. EW2 - Wireless Zone and PGM Output Expansion Module.....	87
19.8. EWM1 - Wireless Power Socket.....	87
20. WIRED SIREN/BELL.....	89
20.1. BELL Output Status Monitoring.....	90
20.2. Bell Squawk.....	90
20.3. Bell Squawk in Stay Mode.....	91
20.4. Indication by EWS2 - Wireless Outdoor Siren Indicators.....	92
20.5. Indication by EWS3 - Wireless Indoor Siren Indicators.....	93
21. BACKUP BATTERY, MAINS POWER STATUS MONITORING AND MEMORY.....	94
21.1. Backup Battery Status Monitoring.....	94
21.2. Mains Power Status Monitoring.....	96
22. 2G/4G CONNECTION AND ANTENNA STATUS MONITORING.....	98
22.1. 2G/4G Connection Status Monitoring.....	98
22.2. 2G/4G antenna Status Monitoring.....	99
23. PARTITIONS.....	100
23.1. Zone Partition.....	100
23.2. User Phone Number Partition.....	100
23.3. Keypad Partition and Keypad Partition Switch.....	101
23.4. User/Master Code Partition.....	102
23.5. iButton Key Partition.....	103
23.6. EWK2 Wireless Key fob Partition.....	103
24. TEMPERATURE SENSORS.....	104
24.1. Adding, Removing and Replacing On-Board Dallas Temperature Sensors.....	104
24.2. Primary and Secondary Temperature Sensors.....	105
24.3. Setting Up MIN and MAX Temperature Thresholds. Temperature Info SMS.....	106
24.4. Temperature Sensor Names.....	107
25. SYSTEM INFORMATION. INFO SMS.....	108
25.1. Periodic Info SMS.....	108
26. SYSTEM NOTIFICATIONS.....	110
26.1. SMS Text Message Delivery Restrictions.....	121
26.2. SMSC (Short Message Service Center) Phone Number.....	122
27. EVENT AND ALARM LOG.....	123
27.1. Event Log.....	123
27.2. Alarm Log.....	124
28. INDICATION OF SYSTEM FAULTS.....	125
29. MONITORING STATION.....	127
29.1. Data Messages - Events.....	128
29.2. Communication.....	134
30. WIRED DEVICES.....	146
30.1. RS485 Interface.....	146
30.2. 1-Wire Interface.....	155
31. SERVICE MODE.....	156
32. REMOTE SYSTEM RESTART.....	156
33. ELDES CLOUD SERVICES.....	157
34. IP cameras support.....	157
35. TECHNICAL SUPPORT.....	158
35.1. Troubleshooting.....	158
35.2. Restoring Default Parameters.....	158
35.3. Updating the Firmware via USB Cable Locally.....	158

35.4. Updating Firmware via 2G/4G Connection Remotely 159

35.5. Frequently Asked Questions 159

36. RELATED PRODUCTS.....161

37. GLOSSARY - APPENDIX 1 164

38. EKB3/EKB3W/EWKB4 COMMANDS - APPENDIX 2 166

39. SMS COMMANDS - APPENDIX 3177

40. Radio system installation and signal penetration - APPENDIX 4..... 180

41. 2-WIRE SMOKE CONNECTION - APPENDIX 5 183

TERMS OF USE

The following terms and conditions govern use of the ESIM484 device and contains important information on limitations regarding the product's use and function, as well as information on the limitations of the manufacturer's liability. Please carefully read these terms and conditions. For more information on your product, please visit www.eldesalarms.com

TECHNICAL SUPPORT

In order to ensure continuous and proper operation of the ESIM484 device and uninterrupted service, it is the responsibility of the User to make sure that: (I) the product is properly installed, and (II) there is constant internet or 2G/4G connection and electrical supply (low battery must be replaced in time).

If you experience difficulty during the installation or subsequent use of the system, you may contact E ALARMS, UAB distributor or dealer in your country/region. For more information see www.eldesalarms.com

WARRANTY PROCEDURES

Warranty and out of warranty service should be obtained by contacting the system integrator/dealer/retailer/e-tailer or distributor where the customer purchased the product. When requesting for service, the proof of purchase and the product serial number must be provided. The return of the defective product should be strictly through the original route of purchase, and the customers shall pack the product appropriately to prevent the returned product from suffering in the transportation.

MANUFACTURER WARRANTY

ELDES provides a limited warranty for its products only to the person or entity that originally purchased the product from ELDES or its authorized distributor or retailer and only in case of defective workmanship and materials under normal use of the system for a period of twenty four (24) months from the date of shipment by the E ALARMS, UAB (Warranty Period). Warranty obligations do not cover expandable materials (power elements and/or batteries), holders and enclosures. The warranty remains valid only if the system is used as intended, following all guidelines outlined in this manual and in accordance with the operating conditions specified. The warranty is void if the system has been exposed to mechanical impact, chemicals, high humidity, fluids, corrosive and hazardous environments or force majeure factors.

If a hardware defect arises and a valid claim is received within the Warranty Period, at its own discretion, E ALARMS, UAB will either (a) repair a hardware defect at no charge, using new or refurbished replacement parts, or (b) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product, or (c) refund the purchase price of the product.

LIMITED LIABILITY

The buyer must agree that the system will reduce the risk of theft, burglary or other dangers but does not provide guarantee against such events. E ALARMS, UAB will not assume any responsibility regarding personal or property, or revenue loss while using the system. E ALARMS, UAB is not affiliated with any of the Internet providers, therefore, it shall not be responsible for the quality of Internet service.

E ALARMS, UAB shall also assume no liability due to direct or indirect damage or loss, as well as unreceived income when using the system, including cases, when the damages arise due to the above mentioned risks, when due to breakdown or malfunction the user is not informed in a timely manner about a risk which has arisen. In any case, the liability of E ALARMS, UAB, as much as it is allowed by the laws in force, shall not exceed the price of acquisition of the product.

CONSUMER PROTECTION LAWS

FOR CONSUMERS WHO ARE COVERED BY CONSUMER PROTECTION LAWS OR REGULATIONS IN THEIR COUNTRY OF PURCHASE OR, IF DIFFERENT, THEIR COUNTRY OF RESIDENCE, **THE BENEFITS CONFERRED BY THIS WARRANTY ARE IN ADDITION TO ALL RIGHTS AND REMEDIES CONVEYED BY SUCH CONSUMER PROTECTION LAWS AND REGULATIONS.** This warranty grants upon you specific legal rights, and you may also have other rights that vary by country, state or province.

DISPOSAL AND RECYCLING INFORMATION



The WEEE (Waste Electrical and Electronic Equipment) marking on this product (see left) or its documentation indicates that the product must not be disposed of together with household waste. To prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the system supplier, or the local authority responsible for waste disposal in your area.

Content of Pack

Item	Quantity	Item	Quantity
1. ESIM484.....	1	5. Resistors 5,6kΩ.....	20
2. SMA antenna.....	2	6. Resistors 3,3kΩ.....	20
3. Back-up battery connection wire	1	7. Plastic standoffs.....	4
3. User manual.....	1		

These following components are optional (sold separately) and are not included in device’s Content of Pack:
Buzzer.

About Installation Manual

This document describes detailed installation and operation process of alarm system ESIM484. It is very important to read the installation manual before starting to use the system.

Copyright © “E ALARMS, UAB”, 2024. All rights reserved.

It is strictly forbidden to copy and distribute the information contained in this document or to pass thereof to a third party without an a priori written authorization obtained from “E ALARMS, UAB”. “E ALARMS, UAB” reserves the right to update or modify this document and/or related products without an a priori warning. “E ALARMS, UAB” hereby declares that ELDES gate controller is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at eldesalarms.com.



1. GENERAL INFORMATION

1.1. Functionality

ESIM484 - micro-controller based alarm system for houses, cottages, country homes, garages and other buildings, also capable of managing electrical appliances via cellular 2G/4G and 4G network. It can also be used as Intercom system.

Examples of using the system:

- Property security.
- Alarm switch.
- Thermostat, heating and air-conditioner control, temperature monitoring.
- Lighting, garden watering, water pump and other electrical equipment control via mobile app or via SMS messages.
- Mains power status notification by mobile app or by SMS message.

1.2. Compatible Device Overview

Wired Devices		
Device	Description	Max. Connectible Devices
EKB2	LCD keypad	4*
EKB3	LED keypad	4*
EPGM1	16 zone and 2 PGM output expansion module	2
ELAN3-ALARM	Ethernet communicator	1
EKB6	Android Tablet	2**

Wireless Devices		
Device	Description	Max. Connectible Devices
EW2	Wireless 2 zone and 2 PGM output expansion module	32****
EW2	Wireless motion detector	64**
EW2	Wireless motion detector	64**
EW2	Wireless magnetic door contact/shock sensor/flood sensor	64**
EW2	Wireless magnetic door contact/shock sensor/flood sensor	64**
EW2	Wireless key fob with 4 buttons	5/16*** (depends on configuration)
EW2	Wireless key fob with 4 buttons	10**
EW2	Wireless indoor siren	8**
EW2	Wireless key fob with 1 button	16***
EW2	Wireless outdoor siren	8**
EW2	Wireless LED keypad	4**
EW2	Wireless LED keypad	4**
EW2	Wireless smoke detector	64**
EW2	Wireless smoke and CO detector	64**
EW2	Wireless power socket	32**

* - A mixed combination of EKB2 and EKB3 keypads is supported. The combination can consist of up to 4 keypads in total.

** - A mixed combination of wireless devices is supported. The combination can consist of up to 64 wireless devices in total.

*** - A mixed combination of EWK2 and EWK2A key fobs is supported. The combination can consist of up to 5 key fobs in total.

**** - EW2 creates 4 wireless zones, therefore the max. number of connectible EW2 devices is 32 if no keypad zones, no EPGM1 and no virtual zones exist in the system's configuration.

1.3. Default Parameters and Ways of Parameter Configuration

Main Settings					
Parameter	Default Value	Configurable by:			
		SMS	EKB2	EKB3/ EKB3W/ EWKB4	Eldes Utility
User 1... 10 name	N/A				✓
User 1... 10 phone number	N/A	✓	✓	✓	✓
User 1... 10 partition	Partition 1		✓	✓	✓
User 1...10 - call in case of alarm	Enabled		✓	✓	✓
Allow remote connection from any phone number	Disabled	✓	✓	✓	✓
SMS password	0000	✓	✓	✓	✓
SMS language	Depends on the firmware				
Partition 1 name	PART1				✓
Partition 2 name	PART2				✓
Partition 3 name	PART3				✓
Partition 4 name	PART4				✓
Partition 1... 4 exit delay	15 seconds	✓	✓	✓	✓
2G/4G signal loss indication - delay	180 seconds				✓
2G/4G signal loss indication - activate output	N/A				✓

Management					
Parameter	Default Value	Configurable by:			
		SMS	EKB2	EKB3/ EKB3W/ EKB4	Eldes Utility
Passwords/Codes					
Installer's code	1470		✓	✓	✓
Duress code	N/A		✓	✓	✓
SGS code	N/A		✓	✓	✓
Passwords/codes format	4-digit				✓
Prompt additionally for master code when configuring via keypad/software	Disabled				✓
Master code	1111		✓	✓	✓
Master code name	N/A				✓
Master code partition	Partition 1, Partition 2, Partition 3, Partition 4		✓	✓	✓
User code 2... 30	N/A		✓	✓	✓
User code 2... 30 name	N/A				✓
User code 2... 30 partition	Partition 1		✓	✓	✓
Faults					
Main power loss	Enabled				✓
Low battery	Enabled				✓
Battery dead or missing	Enabled				✓
Battery failed	Enabled				✓
Wired siren failed	Enabled				✓
RF jammer detected	Enabled				✓
Tamper alarm	Enabled				✓
Date/time not set	Enabled				✓
2G/4G connection failed	Enabled				✓
2G/4G antenna failed	Enabled				✓
Wireless antenna failed	Enabled				✓
Communication bus failed	Enabled				✓
Critical CO level	Enabled				✓
Wireless power socket fault	Enabled				✓
Wireless device low battery	Enabled				✓
Communication with MS failed	Disabled				✓
Notifications					
System armed - User 1... 10	Enabled		✓	✓	✓
System armed - SMS delivery report	Enabled		✓	✓	✓
System disarmed - User 1... 10	Enabled		✓	✓	✓
System disarmed - SMS delivery report	Enabled		✓	✓	✓
General alarm - User 1... 10	Enabled		✓	✓	✓
General alarm - SMS delivery report	Enabled		✓	✓	✓
Main power loss/restore - User 1... 10	Enabled		✓	✓	✓
Main power loss/restore - SMS delivery report	Enabled		✓	✓	✓
Battery failed - User 1... 10	Enabled		✓	✓	✓
Battery failed - SMS delivery report	Enabled		✓	✓	✓
Battery dead or missing - User 1... 10	Enabled		✓	✓	✓
Battery dead or missing - SMS delivery report	Enabled		✓	✓	✓
Low battery - User 1... 10	Enabled		✓	✓	✓
Low battery - SMS delivery report	Enabled		✓	✓	✓
Siren fail/restore - User 1... 10	Disabled		✓	✓	✓
Siren fail/restore - SMS delivery report	Disabled		✓	✓	✓
RF jammer detected - User 1... 10	Disabled		✓	✓	✓
RF jammer detected - SMS delivery report	Disabled		✓	✓	✓
Date/time not set - User 1... 10	Disabled		✓	✓	✓
Date/time not set - SMS delivery report	Disabled		✓	✓	✓
2G/4G connection failed - User 1... 10	Disabled		✓	✓	✓
2G/4G connection failed - SMS delivery report	Disabled		✓	✓	✓

2G/4G antenna fail/restore - User 1... 10	Disabled		✓	✓	✓
2G/4G antenna fail/restore - SMS delivery report	Disabled		✓	✓	✓
Tamper alarm/restore - User 1... 10	Enabled		✓	✓	✓
Tamper alarm/restore - SMS delivery report	Enabled		✓	✓	✓
Communication bus fail/restore - User 1... 10	Enabled		✓	✓	✓
Communication bus fail/restore - SMS delivery report	Enabled		✓	✓	✓
Temperature info - User 1... 10	Enabled		✓	✓	✓
Temperature info - SMS delivery report	Enabled		✓	✓	✓
System started - User 1... 10	Enabled		✓	✓	✓
System started - SMS delivery report	Enabled		✓	✓	✓
Periodical info - User 1... 10	Enabled		✓	✓	✓
Periodical info - SMS delivery report	Enabled		✓	✓	✓
Wireless signal loss - User 1... 10	Enabled		✓	✓	✓
Wireless signal loss - SMS delivery report	Enabled		✓	✓	✓
Unable to arm - User 1... 10	Enabled		✓	✓	✓
Unable to arm - SMS delivery report	Enabled		✓	✓	✓
Zone bypass - User 1... 10	Enabled		✓	✓	✓
Zone bypass - SMS delivery report	Enabled		✓	✓	✓
Critical CO level - User 1... 10	Enabled		✓	✓	✓
Critical CO level - SMS delivery report	Enabled		✓	✓	✓
Wireless socket signal loss/restore - User 1... 10	Disabled			✓	✓
Wireless socket signal loss/restore - SMS delivery report	Disabled			✓	✓
Report/Control zone triggered - User 1... 10	Enabled		✓	✓	✓
Report/Control zone triggered - SMS delivery report	Enabled		✓	✓	✓
Incoming SMS forwarding - User 1... 10	Enabled			✓	✓
Incoming SMS forwarding - SMS delivery report	Enabled			✓	✓
Wireless communication failed - User 1... 10	Disabled		✓	✓	✓
Wireless communication failed - SMS delivery report	Disabled		✓	✓	✓
Communication with MS failed - User 1... 10	Disabled				✓
Communication with MS failed - SMS delivery report	Disabled				✓
Send to all users simultaneously - all notifications	Disabled		✓	✓	✓

Time Synchronization

Time synchronization	Enabled				✓
Phone number of the currently inserted SIM card	N/A				✓
Synchronization frequency	30 days				✓

Event Log

Event log	Enabled	✓	✓	✓	✓
-----------	---------	---	---	---	---

Zones

Parameter	Default Value	Configurable by:			
		SMS	EKB2	EKB3/ EKB3w/ EWKB4	Eldes Utility
On Board					
Z1... Z8 zone name	Zone1... Zone8	✓			✓
Z1 type	Delay		✓	✓	✓
Z1... Z8 zone status	Enabled	✓	✓	✓	✓
Z2... Z8 type	Instant		✓	✓	✓
Z1... Z8 delay, ms	800 milliseconds				✓
Z1... Z8 - Stay	Disabled		✓	✓	✓
Z1... Z8 - Force	Disabled		✓	✓	✓
Z1... Z8 Tamper name	Tamper1... Tamper8				✓
Delay-type zone - entry delay	15 seconds	✓	✓	✓	✓
Z1... Z8 partition	Partition 1		✓	✓	✓
Z1... Z8 - Shared	Disabled				✓
Z1... Z8 - audio track	N/A				✓
Z1... Z8 - alarm count to bypass	0				✓

Cross-Zone/Intelli-Zone	N/A				✓
Confirmation Timeout	20 seconds				✓
Tamper 1... 8 status	Enabled				✓
Z1... Z8 - zone connection type	Type 1				✓
Delay becomes Instant in STAY mode	Disabled				✓
Chime	Enabled		✓	✓	✓
ATZ mode	Disabled		✓	✓	✓
Arm-disarm by zone No1... No4	N/A		✓	✓	✓
EPGM1 Module					
Zone name	Zone X	✓			✓
Zone status	Enabled	✓	✓	✓	✓
Type	Instant		✓	✓	✓
Delay, ms	800 milliseconds				✓
Stay	Disabled		✓	✓	✓
Force	Disabled		✓	✓	✓
Tamper name	Tamper X				✓
Delay-type zone - entry delay	15 seconds		✓	✓	✓
Partition	Partition 1		✓	✓	✓
Shared	Disabled				✓
Audio track	N/A				✓
Alarm count to bypass	0				✓
Cross-Zone/Intelli-Zone	N/A				✓
Confirmation Timeout	20 seconds				✓
Tamper status	Enabled				✓
Zone connection type for all EPGM1 zones	Type 1				✓
Wireless Devices					
Zone name	Zone X	✓			✓
Zone status	Enabled	✓	✓	✓	✓
Type	Depends on the connected wireless device model		✓	✓	✓
Stay	Disabled		✓	✓	✓
Force	Disabled		✓	✓	✓
Tamper name	Tamper X				✓
Delay-type zone - entry delay	15 seconds		✓	✓	✓
Partition	Partition 1		✓	✓	✓
Shared	Disabled				✓
Audio track	N/A				✓
Alarm count to bypass	0				✓
Cross-Zone/Intelli-Zone	N/A				✓
Confirmation Timeout	20 seconds				✓
Tamper status	Enabled				✓
Keypads					
Zone name	Zone X	✓			✓
Zone status	Disabled	✓	✓	✓	✓
Type	Instant		✓	✓	✓
Stay	Disabled		✓	✓	✓
Force	Disabled		✓	✓	✓
Tamper name	Tamper X				✓
Delay-type zone - entry delay	15 seconds		✓	✓	✓
Partition	Partition 1		✓	✓	✓
Shared	Disabled				✓
Audio track	N/A				✓
Alarm count to bypass	0				✓
Cross-Zone/Intelli-Zone	N/A				✓
Confirmation Timeout	20 seconds				✓
Tamper status	Enabled				✓
Virtual Zones					
Zone name	Zone X				✓
Zone status	Disabled			✓	✓
Type	Instant			✓	✓

Force	Disabled			✓	✓
Delay-type zone - entry delay	15 seconds			✓	✓
Partition	Partition 1			✓	✓
Shared	Disabled				✓
Alarm count to bypass	0				✓
Cross-Zone/Intelli-Zone	N/A				✓
Confirmation Timeout	20 seconds				✓
Tamper status	Enabled				✓

PGM Outputs					
Parameter	Default Value	Configurable by:			
		SMS	EKB2	EKB3/ EKB3W/ EKB4	Eldes Utility
On Board					
C1... C4 output name	Controll1... Controll4	✓			✓
C1... C4 output state	OFF	✓	✓	✓	✓
C1... C4 output status	Enabled				✓
EPGM1 Module					
Output name	ControllX	✓			✓
State	OFF	✓	✓	✓	✓
Status	Disabled				✓
Wireless Devices					
Output name	ControllX	✓			✓
Type	Depends on the connected wireless device model				✓
State	OFF	✓	✓	✓	✓
Status	Disabled				✓

Monitoring Station (MS) Settings					
Parameter	Default Value	Configurable by:			
		SMS	EKB2	EKB3/ EKB3W/ EKB4	Eldes Utility
Management					
MS mode	Disabled	✓	✓	✓	✓
Main Account	9999		✓	✓	✓
2G/4G and SMS - attempts	3		✓	✓	✓
2G/4G and SMS - tel. number 1... 3	N/A		✓	✓	✓
PSTN - treat PSTN call as user call	Disable				✓
PSTN - attempts	3		✓	✓	✓
PSTN - tel. number 1... 3	N/A		✓	✓	✓
Parallel data transfer via IP network	Disabled		✓	✓	✓
IP Server 1... 3 - IP attempts	3		✓	✓	✓
IP Server 1... 3 - test period	180 seconds		✓	✓	✓
IP Server 1... 3 - protocol	UDP	✓	✓	✓	✓
IP Server 1... 3 - account	9999		✓	✓	✓
IP Server 1... 3 - unit ID	0000		✓	✓	✓
IP Server 1... 3 - communication protocol	EGR100		✓	✓	✓
IP Server 1... 3 - server IP	0.0.0.0	✓	✓	✓	✓
IP Server 1... 3 - server port	20000	✓	✓	✓	✓
IP Server 1... 3 - encryption key - status	Disabled				✓
IP Server 1... 3 - encryption key	0000				✓
Communication - primary	IP Server 1 (2G/4G)		✓	✓	✓
Communication - backup 1... 5	N/A		✓	✓	✓
Retry after delay	N/A				✓
Delay after last communication attempt	1200 seconds		✓	✓	✓
SIA IP protocol settings - encryption	Disabled				✓
SIA IP protocol settings - encryption key	0000				✓
SIA IP protocol settings - account prefix	N/A				✓
SIA IP protocol settings - receiver number	N/A				✓
SIA IP protocol settings - use time stamp	Enabled				✓
SIA IP protocol settings - Contact ID ping	Disabled				✓
SIA IP protocol settings - data message	Event: 1602, partition: 01, user/zone: 000				✓

Data Messages					
Burglary alarm/restore - code	130				✓
Burglary alarm/restore - status	Enabled		✓	✓	✓
Main power loss/restore - code	301				✓
Main power loss/restore - status	Enabled		✓	✓	✓
Armed/disarmed by user - code	401				✓
Armed/disarmed by user - status	Enabled		✓	✓	✓
Test event - code	602				✓
Test event - status	Enabled		✓	✓	✓
Battery failed - code	309				✓
Battery failed - status	Enabled		✓	✓	✓
Battery dead or missing - code	311				✓
Battery dead or missing - status	Enabled		✓	✓	✓
Tamper alarm/restore - code	144				✓
Tamper alarm/restore - status	Enabled		✓	✓	✓
Instant Silent zone alarm/restore - code	146				✓
Instant Silent zone alarm/restore - status	Enabled		✓	✓	✓
Kronos ping - code	602				✓
Kronos ping - status	Enabled		✓	✓	✓
System started - code	900				✓
System started - status	Enabled		✓	✓	✓
24H zone alarm/restore - code	133				✓
24H zone alarm/restore - status	Enabled		✓	✓	✓
Fire zone alarm/restore - code	110				✓
Fire zone alarm/restore - status	Enabled		✓	✓	✓
Low battery - code	302				✓
Low battery - status	Enabled		✓	✓	✓
Temperature exceeded - code	158				✓
Temperature exceeded - status	Enabled		✓	✓	✓
Temperature fallen - code	159				✓
Temperature fallen - status	Enabled		✓	✓	✓
Wireless signal loss/restore - code	381				✓
Wireless signal loss/restore - status	Enabled		✓	✓	✓
Disarmed by user (duress code) - code	121				✓
Disarmed by user (duress code) - status	Enabled		✓	✓	✓
SGS code entered - code	463				✓
SGS code entered - status	Enabled		✓	✓	✓
Armed by user (partial arm) - code	456				✓
Armed by user (partial arm) - status	Enabled		✓	✓	✓
RF jammer detected - code	344				✓
RF jammer detected - status	Enabled		✓	✓	✓
Siren fail/restore - code	321				✓
Siren fail/restore - status	Disabled		✓	✓	✓
Date/time not set - code	626				✓
Date/time not set - status	Enabled		✓	✓	✓
2G/4G connection failed - code	358				✓
2G/4G connection failed - status	Enabled		✓	✓	✓
2G/4G antenna fail/restore - code	359				✓
2G/4G antenna fail/restore - status	Disabled		✓	✓	✓
System shutdown - code	414				✓
System shutdown - status	Enabled		✓	✓	✓
Communication bus fail/restore - code	330				✓
Communication bus fail/restore - status	Enabled		✓	✓	✓
IP connection failed - code	360				✓
IP connection failed - status	Enabled		✓	✓	✓
Zone bypass/Bypassed zone activation - code	570				✓
Zone bypass/Bypassed zone activation - status	Enabled		✓	✓	✓
CO sensor lifetime exceeded -code	380				✓
CO sensor lifetime exceeded -status	Enabled		✓	✓	✓
Critical CO level - code	162				✓
Critical CO level - status	Enabled		✓	✓	✓
Report/Control zone triggered/restored - code	150				✓
Report/Control zone triggered/restored - status	Disabled		✓	✓	✓
Armed/disarmed in STAY mode - code	441				✓

Armed/disarmed in STAY mode - status	Enabled		✓	✓	✓
Configuration via remote connection started - code	412				✓
Configuration via remote connection started - status	Disabled		✓	✓	✓
Silent/Panic zone alarm/restore - code	120				✓
Silent/Panic zone alarm/restore - status	Enabled		✓	✓	✓
Armed/disarmed automatically - code	403				✓
Armed/disarmed automatically - status	Enabled		✓	✓	✓
SMS sending limit reached - code	358				✓
SMS sending limit reached - status	Disabled		✓	✓	✓
Failed to arm - code	454				✓
Failed to arm - status	Enabled		✓	✓	✓
Communication with MS failed - code	354				✓
Communication with MS failed - status	Disabled		✓	✓	✓

Automated Control / Schedule					
Parameter	Default Value	Configurable by:			
		SMS	EKB2	EKB3/ EKB3W/ EWKB4	Eldes Utility
PGM output control/System control 1... 48	Disabled				✓
Schedule 1... 32	Disabled				✓
Condition event 1...20	Disabled				✓

Peripheral Devices					
Parameter	Default Value	Configurable by:			
		SMS	EKB2	EKB3/ EKB3W/ EWKB4	Eldes Utility
Keypads					
Keypad 1... 4 partition	Partition 1		✓	✓	✓
Show armed status in keypad	Disabled				✓
Keypad partition switch	Disabled		✓	✓	✓
EKB3 mode	2 partitions				✓
Wireless keypads - partition	Partition 1		✓	✓	✓
Wireless keypads - backlight timeout	10 seconds				✓
Wireless keypads - bell	Disabled				✓

Siren					
EWS2 LED	Enabled		✓	✓	✓
Bell squawk	Disabled		✓	✓	✓
Activate siren if wireless device is lost	Disabled		✓	✓	✓
EWS3 fire alarm LED	Disabled		✓	✓	✓
EWS3 alarm LED	Disabled		✓	✓	✓
Bell squawk enabled if arming in STAY mode	Disabled		✓	✓	✓

Temperature Sensors					
Temperature sensor 1... 8 name	N/A	✓			✓
Temperature sensor 1... 8 min. temperature	0	✓	✓	✓	✓
Temperature sensor 1... 8 max. temperature	0	✓	✓	✓	✓
Primary	No.1	✓	✓	✓	✓
Secondary	No.2	✓	✓	✓	✓



iButton Keys					
iButton key name	N/A				✓
iButton key partition	Partition 1		✓	✓	✓
Allow adding new iButton keys	Disabled	✓	✓	✓	✓

System					
Parameter	Default Value	Configurable by:			
		SMS	EKB2	EKB3/ EKB3W/ EWKB4	Eldes Utility

Management					
Mains power loss delay	30 seconds		✓	✓	✓
Mains power restore delay	120 seconds		✓	✓	✓
Alarm duration	1 minute	✓	✓	✓	✓
Wireless channel	Depends on firmware				✓
Periodic test	Every 1 day at 11:00	✓	✓	✓	✓
Wireless device lost timeout	Grade 2				✓
Arming is not allowed after 20 mins of wireless communication loss	Disabled				✓
SMS notifications - day limit	25				✓
SMS notifications - day limit status	Enabled				✓
SMS notifications - month limit	400				✓
SMS notifications - month limit status	Enabled				✓
Speaker level	85		✓		✓
SMS forward settings - forward all received SMS	Disabled				✓
SMS forward settings - forward all received SMS from unknown users	Disabled				✓
SMS forward settings -forward all received SMS from registered users with wrong syntax or wrong password	Disabled				✓
SMS forward settings - forward all received SMS from specified phone number (status)	Disabled				✓
SMS forward settings - forward all received SMS from specified phone number (phone number)	N/A				✓
Service mode	Disabled	✓	✓	✓	✓
Cloud Services					
Cloud Services	Disabled	✓			✓
Server address	ss.eldes.it	✓			✓
Port	8082	✓			✓
Ping period	180 seconds	✓			✓
Time zone	N/A				✓
Communication	Via 2G/4G network				✓
2G/4G Settings					
SIM1 APN	N/A	✓			✓
SIM1 user name	N/A	✓			✓
SIM1 password	N/A	✓			✓
DNS1	N/A	✓	✓	✓	✓
DNS2	N/A	✓	✓	✓	✓
LAN Settings					
DHCP	Disabled				✓
LAN IP address	0.0.0.0				✓
LAN net mask	0.0.0.0				✓
Default gateway	0.0.0.0				✓
Primary DNS server	0.0.0.0				✓
Secondary DNS server	0.0.0.0				✓


2. TECHNICAL SPECIFICATIONS

2.1. Electrical and Mechanical Characteristics

Electrical and Mechanical Characteristics	
Power supply	16-24V 50/60 Hz ~1.5A max / 18-24V  1,5A max
Current consumption in idle state w/o external devices connected	Up to 80mA
Recommended backup battery voltage, capacity	12V; 1,3-7Ah
Recommended backup battery type	Lead-Acid
Backup battery charge current	Up to 500mA
Backup battery charge duration	Up to 30 hours for 7Ah battery
2G/4G modem frequency	2G 900/1800MHz; 4G 700/800/900/1800/2100/2600MHz
Modem RF power	2G 35/32dBm; 4G 25dBm
Cable type for 2G/4G antenna connection	Shielded
Number of zones on-board	10 (ATZ mode: 20)
Nominal zone resistance	5,6kΩ (ATZ Mode: 5,6kΩ and 3,3kΩ)
Number of PGM outputs on-board	4
On-board PGM output circuit	 <p>Open collector output. Output is pulled to COM when turned ON.</p>
Maximum commuting on-board PGM output values (combined)	4 x 30V; 500mA
BELL: Siren output when activated	Connected to COM
BELL: Maximum siren output current	1A
BELL: Maximum cable length for siren connection	Up to 100m (328.08ft)
BELL: Cable type for siren connection	Unshielded
AUX: Auxiliary equipment power supply voltage	13,8V DC
AUX: Maximum accumulative current of auxiliary equipment	2.0A
AUX: Maximum cable length for auxiliary equipment connection	Up to 100m (328.08ft)
AUX: Cable type for auxiliary equipment connection	Unshielded
BUZ: Maximum current of mini buzzer	150mA
BUZ: Power supply voltage of buzzer	12V DC
BUZ: Cable type for mini buzzer connection	Unshielded
Supported temperature sensor model	Maxim®/Dallas® DS18S20, DS18B20
Maximum supported number of temperature sensors	8
DATA: Maximum cable length for 1-Wire communication	Up to 30m (98.43ft)
DATA: Cable type for 1-Wire communication	Unshielded
Supported iButton key model	Maxim®/Dallas® DS1990A
Maximum supported number of iButton keys	16
Maximum supported number of keypads	4 x EKB2 / EKB3
Y/G: Maximum cable length for RS485 communication	Up to 100m (328.08ft)
Y/G: Cable type for RS485 communication	Unshielded
Wireless band	ISM868
Wireless communication range	Up to 3000m (9842.6ft) in open areas
Maximum supported number of wireless devices	64
Event log size	1024 events
Maximum supported number of zones	144
Maximum supported number of PGM outputs	48
Cable type for zone and PGM output connection	Unshielded
Communications	SMS, Voice calls, 2G/4G network, Ethernet via ELAN3-ALARM
Supported protocols	Ademco Contact ID, EGR100, Kronos, SMS, SIA IP
Dimensions	140x100x18mm (5.51x3.94x0.71in)
Operating temperature range	-20...+55°C (-4...+131°F)
Humidity	0-90% RH @ 0...+40°C (0-90% RH @ +32...+104°F) (non-condensing)

2.2. Main Unit, LED Indicator and Connector Functionality

Main Unit Functionality	
2G/4G MODEM	900/1800MHz 2G; 700/800/900/1800/2100/2600MHz 4G;
SIM CARD	nano SIM card
DEF	Pins for restoring default settings
USB	USB-C port
FUSE F1	2A fuse
W-LESS ANT	Wireless antenna SMA type connector
2G/4G ANT	2G/4G antenna SMA type connector



LED Functionality	
NETW	2G/4G network signal strength
C1	PGM output C1 status - ON/OFF
C2	PGM output C2 status - ON/OFF
C3	PGM output C3 status - ON/OFF
C4	PGM output C4 status - ON/OFF
STAT	Micro-controller status


NETW indication	2G/4G signal strength
OFF	No 2G/4G signal
Flashing every 3 sec.	Poor
Flashing every 1 sec.	Medium
Flashing several times per sec.	Good
Steady ON	Excellent

Connector Functionality	
DATA	1-Wire interface for iButton key and temperature sensor connection
+5V	Temperature sensor power supply terminal (+5V)
BUZ-	Buzzer negative terminal
BUZ+	Buzzer positive terminal
C1 - C4	PGM output terminals (NOTE: PGM output C2 is may be configured to support 2-wire smoke sensors)
Z1-Z10	Security zone terminals
Y	RS485 interface CLOCK terminal (yellow wire)
G	RS485 interface DATA terminal (green wire)
COM	Common return terminal
BELL-	Siren negative terminal (Commutated)
BELL+	Siren positive terminal (Constant voltage)
AUX-	Negative power supply terminal for auxiliary equipment
AUX+	Positive power supply terminal for auxiliary equipment
AC/DC	Main power supply terminals
AKU-	Backup battery negative terminal
AKU+	Backup battery positive terminal

* - implementable **ONLY** if ESIM484 device hardware version is up to V5.


2.3. Wiring Diagrams

2.3.1.General Wiring




2.3.2. Zone Connection Types

Type 1 Example of 4-wire smoke detector wiring



10-Zone mode: Normally open contact with 5,6KΩ end-of-line resistor.

Type 2 Example of magnetic door contact wiring




10-Zone mode: Normally closed contact with 5,6KΩ end-of-line resistor

NOTE: 2-wire smoke sensors support is **NOT** available for old firmware versions (i.e. for FW versions **V01.05.11 and earlier**).

NOTE: Based on the example given, in the event of an alarm, the smoke detector could be reset by turning OFF and ON the PGM output C1. For more details, please refer to **18.7. Turning PGM Outputs ON and OFF**.


Type 3

Example of motion detector wiring




Type 4

Example of magnetic door contact (Z1) and glass break sensor (Z9) wiring




Type 5

Example of motion detector (Z1) and magnetic door contact (Z9) wiring




See also **14.3. 10-Zone Mode** and **14.4. ATZ (Advanced Technology Zone) Mode**.

2.3.3. Siren




Piezo siren

- 1 Connect positive siren wire (red) to **BELL+** terminal.
- 2 Connect negative siren wire (black) to **BELL-** terminal.




Self-contained siren

- 1 Connect negative **GND** siren wire to **COM** terminal.
- 2 Controlling **BELL** siren wire must be connected to **BELL-** terminal.
- 3 Connect positive **+12V** siren wire to **BELL+** terminal.



Siren status monitoring

NOTE: Siren status monitoring feature supervises the resistance across **BELL+** and **BELL-** terminals. The resistance must be ranging from 1kΩ through 3,3kΩ, otherwise the system will indicate system fault. In order to view the siren resistance value, please refer to Diagnostic Management feature available on Eldes Utility.



No siren status monitoring


If the siren status monitoring feature is not required, do not connect any resistor in parallel and disable siren fault indication on the keypad (see **29. INDICATION OF SYSTEM FAULTS**).

See also **20. SIREN/BELL**.

NOTE: BELL- is the commuted terminal intended for siren control.

NOTE: Siren status monitoring feature supervises the resistance across **BELL+** and **BELL-** terminals. The resistance must be ranging from 1kΩ through 3,3kΩ, otherwise the system will indicate system fault. In order to view the siren resistance value, please refer to Diagnostic Management feature available on *Eldes Utility*.

2.3.4. iButton Key Reader and Buzzer



Supported iButton key model: Maxim/Dallas DS1990A

The iButton key reader can be installed with buzzer or separately. The buzzer is intended for audio indication of exit/entry delay countdown providing short beeps.

- 1 Connect iButton key reader brown and white wires to 1-Wire interface: **COM** and **DATA** terminals respectively.
- 2 Connect buzzer's negative terminal wire to **BUZ-** and positive terminal wire to **BUZ+**.


NOTE: The installation of buzzer is not necessary if EKB2/EKB3 keypad is used.

ATTENTION: The cable length for connection to 1-Wire interface can be up to 30m (98.43ft) max.

2.3.5. Temperature Sensor and iButton Key Reader

Supported iButton key model: Maxim/Dallas DS1990A

Supported temperature sensor model: Maxim/Dallas DS18S20, DS18B20




- 1 Depending on the model, connect temperature sensor **GND**/black wire, **DATA**/yellow wire, **+5V**/red wire terminals to 1-Wire interface: **COM**, **DATA** and **+5V** terminals respectively.
- 2 When connecting iButton key reader in parallel to temperature sensor, connect iButton key reader terminal wires to **COM** and **DATA** terminals respectively.

ATTENTION: The cable length for connection to 1-Wire interface can be up to 30m (98.43ft) max.

2.3.6. Relay Finder (for example, model 40.61.9.12) with Terminal Socket (for example, model 95.85.3) to PGM Output


Example of relay wiring for negative PGM output control



- 1 Wire up relay **A1** terminal to PGM output **Cx** and **A2** terminal to **AUX+**.
- 2 In addition, connect the switching diode to relay's **A2** and **A1** terminals.

NOTE: We highly recommend using switching diode model 1N4148 or similar.

Example of relay wiring for positive PGM output control




- 1 Wire up relay **A1** terminal to PGM output's **Cx** terminal and **A2** terminal to **AUX+** and one of the relay's switch contacts: NC or NO.
- 2 In addition, connect the switching diode to relay's **A2** and **A1** terminals.

NOTE: We highly recommend using switching diode model 1N4148 or similar.

2.3.7. RS485

Serial Wiring Method



Max. cable length: a+b+c+d+e+f+g= up to 100m (328.08ft)

ATTENTION: The cable length must not exceed 100m (328.08ft) in total.


ATTENTION: When wiring more than 1 keypad and/or EPGM1 module, please ensure that the set address of each keypad and/or EPGM1 module is different.

NOTE: If necessary, the RS485 devices can be powered from an external 12-14V DC power supply instead of AUX+ and AUX- terminals

NOTE: You may connect only 1 EKB2/EKB3 keypad or a mixed combination of EKB2 and EKB3 keypads. The combination can consist of up to 4 keypads in total.

For more details on RS485 interface, please refer to **32.1. RS485 Interface**

Parallel Wiring Method



ATTENTION: The cable between ESIM484 and each RS485 device must be of the same length and can NOT exceed 100m (328.08ft).

ATTENTION: When wiring more than 1 keypad and/or EPGM1 module, please ensure that the set address of each keypad and/or EPGM1 module is different.

NOTE: If necessary, the RS485 devices can be powered from an external 12-14V DC power supply instead of AUX+ and AUX- terminals

NOTE: You may connect only 1 EKB2/EKB3 keypad or a mixed combination of EKB2 and EKB3 keypads. The combination can consist of up to 4 keypads in total.


For more details on RS485 interface, please refer to **32.1. RS485 Interface**

3.INSTALLATION

When professional installation, OEM integration or assembly by a third-party is expected, the installation instructions and assembly requirements approved for equipment approval must be provided to the integrators to clearly identify the specific requirements necessary to maintain RF exposure compliance. The grantee of a transmitter, typically the manufacturer, is responsible for ensuring installers and integrators have a clear understanding of the compliance requirements by including the required instructions and documentation with the product and, if necessary, to provide further support to fulfil grantee responsibilities for ensuring compliance. The integrators must be fully informed of their obligations and verify the resolution of any issues and concerns with each transmitter manufacturer or grantee.

- The system can be installed in a metal or non-flammable cabinet only. For a convenient installation, ME1 metal cabinet is highly recommended. The metal cabinet must always be grounded as well as ESIM484 system's PCB by connecting one of the COM terminals to the PE contact of the metal cabinet.
- For the connection of 230V transformer, use 3x0.75 mm² 1 thread double isolated cable. 230V power supply cables must not be grouped with low voltage cable group.
- For the connection of auxiliary and BELL outputs, use 2x0.75 mm² 1 thread unshielded cable of up to 100m (328.08ft) length.
- For the connection of zone/PGM output connectors, use 0.50 mm² 1 thread unshielded cable of up to 100m (328.08ft) length.



SYSTEM INSTALLATION IN ME1 METAL CABINET AND ENCLOSURE COMPONENTS



FUSE	⚡	⚡	⏏	COM	AC/DC	⚡	⚡	⚡	18V	N	L
Fuse 315mA	Tamper	Transformer	PE terminal	Common terminal	Main power supply terminal	AC/DC Main power wire	GND wire	230V wire	AC voltage	Null	Phase



ELAN3-ALARM



18



ESIM484 + EPGM1

19







NOTE: The standard ME1 metal cabinet does NOT contain all of plastic standoffs, the quantity and the type of which depends on your additionally acquired device.

NOTE: Insert the plastic standoffs into the appropriate mounting points and fix the circuit board of selected device on the holders as indicated above (in pics on page 25).


NOTE: In order to appropriately install EPGM1 module, please install it in the first place and ESIM484 alarm system afterwards. EPGM1 must be mounted on shorter plastic standoffs, while ESIM484 and ELAN3-ALARM - on the longer ones. The mounting points of EPGM1 module and ESIM484 system are indicated in pics on page 25.

NOTE: You also may wire up the accessories, such as keypads, zone and PGM output expansion modules, ELAN3-ALARM module, temperature sensors. If you choose to install the buzzer, it must be closer to iButton key reader in order to hear the exit delay countdown.

1. Disable the PIN code of the SIM card by inserting it into a mobile phone and following the proper menu steps. Ensure that the additional services, such as **voice mail, call forwarding, report on missed/busy calls ("call catcher")** are disabled on the SIM card. For more details on how to disable these services, please contact your 2G/4G operator.
2. Once the PIN code is disabled, place the SIM card into the SIM CARD slot of the alarm system.




3. Connect the 2G/4G and wireless antennas and follow the recommendations for the installation:



Never install in the following locations:


- inside the metal cabinet
- closer than 20cm (7.87in) from the metal surface and/or power lines



Recommended installation:


- keep the distance of at least 20cm (7.87in) or more.

4. If one or more wireless devices are to be paired, follow the recommendations for the installation to achieve the strongest wireless signal:



Never install in the following locations:

- inside the metal cabinet
- closer than 20cm (7.87in) from the metal surface and/or power lines



Recommended installation:

- face the front side of the wireless device towards the antenna
- keep the distance: 0.5 to 30m (1.64 to 98.43ft) inside the building, 0.5 to 3000m (1.64 to 9842.6ft) in open areas

For more details on how to install the wireless devices, please refer to chapter **41. RADIO SYSTEM INSTALLATION AND SIGNAL PENETRATION** manual and the latest user manual of the wireless device located at www.eldesalarms.com

- Power up the system and wait until indicator STAT lights up (see **2.2 Main Unit, LED Indicator and Connector Functionality**).
- Indicator STAT should be flashing indicating successful micro-controller operation.
- The illuminated NETW indicator shows that the system has successfully registered to the cellular network. To find the strongest 2G/4G signal, place the 2G/4G antenna and follow the indications provided by the NETW indicator (see section **2.2: Main Unit, LED Indicator, and Connector Functionality**). We recommend using the ELDES Utility instead, where you can view separate 2G and 4G signal strength and quality
- Change the default SMS password (see **6. SMS PASSWORD AND INSTALLER CODE** for more details).
- Set the phone number for User 1 (see **8. USER PHONE NUMBERS** for more details).
- Set system date and time (see **9. DATE AND TIME** for more details).
- Once the system is fully configured, it is ready for use. However, if you fail to receive an SMS reply from the system, please check the SMSC (Short Message Service Center) phone number. For more details regarding the SMS centre phone number, please refer to **27.1. SMSC (Short Message Service Center) Phone Number**.
- If it is required to change the batteries for the wireless devices or carry out other system maintenance tasks, please activate the Service mode. For more detail regarding this mode, please refer to **33. SERVICE MODE**.

ATTENTION: The system is **NOT** compatible with pure 3G SIM cards. Only 2G/4G SIM cards with 2G/4G profile enabled are supported. For more details, please contact your GSM operator.

NOTE: The installation of iButton key reader, EKB2/EKB3/EKB3W/EWKB4 keypad, EWK2 wireless key fob is not mandatory. However, it is recommended to have those devices installed as an emergency switch in case your mobile phone is switched off or missing.

NOTE: For maximum system reliability we recommend you do NOT use a Pay As You Go SIM card. Otherwise, in the event of insufficient credit balance on the SIM card, the system would fail to make a phone call or send messages.

NOTE: We advise you to choose the same 2G/4G SIM provider for your system as for your mobile phone. This will ensure the fastest, most reliable SMS text message delivery service and phone call connection.

NOTE: Even though alarm system ESIM484 installation process is not too complicated, we still recommend to perform it by a person with basic knowledge in electrical engineering and electronics to avoid any system damage.

4. GENERAL OPERATIONAL DESCRIPTION

When the system is being armed, it will initiate the exit delay countdown intended for the user to leave the secured area. During the countdown period the buzzer will emit short beeps. By default, exit delay duration is 15 seconds. After the countdown is complete, the system will become armed and lock the configuration by keypad possibility. In case the user does not leave the secured area before the countdown is complete, the system will STAY-arm if at least 1 zone has Stay attribute enabled. By default, if there is at least 1 violated zone or tamper, the user will not be able to arm the system until the violated zone or tamper is restored. In case it is required to arm the alarm system despite the violated zone presence, the violated zone can be bypassed or Force attribute enabled. After the system is armed and if a zone (depending on type) or tamper is violated, the system will cause an alarm lasting for 1 minute (by default). During the alarm, the siren/bell will provide an alarm sound along with the buzzers of the keypads. By default, the system will also makes a phone call and send an SMS text message containing the violated zone or tamper number to a listed user phone number and indicate the violated zone or tamper number on the keypad. If another zone or tamper is violated or the same one is restored and violated again during the alarm, the system will act as mentioned previously, but will not extend the alarm time.

After the user enters the secured area, the system will initiate the entry delay countdown intended for system disarming. During the countdown period, the buzzer will emit a steady beep. By default, entry delay duration is 15 seconds. After the user successfully performs the disarming process, the system will unlock the keypads. If the user does not disarm the system in time, the alarm system will cause an instant alarm.

NOTE: The alarm will be caused even if a tamper is violated while the system is disarmed.

For more details, please refer to **12. ARMING AND DISARMING**.

5. CONFIGURATION METHODS



!!! While writing an SMS message, a single space **MUST** be left after every SMS password (e.g.: **1111 STATUS**). There must be no spaces or other unnecessary characters at the beginning and at the end of the SMS text message.

5.1. SMS Text Messages



In order to configure and control the system by SMS text message, send the text command to the ESIM484 system phone number from one of the listed user phone numbers. The structure of SMS text message consists of 4-digit SMS password (the default SMS password is 0000 - four zeros), the parameter and value. For some parameters the value does not apply e. g. STATUS. The variables are indicated in lower-case letters, while a valid parameter value range is indicated in brackets.

NOTE: By default the SMS password is 0000, which is necessary to change.

5.2. EKB2 LCD Keypad



The system configuration and control by EKB2 keypad is carried out by navigating throughout the menu section list displayed on LCD screen. To navigate in the menu path, touch ↓, ↑ keys to select the desired menu section and touch OK key to open the selected section. To enter a required value, use 0... 9 keys and touch OK key for confirmation or cancel/go one menu section back by touching ← key. The value can be typed in directly by touching 0... 9 keys while highlighting the desired menu section. EKB2 menu type is "circle", therefore when the last section in the menu list is selected, you will be brought back to the beginning of the list after touching the ↓ key. In this installation manual, the menu path is based on the EKB2 menu tree by starting at home screen view (see **32.1.1.2. Master and User Menu Tree** and **32.1.1.3. Installer Menu Tree**). The variables are provided in lower-case letters, while a valid parameter value range is provided in brackets.

Activate Configuration mode

EKB2

Menu path:
OK → iii → OK
Value: iii - 4-digit installer code.

Deactivate Configuration mode

EKB2

Return to home screen view

NOTE: By default, menu section CONFIGURATION is secured with installer code. The default installer code is 1470, while the default master code is 1111.

NOTE: The system can be configured using only one keypad at a time. Other connected keypads will be inactive while the menu section CONFIGURATION is opened. The inactive EKB2 keypads will display ✕ icon.

NOTE: The keypad will automatically exit the menu section CONFIGURATION and return to home screen view if 1 minute after the last key-touch expires.

5.3. EKB3/EKB3W/EWK4 LED Keypads



The system configuration and control by EKB3/EKB3W/EWK4 keypad is carried out by activating the Configuration mode using the installer code first (i.e. by pressing **X** key, which is the 1st character for Configuration mode activation and de-activation), followed by the installer code (by default -1470) and entering a valid configuration command using the number keys **0-9**, **#** key for confirmation and ***** key to clear the characters that have been typed. Alternatively, the user can wait for 10 seconds until the keypad buzzer will provide a long beep indicating that the entered characters have been cleared. When typing in the characters, the indication of each pressed key is provided by short beep of keypad buzzer and red indicators when the number keys **0-9** are being pressed. Some commands require **⏏**, **\$**, **X** and **...** keys as well. The structure of a standard configuration command is a combination of digits. The commands, which do not require the Configuration mode being activated, are noted. The variables are provided in lower-case letters, while a valid parameter value range is provided in brackets.

NOTE: If you have accidentally typed in an unnecessary character, please press ***** key or wait for 10 seconds until the keypad buzzer will provide a long beep indicating that the typed in characters have been cleared.

NOTE for EKB3W/EWK4: Even if Back-light Timeout has expired, the character will be considered as typed in once the appropriate EKB3W/EWK4 key is pressed. For more details, please refer to **19.5.3. Wireless Communication, Sleep Mode and Back-light Timeout**.



Activate Configuration mode



Enter installer and master codes:

X **iiiiii** **mmmmmm** **#**

Value: **iiiiii** - 6-digit installer code; **mmmmmm** - 6-digit master code.

Example: **X147000111111#**



Deactivate Configuration mode



Enter installer code:

X **iiiiii** **#**

Value: **iiiiii** - 6-digit installer code.

Example: **X147000#**

The following table provides a list of EKB3/EKB3W/EWK4 indications, which are relevant during Configuration mode.

Indication	Description
Indicator flashing	Configuration mode activated successfully.
Indicator flashing	Valid parameter entered and awaiting for valid value to be entered.
1 long beep	Non-existing command or invalid parameter value entered.
3 short beeps	Command entered successfully.

NOTE: The default installer code is 1470, while the default master code is 1111. By activating 6-digit password/code format, it will be necessary to extend the installer code, master code and user code by adding 2 extra digits using *Eldes Utility*.

NOTE: The system can be configured using only one keypad at a time. Other connected keypads will be inactive while the Configuration mode is activated.

5.4. Eldes Utility



Eldes Utility is intended for ESIM484 alarm system configuration locally via USB port or remotely via 2G/4G network or Ethernet connection (ELAN3-ALARM device required). This software simplifies system configuration process by allowing to use a personal computer in the process. Whilst using *Eldes Utility* software for the first time, please pay attention that every function and option in every section provided with an individual explanation, called Hint (put mouse cursor on the "i" icon).

5.4.1. Remote Connection

ATTENTION: The system will NOT transmit any data to monitoring station while configuring the system remotely via 2G/4G network or Ethernet connection. However, during the remote connection session, the data messages are queued up and transmitted to the monitoring station after the configuration session is over.

ATTENTION: When the Configuration mode is activated by EKB3/EKB3W/EWK4 keypad or when menu section CONFIGURATION is opened by the installer using EKB2 keypad, remote system configuration is disabled.

ATTENTION: The keypad (-s) become inactive while the system is being configured remotely.

Eldes Utility provides remote system configuration ability via Internet using one of the following methods:

- ELDES proxy server (recommended). The connection can be established on the system via 2G/4G network or Ethernet using ELAN3-ALARM communicator.

- Running TCP/IP server on *Eldes Utility* (advanced). The connection can be established on the system via 2G/4G network or Ethernet using ELAN3-ALARM communicator.
- Direct connection via Ethernet using ELAN3-ALARM communicator.

In order to start using the remote configuration feature, please run the step-by-step wizard and follow the steps provided in the start page of *Eldes Utility*. Please, note that based on the selected method, it might be necessary to send an SMS text message to the system's phone number in order to initiate the remote connection. By following the steps you will be instructed on what text must be sent to the system's phone number in such case.

Start the connection with server

SMS

SMS text message content:
`ssss STCONFIG`
Value: ssss - 4-digit SMS password.
Example: 1111 STCONFIG

5.4.2. Ending the Remote Connection Session

After the remote system configuration is complete, use one of the following methods to end the configuration process:

- Click **Disconnect** or **Stop** button and close *Eldes Utility*.
- The session will automatically expire in 20 minutes. Before the last 5 minutes, the software will offer the user to extend the session for another 20 minutes.
- Alternatively, the connection with the server can be terminated at any time by sending an SMS text message.

Terminate the connection with server

SMS

SMS text message content:
`ssss ENDCONFIG`
Value: ssss - 4-digit SMS password.
Example: 1111 ENDCONFIG

Once the session is expired or terminated, the system will reply with an SMS text message confirming the end of the session.

5.5. System configuration by USB cable

In order to configure the system by USB cable, the user must plug the specified cable into personal computer's USB port and launch the pre-installed *Eldes Utility*. Configuration by USB cable and *Eldes Utility* does not require the external power supply to be connected to the device. However, the device will NOT fully function when USB-powered .The user will be able to carry out some major part of system's configuration, with the exception of those functions, which are strictly related to 2G/4G modem (disabled during the selected configuration period) or associated with the Wireless connectivity (also disabled).

6.SMS PASSWORD AND INSTALLER CODE

For security reasons, the system uses the following type of password and code:
SMS password - 4-digit password used for system arming/disarming and configuration by SMS text messages. By default, SMS password is **0000**, which **MUST** be changed!. SMS password is authorized to carry out the following:

- Access system configuration by SMS text messages.
- Arm/disarm partition.
- Activate/deactivate service mode.
- Set system date and time.
- Add/remove user phone numbers.
- Set SMS password.
- Turn ON/OFF PGM outputs.
- Restart system remotely.

Installer code - 4-digit password used for system configuration by EKB2/EKB3/EKB3W/EWKB4 keypad and *Eldes Utility*. By default, installer code is **1470**, which is highly recommended to change. Installer code is authorized to carry out the following:

- Access system configuration by keypad and *Eldes Utility*.
- Set installer code.
- Set master code.
- Activate/deactivate service mode.
- Set system date and time.
- Add/remove user phone numbers.
- Set SMS password.
- Restore system configuration to default.
- Clear tamper fault (if enabled).

Set SMS password

SMS

SMS text message content:
www PSW ssss
Value: www - 4-digit existing SMS password; ssss - 4-digit new SMS password; range - [0001... 9999].
Example: 0000 PSW 1111

EKB2

Menu path:
OK → iiiii → OK → PRIMARY SETTINGS → OK → SMS PASSWORD → OK → ssss → OK
Value: iiiii - 4-digit installer code; ssss - 4-digit new SMS password; range - [0001... 9999].

EKB3/
EKB3W/
EWKB4

Enter parameter 14 and new SMS password:
14 ssss #
Value: ssss - 4-digit new SMS password; range - [0001... 9999].
Example: 141111#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Set installer code

EKB2

Menu path:
OK → 1470 → OK → PRIMARY SETTINGS → OK → INSTALLER CODE → OK → iiiii → OK
Value: iiiii - 4-digit new installer code; range - [0000... 9999].

EKB3/
EKB3W/
EWKB4

Enter parameter 16 and new installer code:
16 iiiii #
Value: iiiii - 4-digit new installer code; range - [0000... 9999].
Example: 162538#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

7. SYSTEM LANGUAGE

The system comes equipped with a single language for communication with the user by SMS text messages and EKB2 keypad menu display. The system language depends on ESIM484 firmware, which is based on the user's location.

List of currently available system languages (firmwares):

- Czech
- English
- Estonian
- Finnish
- French
- German
- Greek
- Hungarian
- Italian
- Latvian
- Lithuanian
- Polish
- Portuguese
- Romanian
- Russian
- Slovak
- Icelandic *
- Danish
- Slovenian
- Dutch
- Macedonian
- Spanish

* - supports SMS text messages only.

NOTE: To obtain a firmware that features a different SMS and EKB2 menu language, please contact your local dealer.

8.USER PHONE NUMBERS

The system supports up to 10 user phone numbers identified as User 1 through 10. When the phone number is set, the user will be able to arm/disarm the system by SMS text messages and free of charge phone calls (see 12.1. Free of Charge Phone Call and 12.2. SMS Text Message) as well as to configure the system by SMS text messages. User phone numbers are also used to receive alarm phone calls via 2G/4G connection and SMS text messages from the system (see 17. ALARM INDICATIONS AND NOTIFICATIONS FOR USER).

By default, the system accepts incoming calls and SMS text messages from any phone number. Once a user phone number is listed, the system ignores any incoming calls and SMS text messages from a non-listed phone number as well as it rejects the SMS text messages containing wrong SMS password even from a listed user phone number (see 8.2. Initiate system's remote connection from any phone number).

To set User 1 phone number is mandatory, while the other 9 are optional. The supported phone number formats are the following:

- International (with plus)** - The phone numbers must be entered starting with plus and an international country code in the following format: +[international code][area code][local number], example for UK: +44170911XXXX1. This format can be used when setting up the phone number by SMS text message and Eldes Utility.
- International (with 00)** - The phone numbers must be entered starting with 00 and an international country code in the following format: 00[international code][area code][local number], example for UK: 0044170911XXXX1. This format can be used when setting up the phone number by SMS text message, EKB2/EKB3/EKB3W/EWKB4 keypad and Eldes Utility.
- Local** - The phone numbers must be entered starting with an area code in the following format: [area code][local number], example for UK: 0170911XXXX1. This format can be used when setting up the phone number by SMS text message, EKB2/ EKB3/EKB3W/ EWKB4 keypad and Eldes Utility.

Add user phone number

SMS

SMS text message content:
ssss NRup:ttteeellnnumm

Value: ssss - 4-digit SMS password; up - user phone number slot, range - [1... 10]; ttteeellnnumm - up to 15 digits user phone number.
Example: 1111 NR1:+44170911XXXX1

EKB2

Menu path:
OK → iiiii → OK → PRIMARY SETTINGS → OK → CALL/SMS SETTINGS → OK → USERS → OK → 2G/4G USER 1... 10 → OK → PHONE NUMBER → OK → ttteeellnnumm → OK

Value: iiiii - 4-digit installer code; ttteeellnnumm - up to 15 digits user phone number.

EKB3/
EKB3W/
EWKB4

Enter parameter 17, user phone number slot and phone number:
17 up ttteeellnnumm #

Value: up - user phone number slot, range - [01... 10]; ttteeellnnumm - up to 15 digits user phone number.
Example: 17010044170911XXXX1#

Eldes Utility

This operation may be carried out from the PC using the Eldes Utility.

View user phone number

SMS

SMS text message content:
ssss HELPNR

Value: ssss - 4-digit SMS password.
Example: 1111 HELPNR

EKB2

Menu path:
OK → iiiii → OK → PRIMARY SETTINGS → OK → CALL/SMS SETTINGS → OK → USERS → OK → 2G/4G USER 1... 10 → OK → PHONE NUMBER

Value: iiiii - 4-digit installer code;

Eldes Utility

This operation may be carried out from the PC using the Eldes Utility.

Delete user phone number

SMS

SMS text message content:

ssss NRup:DEL

Value: ssss - 4-digit SMS password; up - user phone number slot, range - [2... 10].

Example: 1111 NR2:DEL

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETTINGS → OK → CALL/SMS SETTINGS → OK → USERS → OK → 2G/4G USER 2... 10 → OK → PHONE NUMBER → OK → OK

Value: **iiii** - 4-digit installer code;

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: NEVER add a phone number of the device's SIM card as a user phone number!

ATTENTION: Once User 1 phone number is set, it will be restricted to modify it only.

NOTE: Multiple user phone numbers can be set by a single SMS text message,

Example: 1111 NR1:+44170911XXXX1 NR2:+44170911XXXX2 NR6:0170911XXXX3 NR10:+44170911XXXX4

NOTE: Multiple user phone numbers can be deleted by a single SMS text message, **Example:** 1111 NR2:DEL NR3:DEL NR6:DEL NR9:DEL NR10:DEL

8.1. User Phone Number Names

When the system is armed or disarmed by free of charge phone call or SMS text message, the system sends a confirmation by SMS text message to user phone number that the system arming/disarming was initiated from. The SMS text message is sent regarding each partition separately and contains system status and partition name as well as it may contain a user name, set to the user phone number.

Manage user phone number name

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

8.2. Initiate system's remote connection from any phone number

By default, system allows to initiate remote connection (5.4.1. Remote Connection) only from listed user phone numbers. To permit system's remote connection initiation from any phone number, please refer to the following configuration methods.

Initiate system's remote connection from any phone number

SMS

SMS text message content:

ssss STR:ON

Value: ssss - 4-digit SMS password.

Example: 1111 STR:ON

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETTINGS → OK → CALL/SMS SETTINGS → OK → CTRL FROM ANY NUM → OK → ENABLE → OK

Value: **iiii** - 4-digit installer code;

**EKB3/
EKB3W/
EKB4**

Enter parameter 12 and parameter status value:

121 #

Example: 121#

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: Users, who initiate system's remote connection from non-listed phone numbers, **WON'T BE ABLE** to control the system (i.e. arm or disarm it).

Forbid system's remote connection from any phone number

SMS

SMS text message content:

ssss STR:OFF

Value: ssss - 4-digit SMS password.

Example: 1111 STR:OFF

EKB2

Menu path:

OK → iiiii → OK → PRIMARY SETTINGS → OK → CALL/SMS SETTINGS → OK → CTRL FROM ANY NUM → OK → DISABLE → OK

Value: iiiii - 4-digit installer code;

**EKB3/
EKB3W/
EWKB4**

Enter parameter 12 and parameter status value:

120 #

Example: 120#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

9. DATE AND TIME

The system comes equipped with internal real-time clock (RTC) that keeps track of the current date and time. Once the system is up and running, the user must set the correct date and time, otherwise the system will not operate properly. By default, after shutting down and starting up the system, the date and time must be set again.

Set date and time

SMS

SMS text message content:

ssss yyyy.mt.dd hr:mn

Value: ssss - 4-digit SMS password; yyyy - year; mt - month, range - [01... 12]; dd - day, range - [01... 31]; hr - hours, range - [00... 23]; mn - minutes, range - [00... 59].

Example: 1111 2014.03.16 14:33

EKB2

Menu path:

a) OK → uumm → OK → DATE/TIME SETTINGS → OK → yyyy-mt-dd hr:mn → OK

b) OK → iiiii → OK → PRIMARY SETTINGS → OK → DATE/TIME SETTINGS → OK → yyyy-mt-dd hr:mn → OK

Value: uumm - 4-digit user/master code; yyyy - year; mt - month, range - [01... 12]; dd - day, range - [01... 31]; hr - hours, range - [00... 23]; mn - minutes, range - [00... 59]; iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter installer code to get into Configuration Mode first (see section 5.3 EKB3/EKB3W/EWKB4 LED Keypad on page 30 to know how it is done).

When in Configuration Mode, enter parameter 66, date and time:

66 yyyy mt dd hr mn #

Value: yyyy - year; mt - month, range - [01... 12]; dd - day, range - [01... 31]; hr - hours, range - [00... 23]; mn - minutes, range - [00... 59].

Example: 66201405291235#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION! To set date and time using EKB3/EKB3W/EWKB4 command, described above, you MUST enter the Configuration mode first!

Eldes Utility provides the ability to select the Time Zone option. The user may also choose Get PC Time option, which instantly provides the exact PC time.

NOTE: When the system is connected to the monitoring station via IP connection (see **30. MONITORING STATION**) and/or when ELDES Cloud Services feature is in use (see **36. ELDES CLOUD SERVICES**), the date and time will be automatically synchronized with the monitoring station or ELDES Cloud Services server upon the system startup. However, SIA IP data format users must enable time synchronization feature using *Eldes Utility*.

9.1. Time Synchronization

In order for the system to work correctly, its time has to be synchronized. For this to happen, user must enable **Time Synchronization** feature. This function may be enabled using Eldes Utility (the menu path for the setting is:

System -> Device settings -> Time Synchronization-> Enable). By default, this function is enabled. User may completely disable Time Synchronization feature, using Eldes Utility software or sending the following SMS command:

Set Time Synchronization from CMS (ARC)

SMS

SMS text message content:

ssss TIMESYNC:OFF

Value: ssss - 4-digit SMS password.

Example: 1111 TIMESYNC:OFF

If Time Synchronization feature is completely disabled, time may be set only manually via Eldes Utility, either by entering a command using EKB3W/EWKB4 keypad or by sending *Set Time* command via EGR100 software.

NOTE: SET TIME sync period may **NOT** be set via SMS.

Automatic Time Synchronization - this feature allows the system to set and synchronize date and time automatically, without the user being involved in this process. By default, this feature is enabled. In case it is disabled, user may enable this feature using *Eldes Utility* software or sending the following SMS command:

Enable Automatic Time Synchronization

SMS

SMS text message content:

ssss TIMESYNC:AUTO

Value: ssss - 4-digit SMS password.

Example: 1111 TIMESYNC:AUTO

If Automatic Time Synchronization feature is disabled, you may choose another option instead: **Time Synchronization from CMS (ARC)**. This way, the device synchronizes its time with Monitoring Station's (CMS) time. Now, for this to work, first step is to enable CMS (ARC) mode beforehand and to set *Primary communication* channel as IP server #1...3. User may enable this feature using *Eldes Utility* software or sending the following SMS command:

Set Time Synchronization from CMS (ARC)

SMS

SMS text message content:

ssss TIMESYNC:CMS

Value: ssss - 4-digit SMS password.

Example: 1111 TIMESYNC:CMS

NOTE: In case when wrong sms password or wrong sms syntax is entered in the text message, the user will get a respective response: "wrong password" or "wrong syntax".

ATTENTION! If an SMS command is written correctly and the system activates it, then the user will get one of the following responses: "timesync:off ok", "timesync:auto ok" or "timesync:cms ok". If, due to certain faults, the SMS command is rejected, then the system will inform the user with one of the following responses: "timesync:off ok", "timesync:auto ok" or "timesync:cms ok".

Another notable thing - user has to enter the correct Server IP address (which is not set by default). When these steps are completed, user has to choose the preferred protocol in Protocols settings.

Time Synchronization from CMS (ARC) function has several options, which user may choose from the drop-down list, located in CMS (ARC) section (the menu path for the setting is: *CMS (ARC)* -> *Communications* -> *Communication Settings* -> *Protocol*):

- SIA IP Protocol;
- EGR100 IP Protocol;
- Kronos IP Protocol.

When Time Synchronization from CMS (ARC) function is selected, SIA IP protocol is being used at first (set by default). Time Synchronization from CMS (ARC) feature has an additional option named **Synchronization Frequency**, which allows user to set a preferred time synchronization frequency.

Default time frequency value is **1 day**; value range is from 1 to 30 days; the frequency countdown begins from the moment when new settings are saved. This additional Synchronization Frequency option is eligible only for 2 protocols, - EGR100 IP Protocol and Kronos IP Protocol.

The aforementioned additional option is unavailable when SIA IP protocol is set. In such case, the synchronization process will be continuous, if the device time and SIA IP server time do not match for longer than the Set time period (the default value of which is 5 minutes).

When Time Synchronization from CMS (ARC) is disabled, this feature is instantly substituted by the other option - Automatic Time Synchronization (which was set at first).

Time Synchronization from Loop SMS - system time will be synchronized by sending SMS text message to itself. In this case, the phone number of the SIM card must be provided. By default, this feature is disabled.

10. MASTER AND USER CODES

NOTE for EKB3/EKB3W/EWKB4: The Configuration mode must remain deactivated before accessing master and user code management using the master code.

The system supports up to 30 numeric codes, identified as Master code and User code 2 through 30, allowing to carry out system arming/disarming as well as minor system configuration and control by the keypad.

Master code is authorized to carry out the following:

- Arm/disarm partition.
- Bypass violated zones.
- View violated zones and tampers.
- View system faults.
- Set system date and time.
- View temperature sensor information.
- View event log,
- View and clear alarm log,
- Set/delete user codes.
- Turn ON/OFF PGM outputs.
- Assign an existing user code as Duress code.
- Assign an existing user code as SGS code.

User code is authorized to carry out the following:

- Arm/disarm partition.
- Bypass violated zones.
- View violated zones and tampers.
- View system faults.
- Set system date and time.
- View temperature sensor information.
- View and clear alarm log.

By default, only Master code is listed as **1111** and assigned Partition 1 **ONLY**. For more details regarding User/Master code partition, please refer to **23.4. User/Master Code Partition**.

Set master code

EKB2

Menu path:

a) `OK → vvvv → OK → CODES → OK → MASTER CODE → OK → CODE → OK → mmmm → OK`

b) `OK → iiiii → OK → PRIMARY SETTINGS → OK → MASTER CODE → mmmm → OK`

Value: vvvv - 4-digit existing master code, range - [0000... 9999]; iiiii - 4-digit installer code; mmmm - 4-digit new master code, range - [0000... 9999].

EKB3/
EKB3W/
EWKB4

a) Press ... 0, enter existing master code and new master code:

`...0 vvvv 01 mmmm # mm #`

Value: vvvv - 4-digit existing master code; mmmm - 4-digit new master code; range - [0000... 9999].

Example: ...01111012222#

b) (Only when Configuration Mode is activated):

Enter parameter 63, existing master code and new master code:

`63 vvvv mmmm #`

Value: vvvv - 4-digit existing master code; mmmm - 4-digit new master code, range - [0000... 9999].

Example: 6311112222#

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

38EN

ESIM484 Installation and Configuration Manual v1.1

Set user code

EKB2

Menu path:

User code 2... 16: OK → mmmm → OK → CODES → OK → USER CODE (2-16) → OK → USER CODE 2... 16 → OK → CODE → OK → uuuu → OK

User code 17... 30: OK → mmmm → OK → CODES → OK → USER CODE (17-30) → OK → USER CODE 17... 30 → OK → CODE → OK → uuuu → OK

Value: mmmm - 4-digit master code; uuuu - 4-digit user code, range - [0000... 9999].

**EKB3/
EKB3W/
EWKB4**

Press ..., 0, enter master code, user code slot and user code:

...0 mmmm us uuuu #

Value: mmmm - 4-digit master code; us - user code slot, range - [02... 30]; uuuu - 4-digit user code, range - [0000... 9999].

Example: ...01111092556#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Delete user code

EKB2

Menu path:

OK → mmmm → OK → CODES → OK → REMOVE CODE → OK → uuuu → OK

Value: mmmm - 4-digit master code; uuuu - 4-digit user code.

**EKB3/
EKB3W/
EWKB4**

Press ..., 0, enter master code and user code slot:

...0 mmmm us #

Value: mmmm - 4-digit master code; us - user code slot, range - [02... 30].

Example: ...0111109#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: The system does not allow to set a duplicate code.

The user codes ranging from User code 2 through 10 can be set as SGS (Security Guard Service) code, which is used as a checkpoint by a security service guard upon his/her visit in the secured location. When used, a data message, containing a certain event code, will be delivered to the monitoring station. However, NO system arming or disarming will be carried out after entering the SGS code.

Set SGS code

EKB2

Menu path:

OK → mmmm → OK → CODES → OK → SGS CODE → OK → N/A | USER CODE 2... 10 → OK

Value: mmmm - 4-digit master code; N/A - SGS code not in use.

**EKB3/
EKB3W/
EWKB4**

Press ..., 4, enter user code slot and enter master code:

...4 us mmmm #

Value: us - user code slot, range - [02... 10]; mmmm - 4-digit master code.

Example: ...4041111#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

The Duress code is used when system arming or disarming is demanded by force. When used, the system will arm/disarm as well as it will silently transmit an alert to the monitoring station. Only one of the user codes ranging from User code 2 through 10 can be set as Duress code.

Set Duress code

EKB2

Menu path:

OK → mmmm → OK → CODES → OK → DURESS CODE → OK → N/A | USER CODE 2... 10 → OK

Value: mmmm - 4-digit master code; N/A - Duress code not in use.

**EKB3/
EKB3W/
EWKB4**

Press ..., 3, enter user code slot and master code:

...3 us mmmm #

Value: us - user code slot, range - [02... 10]; mmmm - 4-digit master code.

Example: ...3081111#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

10.1. Master and User Code Names

When the system is armed or disarmed by entering a master or user code using a keypad, the system sends a confirmation by SMS text message to user phone number, sharing the same partition (-s) as the keypad and user/master code. The SMS text message is sent regarding each partition separately and contains system status and partition name as well as it may contain a user name, set to the user/master code.

Manage user/master code name

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

11. IBUTTON KEYS


An iButton key is a unique 64-bit ID code containing chip enclosed in a stainless steel tab usually implemented in a small plastic holder. ESIM484 system supports up to 16 iButton keys each holding a unique identity code (ID), which is used for system arming and disarming.

11.1. Adding and Removing iButton Keys

NOTE: iButton Key 1 can be added without Allow Adding New iButton Keys mode being enabled.

To add an iButton key to the system, do the following:

- a) Disarm the system in all partitions (see 12. ARMING AND DISARMING).
- b) Enable Allow Adding New iButton Keys mode.
- c) Touch the key to the iButton key reader when the system is disarmed.



- d) The successfully added iButton key will be indicated by short beeps emitted by the system's buzzer.
- e) Add as many iButton keys as necessary - touch one key after another to the reader - until the number of 16 keys is reached.

Enable Allow Adding New iButton Keys mode

SMS	<p>SMS text message content: ssssIBPROG:ON Value: ssss - 4-digit SMS password. Example: 1111 IBPROG:ON</p>
EKB2	<p>Menu path: OK → iii → OK → IBUTTON KEYS → OK → NEW IBUTTON → OK → ENABLE → OK Value: iii - 4-digit installer code.</p>
EKB3/ EKB3w/ EWKB4	<p>Enter parameter 18 and parameter status value: 18 0 # Example: 180#</p>
Eldes Utility	<p>This operation may be carried out from the PC using the <i>Eldes Utility</i>.</p>

When adding of iButton keys is complete, please disable Allow Adding New iButton Keys mode.

Disable Allow Adding New iButton Keys mode

SMS

SMS text message content:

`ssss IBPROG:OFF`

Value: ssss - 4-digit SMS password.

Example: 1111 IBPROG:OFF

EKB2

Menu path:

OK → `iiii` → OK → IBUTTON KEYS → OK → NEW IBUTTON → OK → DISABLE → OK

Value: `iiii` - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 18 and parameter status value:

`18 1 #`

Example: 181#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

To view the ID of the added iButton keys, please refer to the following configuration methods.

View iButton key ID

EKB2

Menu path:

OK → `iiii` → OK → IBUTTON KEYS → OK → IBUTTON → OK → IBUTTON 1...16 → OK → ID

Value: `iiii` - 4-digit installer code.

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

If the iButton key is lost or stolen, due to security reasons it is highly recommended to remove it from the system.

Remove individual iButton key from the system

EKB2

Menu path:

OK → `iiii` → OK → IBUTTON KEYS → OK → IBUTTON → OK → IBUTTON 1...16 → OK → REMOVE → OK

Value: `iiii` - 4-digit installer code.

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Remove all iButton keys from the system

SMS

SMS text message content:

`ssss RESETIB`

Value: ssss - 4-digit SMS password.

Example: 1111 RESETIB

11.2. iButton Key Names

When the system is armed or disarmed by iButton key, the system sends a confirmation by SMS text message to listed user phone number, sharing the same partition (-s) as the key. The SMS text message is sent regarding each partition separately and contains system status and partition name as well as it may contain a user name, set to the iButton key.

Manage iButton key name

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

12. ARMING AND DISARMING

The system supports the following arming and disarming methods:

- By free of charge phone call
- By SMS text message
- By entering user/master code on EKB2/EKB3/EKB3W/EWKB4 keypad or EKB6 touchpad
- Using iButton key
- Using wireless key fobs KeyBoB and EWK2 or panic button EWK2A (selecting either arming or disarming function)
- Arm-Disarm by Zone
- EGR100 middle-ware
- Automatic arm/disarm by schedule
- ELDES Cloud Services platform

The system partitions can be armed/disarmed by the listed user phone number, EKB2/EKB3/EKB3W/EWKB4 keypad and user/master code, iButton key, EWK2/EWK2A wireless key fob, automatically according to the scheduled weekday and time or zone, which is set up for Arm-Disarm by Zone method. For example, if User 1 phone number is assigned to Partition 1, 2 and 4, the user will be able to arm/disarm Partition 1, 2 and 4 by a single phone call to the system (see **23. PARTITIONS**).

By default, when the system is successfully armed or disarmed, it replies with confirmation by SMS text message. For more details on SMS text message regarding system arming/disarming and how to manage it, please refer to **12.10. Disabling and Enabling Arm/Disarm Notifications**.

By default, it is allowed to arm the system while the following system faults are present (see **29. INDICATION OF SYSTEM FAULTS**):

- Mains power is lost.
- Low battery.
- Battery dead or missing.
- Battery failed.
- Siren failed.
- Date/time not set.
- 2G/4G connection failed.
- 2G/4G antenna failed.
- Wireless antenna failed.
- Keypad lost.
- Wireless power socket (EWM1) fault.
- Wireless device battery low.
- Communication to MS failed.
- RF jammer detected.

In case of violated zone/tamper presence when attempting to arm the system by free of charge phone call, SMS text message, iButton key and Arm-Disarm by Zone method, the system will reply with SMS text message containing violated zone/tamper number. Due to security reasons it is highly recommended to restore the violated zone/tamper before arming the system. For more details on how to arm the system regardless of the violated zone or tamper presence, please refer to **14.6. Zone Attributes**, **14.7. Bypassing and Activating Zones** and **16. TAMPERS** respectively.

The system ignores any incoming calls and SMS text messages from a non-listed phone number as well as it rejects the SMS text messages containing wrong SMS password even from a listed user phone number.

NOTE: The system remembers the last status (armed/disarmed) of all partitions even after complete shut down.

12.1. Free of Charge Phone Call



To arm, disarm the system and turn OFF the alarm, dial the system's phone number from any of 10 available user phone numbers (see **8. USER PHONE NUMBERS** for user phone number management). The phone call is free charge as the system rejects it and carries out arming/disarming procedure afterwards. When arming - the system rejects the phone call after 2 rings, when disarming - the system rejects the phone call immediately. If there is more than one listed user dialling to the system at the same time, the system will accept the incoming call from the user who was the first to dial while other user (-s) will be ignored.

When system's phone number is dialled for arming, the system will proceed as follows:


- **Non-partitioned system:**

- If ready (no violated zone/tamper), the system will arm.
- If unready (violated zone/tamper is present), the system will not arm and provide a list of violated zones/tampers by SMS text message to user phone number. In such case the user must restore all violated zones and tampers before arming the system. Alternatively, the violated zones can be bypassed (see **14.7. Bypassing and Activating Zones**), disabled (see **14.9. Disabling and Enabling Zones**) or a Force attribute enabled (resulting in partial arm; see **14.6. Zone Attributes**), while the tampers can be disabled (see **16. TAMPERS**).

- **Partitioned system:**

- If all partitions are disarmed ready, the system will arm them.
- If one or more partitions are disarmed unready (violated zone/tamper is present), the system will arm the ready partition (-s) and skip the unready one (-s). The system will then send an SMS text message, containing a list of violated zones/tampers, to user phone number that the system arming was initiated from.
- If a combination of armed and disarmed ready partitions is present, the system will arm the disarmed ready partitions and skip the armed ones.

When a user phone number is assigned to multiple partitions, the user will be able arm/disarm the corresponding system partitions by dialling the system's phone number. For example, if User 1 is assigned to Partition 1, 2 and 3, the user will be able to arm/disarm Partition 1, 2 and 3 by a single phone call to the system from User 1 phone number. For more details on how to set user phone number partition, please refer to **23.2. User Phone Number Partition**.



By default, all listed user phone numbers are granted with permission to arm and disarm the system by free of charge phone call and SMS text message. To disable/enable arming or disarming for certain listed user phone numbers, please refer to the following configuration method.

Manage arming and
disarming for listed
user phone numbers

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

12.2. SMS Text Message

SMS

To arm the system by SMS text message, send the following text to the system's phone number from any of 10 available user phone numbers (see **8. USER PHONE NUMBERS** for user phone number management).


Arm the system

SMS text message content:

ssss ARMp or ssss ARMp,p,p

Value: ssss - 4-digit SMS password; p - partition number, range - [1... 4].

Example: 1111 ARM1



When the SMS text message for arming is sent to the system's phone number, the system will proceed as follows:

- **Non-partitioned system:**
 - If ready (no violated zone/tamper), the system will arm.
 - If unready, the system will not arm and provide a list of violated zones/tampers by SMS text message to user phone number. In such case the user must restore all violated zones and tampers before arming the system. Alternatively, the violated zones can be bypassed (see **14.7. Bypassing and Activating Zones**), disabled (see **14.9. Disabling and Enabling Zones**) or a Force attribute enabled (resulting in partial arm; see **14.6. Zone Attributes**), while the tampers can be disabled (see **16. TAMPERS**).
- **Partitioned system:**
 - If all partitions are disarmed ready (no violated zone/tamper), the system will arm them.
 - If one or more partitions are disarmed unready (violated zone/tamper is present), the system will arm the ready partition (-s) and skip the unready one (-s). The system will then send an SMS text message, containing a list of violated zones/tampers, to user phone number that the system arming was initiated from.
 - If a combination of armed and disarmed ready partitions is present, the system will arm the disarmed ready partitions and skip the armed ones.

To disarm the system and turn OFF the alarm by SMS text message, send the following text to the system's phone number from any of 10 available user phone numbers:

Disarm the system and turn OFF the alarm

SMS text message content:

ssss DISARMp or ssss DISARMp,p,p

Value: ssss - 4-digit SMS password; p - partition number, range - [1... 4].

Example: 1111 DISARM1,2,4



When a user phone number is assigned to multiple partitions, the user will be able arm/disarm the corresponding system partitions by sending the SMS text message to the system's phone number. For example, if User 3 is assigned to Partition 2 and 3, the user will be able to arm/disarm Partition 2 and/or 3 by sending an SMS text message from User 3 phone number. For more details on how to set user phone number partition, please refer to **23.2. User Phone Number Partition**.

By default, all listed user phone numbers are granted with permission to arm and disarm the system by free of charge phone call and SMS text message. To disable/enable arming or disarming for certain listed user phone numbers, please refer to the following configuration method.

Manage arming and disarming for listed user phone numbers

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

12.3. EKB2 Keypad and User/Master Code

✓ icon displayed next to the partition name in the home screen view of EKB2 keypad indicates that no violated zones and/or tampers are present, therefore the partition is ready for arming. If X icon is displayed instead, the partition is unready for arming, therefore the user must restore all violated zones and/or tampers before arming the partition. Alternatively, the violated zones can be bypassed (see **14.7. Bypassing and Activating Zones**), disabled (see **14.9. Disabling and Enabling Zones**) or a Force attribute enabled (resulting in partial arm; see **14.6. Zone Attributes**), while the tampers can be disabled (see **16. TAMPERS**). 🚫 icon appears in the home screen view if system fault (-s) exist (see **29. INDICATION OF SYSTEM FAULTS**).

When a user/master code is assigned to multiple partitions, the user will be able arm/disarm the corresponding system partitions by EKB2 keypad using partition selection menu. However, if a user/master code is assigned to Partition 1, 2 and 4, while EKB2 keypad is assigned to Partition 2, the user will be able to arm/disarm Partition 1, 2 and 4, but the keypad will only display Partition 2 name and the related information in home screen view. For more details on how to set keypad partition and user/master code partition, please refer to **23.3. Keypad Partition and Keypad Partition Switch** and **23.4. User/ Master Code Partition** respectively.

12.3.1. Arming the System

To arm the system by EKB2 keypad, enter any out of 29 available 4-digit user codes or master code using the number keys on the keypad (see **10. MASTER AND USER CODES** for user/master code management). By default, the arming process is as follows:


- **Non-partitioned system** - When a valid user code is entered, the system will initiate exit delay, the keypad's buzzer will emit short beeps, the keypad will switch to home screen view and display the countdown timer.

Arm the system

Enter user/master code:

uumm → OK

Value: uumm - 4-digit user/master code.

- **Partitioned system - arming a single partition** - When a valid user or master code is entered, the keypad will display the partition selection menu. Once a partition that is to be armed is selected, the system will initiate exit delay. During the exit delay, the keypad's buzzer will emit short beeps and the keypad will display **ARMING part-name** message for 3 seconds followed by partition selection menu. When the keypad back-light timeout expires, the home screen view will follow. If  key is touched twice during exit delay, the keypad will return to home screen view and display the countdown timer next to the partition name that is being armed.


Arm the system

Enter user/master code and select partition:

uumm → OK → [p] part-name → OK or OK → uumm → OK → ARM/DIS PARTITION → OK → [p] part-name → OK

Value: uumm - 4-digit user/master code; p - partition number, range - [1... 4], part-name - up to 15 characters partition name

- **Partitioned system - arming multiple partitions simultaneously** - When a valid user or master code is entered, the keypad will display the partition selection menu. Once **ARM ALL** menu item is selected the system will proceed as follows:
 - if all partitions are disarmed-ready (no violated zone/tamper), the system will initiate exit delay. During the exit delay, the keypad's buzzer will emit short beeps and the keypad will display multiple **ARMING part-name** messages for 3 seconds reflecting each partition the user/master code is assigned to, followed by partition selection menu.
 - if one or more partitions are disarmed unready (contains violated zone/tamper), the system will initiate exit delay. During the exit delay, the keypad's buzzer will emit short beeps and the keypad will display **ARMING part-name** message (-s) reflecting ready partition (-s), while the unready partition (-s) will be skipped indicated by **part-name NOT READY** message (-s) followed by partition selection menu. Each message will be displayed for 2 seconds and corresponds to the partition (-s) the user/master code is assigned to.
 - if a combination of armed and disarmed-ready partitions exist, the system will initiate exit delay. During the exit delay, the keypad's buzzer will emit short beeps and the keypad will display **ARMING part-name** message (-s) seconds reflecting ready partition (-s), while the pre-armed partition (-s) will be skipped. Each message will be displayed for 2 seconds and corresponds to the partition (-s) the user/master code is assigned to.

When the keypad back-light timeout expires, the home screen view will follow. If  key is touched twice during exit delay, the keypad will return to home screen view and display the countdown timers next to the partition names the keypad is assigned to.


Arm all partitions simultaneously

Enter user/master code:

uumm → OK → ARM ALL → OK or OK → uumm → OK → ARM/DIS PARTITION → OK → ARM ALL → OK

Value: uumm - 4-digit user/master code.

When successfully armed:

- the countdown timers will disappear.
- in addition, the keypad may display  icon next to the partition name that has been armed (by default - disabled).

Enable/disable Show ARMED status in keypad

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: If the user fails to enter a correct user/master code 10 times in a row, the system will block the keypad for 2 minutes and the keypad will display **KEYPAD BLOCKED** message. While the keypad is blocked, the system prevents from entering any user/master code. The keypad will automatically unblock once the 2-minute time has expired and display **KEYPAD UNBLOCKED** message

12.3.2. Cancelling System Arming

To cancel the arming process:

- **Non-partitioned system** - Enter the user/master code again during exit delay countdown.
- **Partitioned system** - Select the partition again, that is currently being armed, from the partition selection menu during exit delay countdown. The keypad will display **part-name ARMING TERMINATED** message for 2 seconds followed by partition selection menu.

12.3.3. Disarming the System and Turning OFF the Alarm

To disarm and turn OFF the alarm, enter any out of 29 available 4-digit user codes or master code using the number keys on the keypad. By default, the system disarming process is as follows:


- **Non-partitioned system** - When a valid user or master code is entered, the keypad will switch to home screen view.

Disarm the system and turn OFF the alarm

Enter user/master code:

uumm → OK

Value: uumm - 4-digit user/master code.


- **Partitioned system - disarming a single partition** - When a valid user or master code is entered, the keypad will display the partition selection menu. Once a partition that is to be disarmed is selected, the keypad will display **part-name DISARMED** message for 2 seconds and return to partition selection menu followed by home screen view after the keypad back-light timeout expires. Alternatively, the  key may be touched in order to instantly return to home screen view.

Disarm the system and turn OFF the alarm

Enter user/master code and select partition:

uumm → OK → [p] part-name → OK or OK → uumm → OK → ARM/DIS PARTITION → OK → [p] part-name → OK

Value: uumm - 4-digit user/master code; p - partition number, range - [1... 4], part-name - up to 15 characters partition name


- **Partitioned system; disarming multiple partitions simultaneously** - When a valid user or master code is entered, the keypad will display the partition selection menu. Once **DISARM ALL** menu item is selected, the keypad will display multiple **part-name DISARMED** messages for 2 seconds reflecting each partition the user/master code is assigned to and return to partition selection menu followed by home screen view after the keypad back-light timeout expires. Alternatively, the  key may be touched in order to instantly return to home screen view.

Disarm all partitions and turn OFF the alarm simultaneously

Enter user/master code:

uumm → OK → DISARM ALL → OK or OK → uumm → OK → ARM/DIS PARTITION → OK → DISARM ALL → OK

Value: uumm - 4-digit user/master code.

When successfully disarmed, the keypad may display  icon next to the partition name that has been disarmed (by default - disabled).

Enable/disable Show ARMED status in keypad




Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: If the user fails to enter a correct user/master code 10 times in a row, the system will block the keypad for 2 minutes and the keypad will display **KEYPAD BLOCKED** message. While the keypad is blocked, the system prevents from entering any user/master code. The keypad will automatically unblock once the 2-minute time has expired and display **KEYPAD UNBLOCKED** message.

12.4. EKB3 Keypad and User/Master Code


ATTENTION: EKB3 keypad can operate either in 2-partition or in 4-partition mode. The description of the following procedure is based on 4-partition mode operation on EKB3 keypad. The arming/disarming procedure in 2-partition mode using EKB3 keypad would be carried out identically to EKB3W/EWKB4 wireless keypads. For more details on 2-partition mode, please refer to **12.5. EKB3W/EWKB4 Keypads and User/Master Code**.

Illuminated indicator  on EKB3 keypad indicates that no violated zones and/or tampers are present, therefore the partition is ready for arming. If the indicator  is not illuminated, the partition is unready for arming, therefore the user must restore all violated zones and/or tampers before arming the partition. Alternatively, the violated zones can be bypassed (see **14.7. Bypassing and Activating Zones**), disabled (see **14.9. Disabling and Enabling Zones**) or a Force attribute enabled (resulting in partial arm; see **14.6. Zone Attributes**), while the tampers can be disabled (see **16. TAMPERS**). Indicator  will illuminate or flash if system fault (-s) exist (see **29. INDICATION OF SYSTEM FAULTS**).

The system will arm/disarm the partition corresponding to the one that user/master code and the keypad are assigned to. For example, if User code 4 is assigned to Partition 2, 3 and 4, while EKB3 keypad is assigned to Partition 2, the user will be able to arm/disarm only Partition 2 by entering User code 4. For more details on how to set keypad partition and user/master code partition, please refer to **23.3. Keypad Partition and Keypad Partition Switch** and **23.4. User/ Master Code Partition** respectively.

12.4.1. Arming the System

To arm the system by EKB3 keypad, enter any out of 29 available 4-digit user codes or master code using the number keys on the keypad (see **10. MASTER AND USER CODES** for user/master code management). By default, the arming process is as follows:

- **Non-partitioned system** - When a valid user/master code is entered, the system will initiate exit delay, the keypad's buzzer will emit short beeps and the indicator  along with number [1], [2], [3] and [4] keys will light ON. When the system is successfully armed, the keypad's buzzer will silent down.

Arm the system

Enter user/master code:

uumm

Value: uumm - 4-digit user/master code.


Example: 2222

- **Partitioned system - arming a single partition** - To arm a different partition than the keypad is assigned to, use keypad partition switch feature (by default - disabled; see **23.3. Keypad Partition and Keypad Partition Switch**) before the arming process.

Switch keypad partition

Hold the [1]... [4] key and release it after 3 short beeps:

Value: [1]... [4] key - partition number 1... 4 respectively.

Once the partition is switched and a valid user/master code is entered, the system will initiate exit delay, the keypad's buzzer will emit short beeps and the indicator  along with the number [1]... [4] key, indicating the partition that is to be armed, will light ON. When the system is successfully armed, the keypad's buzzer will silent down.




Arm the system

Enter user/master code:

uumm

Value: uumm - 4-digit user/master code.

Example: 2222

- **Partitioned system - arming all 4 partitions simultaneously** - If a user/master code assigned to all 4 partitions exists, user can arm all partitions simultaneously. When this feature is used, the system will proceed as follows:
 - if all partitions are disarmed-ready (no violated zone/tamper), the system will initiate exit delay. During the exit delay, the keypad's buzzer will emit short beeps and indicator  along with number [1], [2], [3] and [4] keys will light ON. When the system is successfully armed, the keypad's buzzer will silent down.
 - if one or more partitions are disarmed unready (keypad number [1]... [4] key flashing, indicating the partition that contains violated zone/tamper), the system will initiate exit delay. During the exit delay, the keypad's buzzer will emit short beeps and keypad indicator  (if the keypad is switched to a non-violated partition) along with the number [1]... [4] key, indicating the partition that is to be armed, will light ON. The ready partition (-s) will be armed and the unready one (-s) will be skipped.
 - if a combination of armed and disarmed ready partitions is present, the system will initiate exit delay. During the exit delay, the keypad's buzzer will emit short beeps and keypad indicator  (if the keypad is switched to a disarmed partition) along with the number [1]... [4] key, indicating the partition that is to be armed, will light ON. The disarmed-ready partitions will be armed and the pre-armed ones will be skipped.

Arm all 4 partitions simultaneously

Hold the [0] key, release it after 3 short beeps and enter user/ master code:

0 uumm

Value: uumm - 4-digit user/master code.

Example: 0 2222

Alternatively, the user can arm multiple partitions one by one (see **Partitioned system - arming a single partition** above).

NOTE: If the user fails to enter a correct user/master code 10 times in a row, the system will block the keypad for 2 minutes. While the keypad is blocked, the system prevents from entering any user/master code. The keypad will automatically unblock once the 2-minute time has expired/


NOTE: Before arming all 4 partitions simultaneously, the user/master code must be assigned to all 4 partitions and the keypad partition switch feature enabled (see **23.3. Keypad Partition and Keypad Partition Switch**).

12.4.2. Cancelling System Arming

To cancel the arming process, enter the user/master code again during exit delay countdown.

12.4.3. Disarming the System and Turning OFF the Alarm

To disarm and turn OFF the alarm, enter any out of 29 available 4-digit user codes or master code using the number keys on the keypad. By default, the system disarming process is as follows:

- **Non-partitioned system** - When a valid user/ master code is entered, indicator  and the number [1] key will light OFF.

Disarm the system and turn OFF the alarm

Enter user/master code:

uumm


Value: uumm - 4-digit user/master code.

Example: 2222


- **Partitioned system - disarming a single partition** - To disarm a different partition than the keypad is assigned to, use keypad partition switch feature (by default - disabled; see **23.3. Keypad Partition and Keypad Partition Switch**) before the disarming process.



Switch keypad partition

Hold the [1]... [4] key and release it after 3 short beeps:
Value: [1]... [4] key - partition number 1... 4 respectively.


Once the partition is switched and a valid user/master code is entered, indicator  and the number [1]... [4] key, indicating the partition that has been disarmed, will light OFF.

Disarm the system and turn OFF the alarm

Enter user/master code:
Value:  - 4-digit user/master code.
Example: 2222

- **Partitioned system - disarming all 4 partitions simultaneously** - If a user/master code assigned to all 4 partitions exists, user can disarm and turn OFF the alarm in all partitions simultaneously. When this feature is used, the system will proceed as follows:
 - if all partitions are armed and a valid user/master code is entered, indicator  along with the number [1], [2], [3] and [4] keys will light OFF.
 - if one or more partitions are disarmed unready (keypad number [1]... [4] key flashing, indicating the partition that contains violated zone/tamper), the system will deny simultaneous partition disarming until the partition's zone/tamper violation is removed.
 - if a combination of armed and disarmed ready partitions is present, the system will initiate exit delay. During the exit delay, the keypad's buzzer will emit short beeps and keypad indicator  (if the keypad is switched to a disarmed partition) along with the number [1]... [4] key, indicating the partition that is to be armed, will light ON. The disarmed-ready partitions will be armed and the pre-armed ones will be skipped. In order to disarm all 4 partitions simultaneously, the user must repeat the following command:

Disarm and turn OFF the alarm in all 4 partitions simultaneously

Hold the [0] key, release it after 3 short beeps and enter user/ master code:
Value:  - 4-digit user/master code.
Example: 02222




Alternatively, the user can disarm and turn OFF the alarm in multiple partitions one by one (see **Partitioned system - disarming a single partition** above).

NOTE: If the user fails to enter a correct user/master code 10 times in a row, the system will block the keypad for 2 minutes. While the keypad is blocked, the system prevents from entering any user/master code. The keypad will automatically unblock once the 2-minute time has expired.

NOTE: Before disarming all 4 partitions simultaneously, the user/master code must be assigned to all 4 partitions and the keypad partition switch feature enabled (see **23.3. Keypad Partition and Keypad Partition Switch**).


12.5. EKB3W/EWKB4 Keypads and User/Master Code

ATTENTION: The user will be able arm/disarm only the first two system partitions using EKB3W keypad. Partition 3 and Partition 4 are NOT supported by EKB3W keypad.


Illuminated indicator  on EKB3W/EWKB4 keypad indicates that no violated zones and/or tamperers are present, therefore the partition is ready for arming. If the indicator  is not illuminated, the partition is unready for arming, therefore the user must restore all violated zones and/or tamperers before arming the partition. Alternatively, the violated zones can be bypassed (see **14.7. Bypassing and Activating Zones**), disabled (see **14.9. Disabling and Enabling Zones**) or a Force attribute enabled (resulting in partial arm; see **14.6. Zone Attributes**), while the tamperers can be disabled (see **16. TAMPERS**). Indicator  will illuminate or flash if system fault (-s) exist (see **29. INDICATION OF SYSTEM FAULTS**).

The system will arm/disarm the partition corresponding to the one that user/master code and the keypad are assigned to. For example, if User code 4 is assigned to Partition 2, while EKB3W/EWKB4 keypad is assigned to Partition 1, the user will be able to arm/disarm only Partition 2 by entering User code 4. For more details on how to set keypad partition and user/master code partition, please refer to **23.3. Keypad Partition and Keypad Partition Switch** and **23.4. User/ Master Code Partition** respectively.

12.5.1. Arming the System

- **Non-partitioned system** - When a valid user/master code is entered, the system will initiate exit delay, the keypad's buzzer will emit short beeps and the indicator  will light ON. When the system is successfully armed, the keypad's buzzer will silent down.

Arm the system

Enter user/master code:
Value:  - 4-digit user/master code.
Example: 2222

- **Partitioned system - arming a single partition** - To arm a different partition than the keypad is assigned to, use keypad partition switch feature (by default - disabled; see **23.3. Keypad Partition and Keypad Partition Switch**) before the arming process.

Switch keypad partition

Hold the [1]... [2] key and release it after 3 short beeps:
Value: [1]... [2] key - partition number 1... 2 respectively.

Once the partition is switched, indicator ✓ will light ON in EKB3W/EWKB4 keypad's section A (= Partition 1) or B (= Partition 2) and a by entering a valid user/master code, the system will initiate exit delay, the keypad's buzzer will emit short beeps and the indicator ⏏ will light ON in the respective EKB3W/EWKB4 keypad's section. When the system is successfully armed, the keypad's buzzer will silent down.

Arm the system

Enter user/master code:
uumm
Value: uumm - 4-digit user/master code.
Example: 2222

To arm multiple partitions, please arm the partitions one by one by following the aforementioned procedure.

NOTE: If the user fails to enter a correct user/master code 10 times in a row, the system will block the keypad for 2 minutes. While the keypad is blocked, the system prevents from entering any user/master code. The keypad will automatically unblock once the 2-minute time has expired/

12.5.2. Cancelling System Arming

To cancel the arming process, enter the user/master code again during exit delay countdown.

12.5.3. Disarming the System and Turning OFF the Alarm

To disarm and turn OFF the alarm, enter any out of 29 available 4-digit user codes or master code using the number keys on the keypad. By default, the system disarming process is as follows:

- **Non-partitioned system** - When a valid user/ master code is entered, indicator ⏏ will light OFF.

Disarm the system and turn OFF the alarm

Enter user/master code:
uumm
Value: uumm - 4-digit user/master code.
Example: 2222

- **Partitioned system - disarming a single partition** - To disarm and turn OFF the alarm in a different partition than the keypad is assigned to, use keypad partition switch feature (by default - disabled; see **23.3. Keypad Partition and Keypad Partition Switch**) before the disarming process.

Switch keypad partition

Hold the [1]... [2] key and release it after 3 short beeps:
Value: [1]... [2] key - partition number 1... 2 respectively.

Once the partition is switched, indicator ✓ will light ON in EKB3W/EWKB4 keypad's section A (= Partition 1) or B (= Partition 2) and a by entering a valid user/master code, indicator ⏏ will light OFF.

Disarm the system and turn OFF the alarm

Enter user/master code:
uumm
Value: uumm - 4-digit user/master code.
Example: 2222

To disarm and turn OFF the alarm in multiple partitions, please disarm the partitions one by one by following the aforementioned procedure.

NOTE: If the user fails to enter a correct user/master code 10 times in a row, the system will block the keypad for 2 minutes. While the keypad is blocked, the system prevents from entering any user/master code. The keypad will automatically unblock once the 2-minute time has expired.

12.6. iButton Key




To arm or disarm the system and turn OFF the alarm, touch the iButton key reader by any of 16 available iButton keys (see **11. iBUTTON KEYS** for iButton key management). When the iButton is touched to the iButton key reader for arming, the system will proceed as follows:

Non-partitioned system:

- If ready (no violated zone/tamper), the system will initiate exit delay and arm.
- If unready, the system will not arm and provide a list of violated zones/tampers by SMS text message to user phone number. In such case the user must restore all violated zones and tampers before arming the system. Alternatively, the violated zones can be bypassed (see **14.7. Bypassing and Activating Zones**), disabled (see **14.9. Disabling and Enabling Zones**) or a Force attribute enabled (resulting in partial arm; see **14.6. Zone Attributes**), while the tampers can be disabled (see **16. TAMPERS**).

Partitioned system:

- If all partitions are disarmed ready (no violated zone/tamper), the system will initiate exit delay and arm them.
- If one or more partitions are disarmed unready (violated zone/tamper is present), the system will arm the ready partition (-s) and skip the unready one (-s).
- If a combination of armed and disarmed ready partitions is present, the system will initiate exit delay, arm the disarmed ready partitions and skip the armed ones.



When an iButton key is assigned to multiple partitions, the user will be able to arm/disarm the corresponding system partitions by touching the iButton key to the reader. For example, if iButton 5 is assigned to Partition 1 and 4, the user will be able to arm/disarm Partition 1 and 4 by touching iButton 5 to the reader. For more details on how to set iButton key partition, please refer to **23.5. iButton Key Partition**.


Overview:

EWK2/EWK2A is a wireless device intended to remotely arm and disarm ESIM484 alarm system, cause system alarm (EWK2A Panic Alarm) or to control any electric appliance connected to the alarm system's PGM output (EWK2). The maximum wireless connection range is 150m (492.13ft) (in open areas).

By default, one pair of EWK2 buttons is already configured to arm and disarm the alarm system (configurable). ELDES alarm system supports up to 16 EWK2/EWK2A devices with the same configuration (**Public** configuration) or up to 5 EWK2/EWK2A devices with custom configuration (**Private** configuration).


For more information please refer to user manual of EWK2/EWK2A device, located at eldesalarms.com

Non-partitioned system:


To arm the system, press 1 of 4 key fob buttons set to arm the system (by default, EWK 2 - ). When EWK2 button is pressed for arming, the system will proceed as follows:


- If ready (no violated zone/tamper), the system will arm.
- If unready, the system will not arm. In such case the user must restore all violated zones and tampers before arming the system. Alternatively, the violated zones can be bypassed (see **14.7. Bypassing and Activating Zones**), disabled (see **14.9. Disabling and Enabling Zones**) or a Force attribute enabled (resulting in partial arm; see **14.6. Zone Attributes**), while the tampers can be disabled (see **16. TAMPERS**).


Partitioned system:

To arm the system, press 1 of 4 key fob buttons with Partition Selection action assigned followed by a button with Arm the System action assigned (by default, EWK 2 - ). When EWK2 button is pressed for arming, the system will proceed as follows:

- If all partitions are disarmed ready (no violated zone/tamper), the system will arm them.
- If one or more partitions are disarmed unready (violated zone/tamper is present), the system will arm the ready partition (-s) and skip the unready one (-s).
- If a combination of armed and disarmed ready partitions is present, the system will arm the disarmed ready partitions and skip the armed ones.



To disarm the system, press 1 of 4 key fob buttons set to disarm the system (by default, EWK2 - ).



To verify if the system has been successfully armed, do not release the Arm the System key fob button and wait for the 3 short key fob buzzer's beeps/indicator's flashes indicating the successfully carried out command. The long beep/flash indicates the unsuccessful command.

When a certain key fob's button is assigned to multiple partitions, the user will be able to arm/disarm the corresponding system partition (-s) assigned to the button with Partition Selection action followed by a button with Arm the System/Disarm the System action. For more details on how to set the key fob partition, please refer to *Eldes Utility's* documentation.

NOTE: Single EWK2 key fob button can be configured to carry out Partition Selection and Control Output/Output Toggle/Output Pulse actions. In such case the PGM output control action will be executed with a 3-second delay once the button is pressed and in case it is not followed within a 3-second period by a button with Arm the System or Disarm the System action assigned.

12.8. Arm-Disarm by Zone

ARM/
DISARM
ZONE

The Arm-Disarm by Zone feature allows to use a zone for arming and disarming the alarm system. The process is performed by applying a low-level pulse for more than 3 seconds to the specified zone. It means that violating and restoring the zone leads to system arming and by repeating this action the system becomes disarmed. The system will arm/disarm the partition (-s) that the zone is assigned to. Up to 4 on-board zones can be set to arm/disarm up to 4 system partitions by this method.

Set zone for Arm-Disarm by Zone method

EKB2

Menu path:

OK → **iiii** → OK → ZONES → OK → ARM/DISARM BY ZONE → OK → ZONE 1... 4 → OK → **nn**

Value: **iiii** - 4-digit installer code; **nn** - on-board zone number, range - [01... 16].

EKB3/
EKB3W/
EKB4

Enter parameter 34, on-board zone slot and zone number:

34 z nn #

Value: **z** - on-board zone slot for Arm-Disarm by Zone method; range - [1... 4]; **nn** - on-board zone number, range - [01... 16].

Example: 34023#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Disable Arm-Disarm by Zone method

EKB2

Menu path:

OK → **iiii** → OK → ZONES → OK → ARM/DISARM BY ZONE → OK → ZONE 1... 4 → OK → 0

Value: **iiii** - 4-digit installer code.

EKB3/
EKB3W/
EKB4

Enter parameter 34, on-board zone slot and parameter status value:

34 z 00 #

Value: **z** - on-board zone slot for Arm-Disarm by Zone method; range - [1... 4].

Example: 34200#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

12.9. Automatic Arm/Disarm by Schedule

The system comes equipped with an automatic arm/disarm feature that operates according to the specified time and day of the week. This feature requires to set up the Action Time value of a certain schedule and assign it to Arm System/Disarm System/Arm Stay/Disarm from Stay/Disarm from any or Arm/Disarm by zone action, which is associated with a selected partition (any or all partitions).

Manage automatic arm/disarm method

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

For more details on the schedule management, please refer to **18.8.1. Automated Control by Schedule**.

12.10. Disabling and Enabling Arm/Disarm Confirmation SMS

By default, when the system is successfully armed or disarmed, it replies with confirmation by SMS text message to:

- user phone number, sharing the same partition as: EKB2/EKB3/EKB3W/EKB4 keypad and user/master code; EKB6 touchpad and user/master code; iButton key; EWB2 and KeyBoB wireless key fobs and EWB2A panic button; zone, set up for Arm/Disarm by Zone method; automated schedule.
- user phone number that the system arming/disarming by free of charge phone call was initiated from.
- user phone number that the system arming/disarming by SMS text message was initiated from.

The confirmation SMS text message is sent to the user phone number regarding each partition separately and contains system status and partition name as well as it may contain a user name assigned to user phone number, user/master code or iButton key. For more details on names, please refer to **8.1. User Phone Number Names**, **10.1. User/Master Code Names** and **11.2. iButton Key Names**.

To disable/enable this confirmation SMS for individual user phone number, please refer to the following configuration methods:

Disable arm/disarm confirmation SMS

EKB2

Menu path:

System armed:

User phone number: OK → **iiii** → OK → SMS MESSAGES 1 → OK → SYS ARMED EVENT → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → SYS ARMED EVENT → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → SYS ARMED EVENT → OK → SMS REPORT → OK → DISABLE → OK

Disable arm/disarm confirmation SMS

EKB2

System disarmed:

User phone number: ... → SYS DISARMED EVENT → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → SYS DISARMED EVENT → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → SYS DISARMED EVENT → OK → SMS REPORT → OK → DISABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

System armed event

User phone number: 25 01 up 0 #

SMS text message to all users simultaneously: 21 01 0 #

SMS delivery report: 55 01 0 #

System disarmed event

User phone number: 25 02 up 0 #

SMS text message to all users simultaneously: 21 02 0 #

SMS delivery report: 55 02 0 #

Value: *up* - user phone number slot, range - [01... 10].

Example: 2502040#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Enable arm/disarm confirmation SMS

EKB2

Menu path:

System armed:

User phone number: OK → *iiii* → OK → SMS MESSAGES 1 → OK → SYS ARMED EVENT → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → SYS ARMED EVENT → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → SYS ARMED EVENT → OK → SMS REPORT → OK → ENABLE → OK

System disarmed:

User phone number: ... → SYS DISARMED EVENT → OK → 2G/4G USER 1... 10 → OK → EN-ABLE → OK

SMS text message to all users simultaneously: ... → SYS DISARMED EVENT → OK → SMS TO ALL → OK → EN-ABLE → OK

SMS delivery report: ... → SYS DISARMED EVENT → OK → SMS REPORT → OK → EN-ABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

System armed event

User phone number: 25 01 up 1 #

SMS text message to all users simultaneously: 21 01 1 #

SMS delivery report: 55 01 1 #

System disarmed event

User phone number: 25 02 up 1 #

SMS text message to all users simultaneously: 21 02 1 #

SMS delivery report: 55 02 1 #

Value: *up* - user phone number slot, range - [01... 10].

Example: 2502061#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: The system will always deliver a confirmation SMS to the user after arming/disarming the system by SMS text message or Call method, even if the arm/ disarm SMS notification is disabled.

For more details on how *Send SMS text message to all users simultaneously* and *SMS delivery* report parameters affect the SMS text message transmission, please refer to **27. SYSTEM NOTIFICATIONS**.

13. EXIT AND ENTRY DELAY

When arming, the system initiates the exit delay countdown (by default - 15 seconds) intended for the user to leave the secured area. The exit delay is indicated by short beeps emitted by EKB2/EKB3/EKB3W/EWKB4/EKB6 keypad buzzer and buzzer, connected to the alarm system. When arming:

- a non-partitioned system, a countdown timer will be displayed in the home screen view of EKB2 during exit delay.
- a partitioned system, EKB2 keypad will display **ARMING part-name** message on the screen for 2 seconds and switch to partition selection menu during exit delay.

Exit delay is provided when arming the system by the following methods:

- EKB2/EKB3/EKB3W/EWKB4 keypad and user/master code.
- iButton key.
- Arm/Disarm by Zone.

To arm the system without exit delay, use one of the following system arming methods:

- Free of charge phone call.
- SMS text message.
- EWK3 wireless key fob
- EGR100 middle-ware.

Set exit delay

SMS

SMS text message content:
`ssss EXITDELAY;p,ext` or `ssss EXITDELAY;p,ext;p,ext;p,ext;p,ext`
Value: *ssss* - 4-digit SMS password; *p* - partition number, range - [1... 4], *ext* - exit delay duration, range - [0... 600] seconds.
Example: *1111 EXITDELAY:1,20;3,43*

EKB2

Menu path:
`OK → iiii → OK → PRIMARY SETTINGS → OK → EXIT DELAY → OK → PARTITION 1... 4 → OK → ext → OK`
Value: *iiii* - 4-digit installer code;, *ext* - exit delay duration, range - [0... 600] seconds.

EKB3/
EKB3W/
EWKB4

Enter parameter 72, partition number and exit delay duration:
`72 pp ext #`
Value: *pp* - partition number, range - [01... 04], *ext* - exit delay duration, range - [0... 600] seconds.
Example: *7203259#*

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: Alternatively, you can set exit delay value to "0" in order to arm the system without exit delay by any available method.

NOTE: EKB3/EKB3W/EWKB4/EKB6 keypad buzzer will only beep if the keypad is operating in the partition where exit delay countdown is in progress.

Once the exit delay has expired, the system is armed. Upon return and violation of delay zone, the system will initiate the entry delay countdown (by default - 15 seconds) after the user has entered the secured area. The countdown is indicated by short beeps provided emitted by keypad internal buzzer. Once the user presses/touches any key on the keypad during this delay, the buzzer of the keypad will be silenced. Entry delay countdown is intended for user to enter a valid user code and disarm the system before the alarm is caused.

Set entry delay for Delay zone

SMS

SMS text message content:
`ssss ENTRYDELAY:nn,eeeeee` or `ssss ENTRYDELAY:nn,eeeeee;nn,eeeeee;nn,eeeeee;nn,eeeeee`
Value: `ssss` - 4-digit SMS password; `nn` - zone number, range - [1... 144], `eeeeee` - entry delay duration, range - [0... 9999] seconds.
Example: `1111 ENTRYDELAY:1,25;54,14;12,20`

EKB2

Menu path:
On-board zone: `OK → iiiii → OK → ZONES → OK → ONBOARD ZONES → OK → ZONE 1... 16 → OK → ENTRY DELAY → OK → eeeee → OK`
Wireless zone: `OK → iiiii → OK → WIRELESS ZONES → OK → WIRELESS ZONES 1... 4 → OK → WIRELESS ZONE 17... 144 → OK → ENTRY DELAY → OK → eeeee → OK`
Keypad zone: `OK → iiiii → OK → ZONES → OK → KEYPAD ZONES → OK → 1ST... 4TH KEYPAD ZONE → OK → ENTRY DELAY → OK → eeeee → OK`
EPGM1 zone: `... → EPGM1 ZONES 1-16... EPGM1 ZONES 17-32 → OK → EPGM1 ZONE 1... 32 → OK → ENTRY DELAY → OK → eeeee → OK`
Value: `iiii` - 4-digit installer code; `eeeeee` - entry delay duration, range - [0... 9999] seconds.

EKB3/
EKB3W/
EWKB4

Enter parameter 54, partition number and entry delay duration:
`54 nn eeeee #`
Value: `nn` - zone number, range - [01... 144], `eeeeee` - entry delay duration, range - [0... 9999] seconds
Example: `5403259#`

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: Due to battery power saving reasons, EKB3W/EWKB4 keypad buzzer will not sound during entry delay if the violated Delay type zone is not of the associated EKB3W/EWKB4 keypad.

For more details on zone types, please refer to **14.5. Zone Type Definitions**.

14. ZONES

Detection devices such as motion detectors and door contacts are connected to the alarm system's zone terminals. Once connected, the associated zone's parameters must be configured.

ESIM484 comes equipped with 8 on-board zones allowing to connect up to 8 detection devices. For more details regarding zone expansion, please refer to **14.2. Zone Expansion**.

ESIM484 zones are classified by 5 categories:

Zone category	Description	Max. number of zones per device	Max. number of zones in total
On-board zones	Built-in wired zones of ESIM484 alarm system.	10/20*	10/20*
Keypad zones	Hardwired zones of EKB2/EKB3/EKB3W/EWKB4 keypad.	1	4
EPGM1 zones	Zones of EPGM1 - hardwired zone and PGM output expansion module.	16	32
Wireless zones	Non-physical zones automatically created by connected wireless devices.	4**	128***
Virtual zones	Non-physical zones intended for Panic button feature (alarm activation upon pressing the button) on EWK2 wireless key fob. Virtual zones can be manually created using <i>Eldes Utility</i> .	64****	64****

* - 10-Zone mode is enabled by default. ATZ mode doubles the on-board zone number and increases it to 20 in total.

** - Depends on the paired wireless device.

*** - Available only if no keypad zones, EPGM1 zones and virtual zones are present.

**** - Available only if no keypad zones, EPGM1 zones and wireless zones are present.

14.1. Zone Numbering

The zone numbers ranging from Z1 through Z20 are permanently reserved for on-board zones even when ATZ mode is disabled. The Z21-Z144 zone numbers are automatically assigned in the chronological order to the created virtual zones and the devices connected to the system: keypads, wireless devices, EPGM1 modules.

14.2. Zone Expansion

For additional detection device connection, the number of zones can be expanded by:

- enabling the ATZ (Advanced Technology zone) mode (see **14.4. ATZ (Advanced Technology Zone) Mode**).
- connecting EPGM1 hardwired zone and PGM output expansion module.
- connecting keypads (see **32.1.1. EKB2 - LCD Keypad**, **32.1.2. EKB3 - LED Keypad** and **19.4. EKB3W/EWKB4 - Wireless LED Keypad**).
- pairing wireless devices (see **19. WIRELESS DEVICES**).
- creating virtual zones (see *Eldes Utility*'s Help section).

The maximum supported number of zones is 144.

14.3. 10-Zone Mode

By default, ESIM484 alarm system runs in the 10-Zone mode under zone connection Type 1 allowing to connect up to 10 detection devices of NO (normally-open) type to the on-board zone terminals as indicated in the wiring diagram of Type 1. Different zone connection types of 10-Zone mode can be individually assigned to each on-board zone.

The EPGM1 module supports "non ATZ" mode only, while the selected zone connection type applies to hardwired zones of EPGM1 module altogether. By default, EPGM1 module runs under zone connection Type 1. However, a mixed combination of Type 1 and Type 2 zone connection types is supported simultaneously regardless of the type (Type 1 or Type 2) selected in the system's configuration. Once Type 3 zone connection type is selected, the detection device wiring on EPGM1 module zones must be done according to the wiring diagram of the associated type.

The keypads support Type 1 and Type 2 wiring. A mixed combination of both zone connection types is supported by keypad zones.

Zone connection types featured by 10-Zone mode are following:

- **Type 1** - Parallel wiring of NO (normally-open) detection device with 5,6kΩ EOL (end-of-line) resistor.
- **Type 2** - Consecutive wiring of NC (normally-closed) detection device with 5,6kΩ EOL resistor.
- **Type 3** - Combination of serial and parallel wiring of tamper with 5,6kΩ EOL resistor and NC detection device with 3,3kΩ EOL resistor.

For zone wiring diagrams of the "non ATZ" mode, please refer to **2.3.2. Zone Connection Types**.

Set zone connection type of "non ATZ" mode for on-board and EPGM1 zones

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: Type 3 is NOT supported by keypad zones.

14.4. ATZ (Advanced Technology Zone) Mode

The ATZ mode is a software-based feature that doubles the number of on-board zones and enables two detection devices to be installed per 1 zone terminal. Once this mode is enabled, the zone connection Type 4 is set automatically. The detection devices must be wired to the on-board zone terminals as indicated in the wiring diagram of the associated zone connection type. Different zone connection types of ATZ mode can be individually assigned to each on-board zone pair i.e. Z1-Z11, Z2-Z12 etc. .

Once enabled, the ATZ mode DOES NOT affect EPGM1 zones, nor keypad zones and applies to on-board zones only. The ATZ mode is NOT supported by EPGM1 and keypad zones.

Zone connection types featured by ATZ mode are the following:

- **Type 4** - Parallel wiring of 2 NC (normally-closed) detection devices with 5,6kΩ and 3,3kΩ EOL (end-of-line) resistors respectively. 5,6kΩ EOL resistor corresponds to zones ranging from Z1 through Z10, while 3,3kΩ EOL resistor corresponds to zones ranging from Z11 through Z16.
- **Type 5** - Combination of consecutive and parallel wiring of tamper with 5,6kΩ EOL resistor and 2 NC (normally-closed) detection devices with 5,6kΩ and 3,3kΩ EOL resistors respectively. 5,6kΩ EOL resistor corresponds to zones ranging from Z1 through Z10, while 3,3kΩ EOL resistor corresponds to zones ranging from Z11 through Z20.

For zone wiring diagrams of the ATZ mode, please refer to **2.3.2. Zone Connection Types**.

Enable ATZ mode

EKB2

Menu path:

OK → **iiii** → OK → ZONES → OK → ATZ MODE → OK → ENABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 28 and parameter status value:

28 1 #

Example: 281 #

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Disable ATZ mode

EKB2

Menu path:

OK → **iiii** → OK → ZONES → OK → ATZ MODE → OK → DISABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 28 and parameter status value:

28 0 #

Example: 280 #

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Set zone connection type of ATZ mode for on-board zones

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

14.5. Zone Type Definitions

- **Interior Follower** - The zone can be violated during exit and entry delay without causing an alarm. If the zone is violated before the entry delay has begun, it will cause an instant alarm followed by single notification delivery even if the zone has been violated multiple times while alarm period (by default - 1 minute) is in progress. If another Interior Follower-type zone has been violated it should act in

the same way - cause an instant alarm followed by single notification delivery even if the zone has been violated multiple times while alarm period (by default - 1 minute) is in progress.

- **Instant** - The alarm is instantly caused if this zone is violated when the system is armed or during entry delay. This zone type is usually used for doors, windows, shock sensors or other zones.
- **24-Hour** - When the system is either armed or disarmed, the zone will cause instant alarm if violated. Normally, this type of zone is used for securing the areas that require constant supervisory.
- **Delay** - This zone type can be violated during exit and entry delay without causing an alarm. If the zone is violated when the system is armed, it will initiate entry delay countdown intended for the user to disarm the system. If the zone remains violated after the exit delay expires, it will cause an instant alarm. Typically, this zone type is used for door contacts installed at designated exit/entry doors.
- **Fire** - If this zone type is violated when the system is either armed or disarmed, the alarm will be instantly caused and the siren/bell will emit pulsating sound. Once the alarm is caused by violating a Fire-type zone followed by turning OFF the alarm using any available disarm method, the system will ignore the violations of any Fire-type zone (including the repeated violations of the said zone) caused within a 1-minute time frame. Typically, this zone type is used for flame and smoke detectors.
- **Panic/Silent** - This zone operates the same as 24-Hour zone type, but the system will not activate the siren/bell and keypad buzzer if violated. Normally, this zone type used for panic alarm buttons.
- **CO Sensor** - This zone type operates identically to Fire zone type and it is used for CO (carbon monoxide) detector.
- **Report/Control** - This zone operates the same as Panic/Silent zone type, but unique event data message will be transmitted to the monitoring station if violated. However, no alarm will be caused - the system will NOT dial the listed user phone number regardless of the status of Call in Case of Alarm feature (enabled or disabled), nor the siren will sound. Typically, this zone type is used to report a certain non-alarm event, such as heating activation or fault.
- **Instant Silent** - This zone operates in the same way as Panic/Silent, but only when the system is armed.

Set zone type for individual zone

EKB2

Menu path:

On-board zone: OK → iiiii → OK → ZONES → OK → ONBOARD ZONES → OK → ZONE 1... 16 → OK → TYPE → OK → INTERIOR FOLLOWER | INSTANT | 24- HOUR | DELAY | FIRE | PANIC/SILENT | CO SENSOR | REPORT/CTRL | INSTANT SILENT → OK

Wireless zone: OK → iiiii → OK → WIRELESS ZONES → OK → WIRELESS ZONES 1... 4 → OK → WIRELESS ZONE 17...144 → OK → TYPE → OK → INTERIOR FOLLOWER | INSTANT | 24-HOUR | DELAY | FIRE | PANIC/SILENT | CO SENSOR | REPORT/CTRL | INSTANT SILENT → OK

Keypad zone: OK → iiiii → OK → ZONES → OK → KEYPAD ZONES → OK → 1ST... 4TH KEYPAD ZONE → OK → TYPE → OK → INTERIOR FOLLOWER | INSTANT | 24-HOUR | DELAY | FIRE | PANIC/SILENT | CO SENSOR | REPORT/CTRL | INSTANT SILENT → OK

EPGM1 zone: ... → 1... 8. EPGM1 ZONES 1-16... EPGM1 ZONES 17-32 → OK → EPGM1 ZONE 1... 32 → OK → INTERIOR FOLLOWER | INSTANT | 24-HOUR | DELAY | FIRE | PANIC/SILENT | CO SENSOR | REPORT/CTRL | INSTANT SILENT → OK

Value: iiiii - 4-digit installer code.

EKB3/
EKB3W/
EKB4

Enter parameter 53, zone number and zone type number:

53 nn 1 # - Interior Follower

53 nn 2 # - Instant

53 nn 3 # - 24-Hour

53 nn 4 # - Delay

53 nn 5 # - Fire

53 nn 6 # - Panic/Silent

53 nn 7 # - CO Sensor

53 nn 8 # - Report/Control

53 nn 9 # - Instant Silent

Value: nn - zone number, range - {01...144}

Example: 53125#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: The system will NOT activate siren and keypad buzzer only when Panic/Silent, Report/Control or Instant Silent zone type is violated.

14.6. Zone Attributes

- **Stay** - If this attribute is enabled, the zone, regardless of its type, will not cause an alarm if violated when the system is STAY-armed. By enabling this attribute, Alarm Count to Bypass feature will not operate with the same zone. For more details on arming the system in the Stay mode, please refer to **15. STAY MODE**.
- **Force** - This attribute determines whether the system can be armed or not while a zone is violated resulting in partial arm event. If a zone with the Force attribute enabled remains violated until the exit delay expires, it will be ignored. Once the system is partially armed followed by zone restore, the violation of this zone will no longer be ignored and the zone will operate according to the determined type. For more details on zone types, please refer to **14.5. Zone Type Definitions**.
- **Shared** - This attribute determines whether a zone, assigned to multiple partitions, will cause an alarm or not in the associated armed

partition if violated. If a zone with the Shared attribute enabled is violated when at least one of the associated partitions is disarmed, the alarm will not be caused. Once the system is armed in all of the associated partitions, the zone with Shared attribute enabled will operate according to the determined type. Typically, this attribute is used for shared areas, such as corridors.

- **Delay, s** - This attribute determines the zone sensitivity level by delay time (by default - 15 seconds). If the zone remains triggered until the delay time expires, the zone is considered violated. This attribute does not apply to wireless zones, keypad zones and virtual zones.
- **Cross-Zone/Intelli-Zone** is a method used to prevent false alarms. The system will not cause an alarm unless two associated zones are violated within a specified time period, known as Alarm Confirmation Timeout. By associating a certain zone to itself, the system would cause an alarm only if the zone has been violated repeatedly within the Alarm Confirmation Timeout. This feature operates with all zone categories including virtual zones.
- **Delay becomes Instant in Stay mode** - This attribute determines whether or not any Delay type zone will operate as Instant type zone when the system is armed in the Stay mode. When the system is fully armed, the Delay type zone will operate normally. For more details on Delay and Instant zone types, please refer to **14.5. Zone Type Definitions**.
- **Chime** - This feature is used to emit 3 short beeps from the keypad buzzer whenever any Delay type zone is violated while the system is disarmed. Typically, the feature is used for designated exit/entry doors to indicate the opening of the doors.
- **Bell** - This attribute operates identically as Chime and applies to EKB3W/EWKB4 keypad only.
- **Alarm Count to Bypass** - This attribute determines a number of times the zone can be violated until it is automatically bypassed. It can be assigned to Interior Follower, Instant, Delay and Instant Silent zone types only. Alarm Count to Bypass becomes inactive once the Stay attribute is enabled on the same zone. For more details on zone bypassing and how to activate a bypassed zone, please refer to **14.7. Bypassing and Activating Zones**.

NOTE: Due to battery power saving reasons, EKB3W/EWKB4 wireless keypad buzzer will not sound if the Bell attribute is not enabled and the violated Delay type zone is not of the associated EKB3W/EWKB4 wireless keypad. For more details on EKB3W/EWKB4 wireless keypad, please refer to **19.5. EKB3W/EWKB4 - Wireless LED Keypad**.

Enable Stay attribute for individual zone	<div>EKB2</div> <div>Menu path: On-board zone: OK → iiiii → OK → ZONES → OK → ONBOARD ZONES → OK → ZONE 1... 16 → OK → STAY → OK → ENABLE → OK Wireless zone: OK → iiiii → OK → WIRELESS ZONES → OK → WIRELESS ZONES 1... 4 → OK → WIRELESS ZONE 17... 144 → OK → STAY → OK → ENABLE → OK Keypad zone: OK → iiiii → OK → ZONES → OK → KEYPAD ZONES → OK → 1ST... 4TH KEYPAD ZONE → OK → STAY → OK → ENABLE → OK EPGM1 zone: ... → EPGM1 ZONES 1-16... EPGM1 ZONES 17-32 → OK → 1...8. EPGM1 ZONE 1... 32 → OK → STAY → OK → ENABLE → OK Value: iiiii - 4-digit installer code.</div>
	<div>EKB3/ EKB3W/ EWKB4</div> <div>Enter parameter 56, zone number and parameter status value: 56 nn 1 # Value: nn - zone number, range - [01... 144]. Example: 56041#</div>
	<div>Eldes Utility</div> <div>This operation may be carried out from the PC using the <i>Eldes Utility</i>.</div>
Disable Stay attribute for individual zone	<div>EKB2</div> <div>Menu path: On-board zone: OK → iiiii → OK → ZONES → OK → ONBOARD ZONES → OK → ZONE 1... 16 → OK → STAY → OK → DISABLE → OK Wireless zone: OK → iiiii → OK → WIRELESS ZONES → OK → WIRELESS ZONES 1... 4 → OK → WIRELESS ZONE 17... 144 → OK → STAY → OK → DISABLE → OK Keypad zone: OK → iiiii → OK → ZONES → OK → KEYPAD ZONES → OK → 1ST... 4TH KEYPAD ZONE → OK → STAY → OK → DISABLE → OK EPGM1 zone: ... → EPGM1 ZONES 1-16... EPGM1 ZONES 17-32 → OK → 1...8. EPGM1 ZONE 1... 32 → OK → STAY → OK → DISABLE → OK Value: iiiii - 4-digit installer code.</div>
	<div>EKB3/ EKB3W/ EWKB4</div> <div>Enter parameter 56, zone number and parameter status value: 56 nn 0 # Value: nn - zone number, range - [01... 144]. Example: 56190#</div>
	<div>Eldes Utility</div> <div>This operation may be carried out from the PC using the <i>Eldes Utility</i>.</div>

**Enable Force attribute
for individual zone**

EKB2

Menu path:

On-board zone: OK → **iiii** → OK → ZONES → OK → ONBOARD ZONES → OK → ZONE 1... 16 → OK → FORCE → OK → ENABLE → OK

Wireless zone: OK → **iiii** → OK → WIRELESS ZONES → OK → WIRELESS ZONES 1... 4 → OK → WIRELESS ZONE 17... 144 → OK → FORCE → OK → ENABLE → OK

Keypad zone: OK → **iiii** → OK → ZONES → OK → KEYPAD ZONES → OK → 1ST... 4TH KEYPAD ZONE → OK → FORCE → OK → ENABLE → OK

EPGM1 zone: ... → EPGM1 ZONES 1-16... EPGM1 ZONES 17-32 → OK → 1... 8. EPGM1 ZONE 1... 32 → OK → FORCE → OK → ENABLE → OK

Value: **iiii** - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 82, zone number and parameter status value:

82 nn 1 #

Value: **nn** - zone number, range - [01... 144].

Example: 82061#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Disable Force
attribute for
individual zone**

EKB2

Menu path:

On-board zone: OK → **iiii** → OK → ZONES → OK → ONBOARD ZONES → OK → ZONE 1... 16 → OK → FORCE → OK → DISABLE → OK

Wireless zone: OK → **iiii** → OK → WIRELESS ZONES → OK → WIRELESS ZONES 1... 4 → OK → WIRELESS ZONE 17... 144 → OK → FORCE → OK → DISABLE → OK

Keypad zone: OK → **iiii** → OK → ZONES → OK → KEYPAD ZONES → OK → 1ST... 4TH KEYPAD ZONE → OK → FORCE → OK → DISABLE → OK

EPGM1 zone: ... → EPGM1 ZONES 1-16... EPGM1 ZONES 17-32 → OK → 1...8. EPGM1 ZONE 1... 32 → OK → FORCE → OK → DISABLE → OK

Value: **iiii** - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 82, zone number and parameter status value:

82 nn 0 #

Value: **nn** - zone number, range - [01... 144].

Example: 82110#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Enable/disable
Shared attribute for
individual zone**

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Set Delay,s attribute

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Enable/disable Delay
becomes Instant in
Stay mode attribute**

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Disable Chime
attribute**

EKB2

Menu path:

OK → **iiii** → OK → ZONES → OK → CHIME → OK → DISABLE → OK

Value: **iiii** - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 32 and parameter status value:

32 0 #

Example: 320#

Enable Chime attribute	Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .
	EKB2	Menu path: OK → <u>iiii</u> → OK → ZONES → OK → CHIME → OK → ENABLE → OK Value: <i>iiii</i> - 4-digit installer code.
	EKB3/ EKB3W/ EKB4	Enter parameter 32 and parameter status value: <u>32</u> 1 # Example: 321 #
	Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .



By default, Cross-Zone/Intelli-Zone is not set. To associate two zones and/or set the Alarm Confirmation Timeout, please refer to the following configuration method.

Associate a zone for Cross-Zone/Intelli-Zone attribute	Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .
Set Alarm Confirmation Timeout	Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .
Set Alarm Count to Bypass attribute for individual zone	Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .

ATTENTION: Cross-Zone/Intelli-Zone feature is NOT recommended in case it is necessary to bypass the associated zone, otherwise the zone that requires alarm confirmation will never cause an alarm when violated.

14.7. Bypassing and Activating Zones

NOTE for EKB3/EKB3W/EWKB4: The Configuration mode must remain deactivated before bypassing a violated zone or activating a bypassed zone.

Zone bypassing allows the user to deactivate a violated zone and arm the system without restoring the zone. If a bypassed zone is violated or restored during exit/entry delay, or when then system is armed, it will be ignored. When a zone is bypassed, EKB3/EKB3W/EWKB4 keypad indicator  will light ON and EKB2 keypad will display  icon in the home screen view.

Bypass individual violated zone

EKB2

Menu path:

OK → uumm → OK → BYPASS → OK → BYPASS LIST 1... 9 → OK → Z1-zone-name... Z144-zone-name → OK → BYPASS → OK

Value: uumm - 4-digit user/master code; zone-name - up to 24 characters zone name.

**EKB3/
EKB3W/
EWKB4**

Press the key, enter zone number and user/master code:

 nn uumm #

Value: nn - zone number, range - [01... 144]; uumm - 4-digit user/master code.

Example:  091111#

Bypass all violated zones

EKB2

Menu path:

OK → uumm → OK → BYPASS → OK → BYP VIOLATED ZONES → OK

Value: uumm - 4-digit user/master code.

The zone will remain bypassed until the system is disarmed. Once the system is disarmed, the corresponding zone state will be indicated on the keypads (see **32.1.1. EKB2 - LCD Keypad**, **32.1.2. EKB3 - LED Keypad** and **19.5. EKB3W/EWKB4 - Wireless LED Keypad**) and Info SMS text message (see **26. SYSTEM INFORMATION. INFO SMS**). Alternatively, the user can activate the bypassed zone by the following configuration methods.

Activate bypassed zone

EKB2

Menu path:

OK → uumm → OK → BYPASS → OK → BYPASS LIST 1... 9 → OK → Z1-zone-name... Z144-zone-name → OK → UNBYPASS → OK

Value: uumm - 4-digit user/master code; zone-name - up to 24 characters zone name.

**EKB3/
EKB3W/
EWKB4**

Press the key, enter zone number and user/master code:

 nn uumm #

Value: nn - zone number, range - [01... 144]; uumm - 4-digit user/master code.

Example:  251111#

NOTE: Zones can only be bypassed and activated when the system is not armed.

14.8. Zone Names

Each zone has a name that can be customized by the user. Typically, the name specifies a device type connected to a determined zone terminal, for **Example:** Kitchen doors opened. The zone names are used in SMS text messages that are sent to the user during alarm, the By default, the zone names are: Z1 - Zone1, Z2 - Zone2, Z3 - Zone3, Z4 - Zone4 etc.

Set zone name

SMS

SMS text message content:

ssss Znn:zone-name

Value: ssss - 4-digit SMS password; nn - zone number, range - [1... 144]; zone-name - up to 24 characters zone name.

Example: 1111 Z3:Door sensor triggered

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

View zone names

SMS

SMS text message content:

ssss STATUS

Value: ssss - 4-digit SMS password.

Example: 1111 STATUS

EKB2

Menu path:

On-board zone: OK → iiiii → OK → ZONES → OK → ONBOARD ZONES → OK → ZONE 1... 16 → OK → NAME

Wireless zone: OK → iiiii → OK → WIRELESS ZONES → OK → WIRELESS ZONES 1... 4 → OK → WIRELESS ZONE 17... 144 → OK → NAME

Keypad zone: OK → iiiii → OK → ZONES → OK → KEYPAD ZONES → OK → 1ST... 4TH KEYPAD ZONE → OK → NAME

EPGM1 zone: ... → EPGM1 ZONES 1-16... EPGM1 ZONES 17-32 → OK → 1... 8. EPGM1 ZONE 1... 32 → OK → NAME

Value: iiiii - 4-digit installer code.

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: Colon, semi-colon characters, parameter names and/or values, such as PSW, STATUS, ON, OFF etc. are NOT allowed in zone names

NOTE: Multiple zone names can be set by a single SMS text message, **Example:** 1111 Z1:Kitchen doors opened;Z3:Movement in basement;Z4:Bedroom window opened

14.9. Disabling and Enabling Zones

By default, all zones, except keypad and virtual zones, are enabled. To permanently disable/enable an individual zone, please refer to the following configuration methods.

Disable zone

SMS

SMS text message content:

ssss Znn:OFF

Value: ssss - 4-digit SMS password; nn - zone number, range - [1... 144].

Example: 1111 Z13:OFF

EKB2

Menu path:

On-board zone: OK → iiiii → OK → ZONES → OK → ONBOARD ZONES → OK → ZONE 1... 16 → OK → STATUS → OK → DISABLE → OK

Wireless zone: OK → iiiii → OK → WIRELESS ZONES → OK → WIRELESS ZONES 1... 4 → OK → WIRELESS ZONE 17... 144 → OK → STATUS → OK → DISABLE → OK

Keypad zone: OK → iiiii → OK → ZONES → OK → KEYPAD ZONES → OK → 1ST... 4TH KEYPAD ZONE → OK → STATUS → DISABLE → OK

EPGM1 zone: ... → EPGM1 ZONES 1-16... EPGM1 ZONES 17-32 → OK → 1... 8. EPGM1 ZONE 1... 32 → OK → STATUS → DISABLE → OK

Value: iiiii - 4-digit installer code.

EKB3/ EKB3W/ EKB4

Enter parameter 52, zone number and parameter status value:

52 nn 0 #

Value: nn - zone number, range - [01... 144].

Example: 52360#

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Enable zone

SMS

SMS text message content:

ssss Znn:ON

Value: ssss - 4-digit SMS password; nn - zone number, range - [1... 144].

Example: 1111 Z6:ON


EKB2	Menu path: On-board zone: OK → iiii → OK → ZONES → OK → ONBOARD ZONES → OK → ZONE 1... 16 → OK → STATUS → OK → ENABLE → OK Wireless zone: OK → iiii → OK → WIRELESS ZONES → OK → WIRELESS ZONES 1... 4 → OK → WIRELESS ZONE 17... 144 → OK → STATUS → OK → ENABLE → OK Keypad zone: OK → iiii → OK → ZONES → OK → KEYPAD ZONES → OK → 1ST... 4TH KEYPAD ZONE → OK → STATUS → ENABLE → OK EPGM1 zone: ... → EPGM1 ZONES 1-16... EPGM1 ZONES 17-32 → OK → 1... 8. EPGM1 ZONE 1... 32 → OK → STATUS → ENABLE → OK Value: <i>iiii</i> - 4-digit installer code.
EKB3/ EKB3W/ EKB4	Enter parameter 52, zone number and parameter status value: 52 nn 1 # Value: <i>nn</i> - zone number, range - [01... 144]. Example: 52151#
Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .

14.10. Viewing Zone State

The zone state (violated/restored) is indicated in real-time by all available configuration methods. However, the most convenient way to view the zone state is using the graphical interface of *Eldes Utility* as follows:

- Red - zone is violated.
- Green - zone is restored.
- Grey - zone is disabled.

To view the zone state, please refer to the following configuration methods.

View zone state	SMS	SMS text message content: ssssINFO Value: <i>ssss</i> - 4-digit SMS password. Example: 1111 INFO
	EKB2	Menu path: OK → uumm → OK → VIOLATED ZONES → OK → ZONE 1... 144 Value: <i>uumm</i> - 4-digit user/master code.
	EKB3/ EKB3W/ EKB4	Please, refer to illuminated zone indicators ranging from 1 through 12 on the keypad. The flashing indicator  represents violated high-numbered zones (Z13-Z144). For more details on violated high-numbered zone indication, please refer to 29. INDICATION OF SYSTEM FAULTS .

15. STAY MODE

Stay mode allows the user to arm and disarm the alarm system without leaving the secured area. If the zones with Stay attribute enabled are violated when the system is STAY-armed, no alarm will be caused. Typically, this feature is used when arming the system at home before going to bed.

The system can be STAY-armed under the following conditions:




- If a Delay-type zone is NOT violated during exit delay and a zone (-s) with Stay attribute enabled exists, the system will arm in Stay mode. When arming the system in Stay mode under this condition, one of the available arming methods must be used that provide exit delay. For more details on these methods, please refer to **13. EXIT AND ENTRY DELAY**.
- The system will instantly arm in Stay mode when using one of the following methods.

Arm the system in Stay mode

EKB2


Menu path:
Non-partitioned system: P2 → uumm → OK
Partitioned system: P2 → uumm → OK → [p] part-name → OK
Value: uumm - 4-digit user/master code; p - partition number, range - [1... 4]; part-name - up to 15 characters partition name.

EKB3/
EKB3W/
EWKB4

Press the  key and enter user/master:
 uumm
Value: uumm - 4-digit user/master code.
Example:  1111

EWK2

This operation may be carried out from the wireless key fob if pre-assigned using the PC running *Eldes Utility*.

When one or more system partitions are successfully armed in Stay mode, EKB2 keypad will display  icon in the home screen view.

NOTE for EKB3/EKB3W/EWKB4: The Configuration mode must be deactivated, when Stay-arming the system.

NOTE: The system can be armed in Stay mode, only if there is at least one zone with Stay attribute enabled.

NOTE: Stay mode is not supported by virtual zones.

NOTE: The system can also be instantly STAY-armed using ELDES Cloud Services.


For more details on how to enable Stay attribute for zone, please refer to **14.6. Zone Attributes**.

16. TAMPERS

The tamper circuit is a single closed loop such that a break in the loop at any point will cause a tamper alarm regardless of the system status - armed or disarmed. During the tamper alarm, the system will activate the siren/bell and the keypad buzzer and send the SMS text message to the listed user phone number. The system will cause tamper alarm under the following conditions:

- If the enclosure of a detection device, siren/bell, metal cabinet or keypad is opened, the physical tamper switch will be triggered. By default, indicated as *Tamper x* in the SMS text message (x = tamper number). User is able to change tamper's name if he prefers to (see **16.1. Tamper names**). Alternatively, the tamper switch can be connected to a zone resulting in zone alarm when tampered (see **15. ZONES**).
- If the wireless signal is lost due to low signal level or low battery power on a certain wireless device (see **19.3. Wireless Signal Status Monitoring**).

By default, all tampers and tamper alarm notification by SMS text message is enabled. To disable/enable a certain tamper and/or tamper alarm notification, please refer to the following configuration methods:

Disable/enable tamper	Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .
View violated tampers	SMS	The system will automatically send an SMS text message, containing a violated tamper name, to user phone number.
	EKB2	EKB2 Menu path: OK → uumm → OK → VIOLATED TAMPERS → OK → TAMPER 1... 144 Value: uumm - 4-digit user/master code.
	EKB3/ EKB3W/ EKB4	The illuminated indicator  represents system fault presence including violated tamper. For more details on violated tamper indication, please refer to 29. INDICATION OF SYSTEM FAULTS .
Disable tamper alarm notification	EKB2	Menu path: User phone number: OK → iiiii → OK → SMS MESSAGES 1 → OK → TAMPER ALARM → OK → 2G/4G USER1... 10 → OK → DISABLE → OK SMS text message to all users simultaneously: ... → TAMPER ALARM → OK → SMS TO ALL → OK → DISABLE → OK SMS delivery report: ... → TAMPER ALARM → OK → SMS REPORT → OK → DISABLE → OK Value: iiiii - 4-digit installer code.
	EKB3/ EKB3W/ EKB4	Enter parameter 25/21/55, event number, user phone number slot and parameter status value: User phone number: 25 13 up 0 # SMS text message to all users simultaneously: 21 13 0 # SMS delivery report: 55 13 0 # Value: up - user phone number slot, range - [01... 10]. Example: 2513030#
	Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .
Enable tamper alarm notification	EKB2	Menu path: User phone number: OK → iiiii → OK → SMS MESSAGES 1 → OK → TAMPER ALARM → OK → 2G/4G USER1... 10 → OK → ENABLE → OK SMS text message to all users simultaneously: ... → TAMPER ALARM → OK → SMS TO ALL → OK → ENABLE → OK SMS delivery report: ... → TAMPER ALARM → OK → SMS REPORT → OK → ENABLE → OK Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **2513 up 1 #**

SMS text message to all users simultaneously: **21131 #**

SMS delivery report: **55131 #**

Value: up - user phone number slot, range - [01... 10].

Example: 2513041#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

For more details on how to view violated tamper, please refer to **17. ALARM INDICATIONS AND NOTIFICATIONS FOR USER**.

ATTENTION: Once a certain tamper is disabled, the system will NOT deliver any text message regarding the physical tamper violation nor wireless signal loss or restore.

ATTENTION: The system will NOT deliver any text message regarding wireless signal loss or restore while the physical tamper violation is in progress.

ATTENTION: The system will NOT cause any tamper alarm regarding the physical tamper violation nor wireless signal loss if the associated zone is disabled (excepting EWKB 4 on board zone).

16.1. Tamper Names

Each tamper has a name that can be customized by the user. The tamper names are used in SMS text messages that are sent to the user during the tamper alarm. By default, the tamper names are: *Tamper 1, Tamper 2, Tamper 3, Tamper 4* etc. To set a different tamper name, please refer to the following configuration methods.

Manage tamper name





**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: Starting from firmware version V01.02.00 (and up), tamper name formation process changed. Each tamper name now consists of zone name plus common tamper name. Common tamper name is text which is added in field "common tamper name" through Eldes Utility.

17. ALARM INDICATIONS AND NOTIFICATIONS FOR USER

When a zone, depending on zone type (see **14.5. Zone Type Definitions**), or tamper is violated, the system will cause an alarm. By default, the alarm duration is 1 minute (see **20. SIREN/BELL** regarding the alarm duration). During the alarm, the system will follow this pattern:

1. The system activates the siren/bell and the keypad buzzer.
 - a) The siren/bell will emit pulsating sound if the violated zone is of Fire type, otherwise the sound will be steady.
 - b) The keypad buzzer will emit short beeps.
 - c) EKB2 keypad will display !!! icon next to the alarmed partition in the home screen view followed by  icon indicating the presence of the alarm events in the alarm log (see **28. EVENT AND ALARM LOG**). In case a Fire-type zone is violated in any system partition,  icon will appear in the home screen view.
 - d) EKB3 keypad operating in 4-partition mode will flash the [1]... [4] key corresponding to the alarmed partition number.
 - e) If one or more zones are violated, EKB3/EKB3W/EWKB4 will light ON the corresponding violated zone indicator (-s) ranging from 1 through 12. Indicator  will flash if one or more high-numbered zones are violated. If one or tampers are violated, indicator  will light ON. For more details on viewing violated high-numbered zone and tamper numbers by EKB3/EKB3W/EWKB4 keypad, please refer to **29. INDICATION OF SYSTEM FAULTS**.
2. The system attempts to send an SMS text message, containing the violated zone/tamper name (see **14.8. Zone Names** and **16.1. Tamper Names** on how to set a zone and tamper name respectively), to the first listed user phone number, sharing the same partition as the violated zone/tamper. The system will send SMS text messages regarding each violated zone/tamper separately.
 - a) If the SMS cascade option is enabled and the user phone number is unavailable, then the system will attempt to send the SMS text message to the next listed user phone number, assigned to the same partition as the previous one. The user phone number may be unavailable due to the following reasons:
 - mobile phone was switched off.
 - was out of 2G/4G signal coverage.
 - b) The system will continue sending the SMS text message to the next listed user phone numbers in the priority order until one is available. The system sends the SMS text message only once and will not return to the first user phone number if the last one was unavailable.
3. By default, the system attempts to ring the first user phone number via 2G/4G, sharing the same partition as the violated zone/tamper. The system will dial regarding each violated zone/tamper separately.
 - a) When the call is answered, the system will shut down the siren/bell and play the audio file that can be listened to on the user's mobile phone. This feature will be available only if an audio file is recorded and assigned to the violated zone (see **17.2. Audio Files and Introduction Audio**).
 - c) The system will dial the next listed user phone number, assigned to the same partition, if the previous user was unavailable due to the following reasons:
 - mobile phone was switched off.
 - mobile phone was out of 2G/4G signal coverage.
 - provided "busy" signal.
 - user did not answer the call after several rings, predetermined by the 2G/4G operator.
 - d) The system will continue dialling the next listed user phone numbers in the priority order until one is available. However, it will not dial the next listed user phone number if the previous one was available, but rejected the phone call. If the system ends up with all unsuccessful attempts to contact any listed user phone number, it will stop dialling and will NOT repeat the cycle starting with the first user phone number. In addition, the system will dial the listed user phone number only once regardless of its availability
 - e) If Call All in Case of Alarm feature is enabled, the system will attempt to ring all listed user phone numbers in a row starting with the first user phone number with Call in Case of Alarm feature enabled. Regardless of the user being available, unavailable or if he/she has rejected the call, the system will still move to the next listed user with Call in Case of Alarm feature enabled. Once the system has ended contacting all listed users with Call in Case of Alarm feature enabled, it will repeat this cycle 3 more times (by default) by attempting to contact the previously unavailable users and skipping the available ones.
4. If Treat PSTN Call as User Call is feature is enabled, the system attempts to ring the first phone number via PSTN (see **30.2.3. PSTN**). The system will dial regarding each violated zone/tamper separately.
 - a) When the call is answered, the system will automatically drop the call.
 - b) The system will dial the next listed phone number if the previous one was unavailable due to the following reasons:
 - mobile phone was switched off.
 - mobile phone was out of 2G/4G signal coverage.
 - provided "busy" signal.
 - user did not answer the call after several rings, predetermined by the 2G/4G operator.
 - c) By default, the system will continue dialling the next listed user phone numbers in the priority order until one is available. The system will dial the user phone number 5 times if the first user phone number was out of 2G/4G signal coverage/switched OFF, otherwise the system will dial only once. If the system ends up unsuccessful to contact any listed user phone number, will stop dialling and will not return to the first user phone number. The system will not dial the next listed user phone number if the previous one was available, but

rejected the phone call.
To silent the siren/bell as well as to cease system phone calls and SMS text message sending to the user phone numbers, please disarm the system (see **12. ARMING AND DISARMING**).

ATTENTION: The wireless siren EWS2/EWS3 will sound only if wireless zone of the siren is assigned to the same partition as the one that has been alarmed (see **23.1. Zone Partition**).

View violated zones


SMS

SMS text message content:
 ssss INFO
Value: ssss - 4-digit SMS password.
Example: 1111 INFO

EKB2

Menu path:
 OK → uumm → OK → VIOLATED ZONES → OK → ZONE 1... 144
Value: uumm - 4-digit user/master code.

EKB3/
EKB3w/
EWKB4

Please, refer to illuminated zone indicators ranging from 1 through 12 on the keypad. The flashing indicator  represents violated high-numbered zones (Z13-Z144). For more details on violated high-numbered zone indication, please refer to **29. INDICATION OF SYSTEM FAULTS**.

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

View violated tampers


SMS

The system will automatically send an SMS text message, containing a violated tamper name, to user phone number.

EKB2

Menu path:
 OK → uumm → OK → VIOLATED TAMPERS → OK → TAMPER 1... 144
Value: uumm - 4-digit user/master code.

EKB3/
EKB3w/
EWKB4

The illuminated indicator  stands for system fault presence including violated tamper. For more details on violated tamper indication, please refer to **29. INDICATION OF SYSTEM FAULTS**.

Manage Call All in Case of Alarm

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

For more details on how to disable/enable SMS text messages and phone calls to listed user phone number in case of alarm, please refer to **17.1. Enabling and Disabling Alarm Notifications**

ATTENTION: Phone calls via 2G/4G network to the listed user phone number in case of alarm are disabled by force when MS mode is enabled (see **30. MONITORING STATION**).

NOTE: If one or more zones/tampers are violated during the alarm, the system will attempt to send as many SMS text message and dial the user phone number as many times as the zone/tamper was violated. However, this does NOT apply to Interior Follower-type zones.

NOTE: If the system has delivered an SMS text message and/or dialled the user phone number after disarming the system, it means that the SMS text message and/or phone call was queued up in the memory before the system was disarmed. The capacity of the queue is 24 events maximum.

NOTE: In some case, the system might be UNABLE to dial the next listed user phone number in case the phone number has been migrated from a different 2G/4G operator.

17.1. Enabling and Disabling Alarm Notifications
By, default the system will ring the listed user phone numbers via 2G/4G in case of alarm. To disable/enable this feature, please refer to the following configuration methods.

Disable call in case of alarm

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETTINGS → OK → CALL/SMS SETTINGS → OK → CALL IN CASE ALARM → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 30, user phone number slot and parameter status value:

30 **us** 1 #

Value: *us* - user phone number slot, range - [01... 10].

Example: 30081#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Enable call in case of alarm

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETTINGS → OK → CALL/SMS SETTINGS → OK → CALL IN CASE ALARM → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 30, user phone number slot and parameter status value:

30 **us** 0 #

Value: *us* - user phone number slot, range - [01... 10].

Example: 30090#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

By default the system will send SMS text message to listed user phone numbers in case of alarm. To disable/enable this feature, please refer to the following configuration methods.

Disable SMS text message in case of alarm

EKB2

Menu path:

User phone number: OK → **iiii** → OK → SMS MESSAGES 1 → OK → GENERAL ALARM → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → GENERAL ALARM → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → GENERAL ALARM → OK → SMS REPORT → OK → DISABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: 25 03 **up** 0 #

SMS text message to all users simultaneously: 21 03 0 #

SMS delivery report: 55 03 0 #

Value: *up* - user phone number slot, range - [01... 10].

Example: 2503060#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Enable SMS text message in case of alarm

EKB2

User phone number: OK → **iiii** → OK → SMS MESSAGES 1 → OK → GENERAL ALARM → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → GENERAL ALARM → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → GENERAL ALARM → OK → SMS REPORT → OK → ENABLE → OK

Value: *iiii* - 4-digit installer code.

EKB3/
EKB3W/
EWKB4

Press **✕**, then enter installer code, followed by parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: 25 03 up 1 #

SMS text message to all users simultaneously: 21 03 1 #

SMS delivery report: 55 03 1 #

Value: up - user phone number slot, range - [01... 10].

Example: ✕14702503101#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

By default the system will not ring the listed phone number via PSTN in case of alarm. To manage this feature, please refer to **30.2.3. PSTN**

For more details on how *Send SMS text message to all users simultaneously* and *SMS Cascade* parameters affect the SMS text message transmission, please refer to **27. SYSTEM NOTIFICATIONS**.

By default, tamper alarm notification by SMS text message is enabled. For more details on how to disable/enable tamper alarm notification, please refer to **16. TAMPERS**.

ATTENTION: Regardless of the Call in Case of Alarm parameter status, the system will NOT ring the listed user phone number via 2G/4G network if the system is connected to the monitoring station (see **30. MONITORING STATION**).

17.2. Audio Files and Introduction Audio

The system comes equipped with a feature, allowing to record up to 16 audio files of up to 6 seconds length, and another feature, which allows to record 1 introduction audio file of up to 20 seconds length. Recorded files can be assigned to any system zone and be played when the alarm is caused by zone with an audio file assigned. These features will be available only if the system is able to dial user phone number in the event of an alarm and the user answers the call. When the call is answered, the primarily recorded introduction audio file (if assigned), containing essential information (location/ full address or/and user full name) is being played, while the audio file (up to 6 sec. long) will come up just after introduction audio has ended. The supported audio file format is as follows:

- Max. number of audio files: up to 16
- Max. audio length: up to 6 seconds
- Max. number of introduction audio files: 1
- Max. introduction audio length: up to 20 seconds
- File format: .wav
- Specifications: 8,000 kHz; 8 Bit; Mono

By default, none of these audio files are pre-recorded or assigned to any particular zone. To record an introduction audio or audio file and/or assign it to a zone, please refer to the following configuration method.

Record and manage
audio files

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Assign audio file to
individual zone

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: Single audio file can be assigned to multiple zones.

18. PROGRAMMABLE (PGM) OUTPUTS

A PGM output is a programmable output that toggles to its set up state when a specific event has occurred in the system, the scheduled time and day of the week has come or if the user has initiated the PGM output state change manually. Normally, PGM outputs can be used to open/ close garage doors, activate lights, heating, watering and much more. When a PGM output turns ON, the system triggers any device or relay connected to it. ESIM484 comes equipped with four open-collector PGM outputs allowing to connect up to four devices or relays. For more details on PGM output expanding, please refer to **18.2. PGM Output Expansion**.

ESIM484 PGM outputs are classified by 4 categories:

PGM output category	Description	Max. number of PGM outputs per device	Max. number of PGM outputs in total
On-board PGM Outputs	Built-in wired PGM outputs of ESIM484 alarm system.	4	4
EPGM1 PGM Outputs	PGM outputs of EPGM1 - hardwired zone and PGM output expansion module.	2	4
Wireless PGM Outputs	Non-physical PGM outputs automatically created by connected wireless devices.	2 (depends on the connected wireless device)	48 (available only if no EPGM1 PGM outputs are present)

For PGM output wiring diagram, please refer to **2.3.6. Relay Finder® (for example, model 40.61.9.12) with Terminal Socket (for example, model 95.85.3)**.

18.1. PGM Output Numbering

The PGM output numbers ranging from C1 through C4 re permanently reserved for on-board PGM outputs. The C5-C48 PGM output number are automatically assigned in the chronological order to the devices connected to the system: EPGM1 modules and wireless devices.

18.2. PGM Output Type

User is able to configure every single output at his discretion, by choosing 1 of two available types: Switch or Pulse type*. In order to do so, user has to launch Eldes Utility software, open Output section and choose a preferred output type from the drop-down list. After setting the type, user has to save configuration (to click on "Write settings" option).

Switch type

By default, every available output is of Switch type. Output of this type can be in ON or OFF state (the latter is the default state). Accordingly, when this type is selected, there are 3 possible Switch type actions:

- Turn output ON (only when output's state is OFF).
- Turn output OFF (only when output's state is ON).
- Toggle output (switch the current output's state to the opposite).

Additionally, the Switch type output allows to set its' start up state (ON or OFF).

Pulse type

Pulse type output has another option, called pulse duration, which allows to change the specified output's state. The process is performed by applying a low-level or high-level pulse for a set period of time. Acceptable time value range - from 1 second to 60 seconds (inclusively). If user opts to change the default output type to Pulse type, he won't be allowed to set output's start up state.

ATTENTION: EWM1 has a Switch type built-in button, intended to turn the socket ON or OFF while changing the output state accordingly. Thus, if user sets EWM1 output as Pulse type, then any attempt to manually change the EWM1 output state ON or OFF will affect the following attempt to control that same output via other control method.

18.3. PGM Output Control Options

Below you'll find the list of all possible output control options:

- EWK2
- KeyBOB
- EKB2
- EKB3/EKB3W/EWKB4
- EKB6
- Eldes Security app
- SMS
- Automation (schedules)

EKB2 keypad enhanced by a new **Quick control via keypad long press*** feature, which offers an easy and fast way to complete a quick action (e.g. to control any output). To do so, at first user must program EKB2 buttons for the preferred quick actions. There are 10 possible quick control actions in total.

*- These features **are NOT available** for old firmware versions (i.e. for FW versions **V01.09.15 and earlier**).

18.4. PGM Output Expansion

For additional electrical appliance connection, the number of PGM outputs can be expanded by:

- connecting EPGM1 hardwired zone and PGM output expansion module (for more details on technical specifications and installation, please refer to the latest user manual of the device located at www.eldesalarms.com).
- pairing the wireless devices (see **19. WIRELESS DEVICES**).

NOTE: The maximum supported PGM output number is 48.

18.5. PGM Output Names

Each PGM output has a name that can be customized by the user. Typically, the name specifies a device type connected to a determined PGM output, **for example:** *Lights*. The name can be used instead of PGM output number when controlling the PGM output via SMS command. By default, the PGM output names are: *C1 - Control1, C2 - Control2, C3 - Control3, C4 - Control4* etc.

Set PGM output name

SMS

SMS text message content:

`ssssCoo:out-name`

Value: ssss - 4-digit SMS password; oo - PGM output number, range - [1... 48]; out-name - up to 16 characters PGM output name.

Example: 1111 C2:Lights

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

View PGM output names

SMS

SMS text message content:

`ssssINFO`

Value: ssss - 4-digit SMS password.

Example: 1111 INFO

EKB2

Menu path:

`OK → mmmm → OK → PGM OUTPUTS → OK → out-name`

Value: mmmm - 4-digit master code; out-name - up to 16 characters PGM output name.

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: Space, colon, semi-colon, parameter names and/or values (like PSW, STATUS, ON, OFF) are NOT allowed in PGM output names.

18.6. Disabling and Enabling PGM Outputs

By default, all PGM outputs are enabled. Once a PGM output is disabled, it can be turned ON or OFF, thus the change will not be seen neither on the EKB2 and EKB6 keypads nor via Cloud platform. To disable/enable a certain output, refer to the following configuration method.

Control output via Cloud Services and Keypads

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

18.7. Turning PGM Outputs ON and OFF

By default, all PGM outputs are turned OFF. To instantly turn ON/OFF an individual output, refer to the following configuration methods.

Turn ON PGM output/

SMS

SMS text message content:

`ssssCoo:ON` or `ssss out-name:ON`

Value: ssss - 4-digit SMS password; oo - PGM output number, range - [1... 48]; out-name - up to 16 characters PGM output name.

Example: 1111 Lights:ON

EKB2

Menu path:

`OK → mmmm → OK → PGM OUTPUTS → OK → out-name → ON → OK`

Value: mmmm - 4-digit master code; out-name - up to 16 characters PGM output name.

**EKB3/
EKB3W/
EKB4**

Enter installer code, followed by parameter 61, PGM output number and parameter status value:

`iiii 61 oo 1 #`

Value: iiii - 4-digit installer code; oo - PGM output number, range - [01... 48].

Example: ✕147061031#

EKB6

This operation may be carried out from the PC using the *Eldes Utility*.

**EWK2/
KEYBOB**

This operation may be carried out from the wireless key fob if pre-assigned using the PC running *Eldes Utility*.

Turn OFF PGM output

Eldes Utility

This operation may be carried out from the PC using Eldes Utility.

Eldes Security

This operation may be carried out using ELDES Security mobile application.

SMS

SMS text message content:

`ssss Coo:OFF` or `ssss out-name:OFF`

Value: `ssss` - 4-digit SMS password; `oo` - PGM output number, range - [1... 48]; *out-name* - up to 16 characters PGM output name.

Example: `1111 C2:OFF`

EKB2

Menu path:

`OK → mmmm → OK → PGM OUTPUTS → OK → out-name → OFF → OK`

Value: `mmmm` - 4-digit master code; *out-name* - up to 16 characters PGM output name.

EKB3/ EKB3W/ EKB4

Enter installer code, followed by parameter 61, PGM output number and parameter status value:

`iiii 61 oo 0 #`

Value: `iiii` - 4-digit installer code; `oo` - PGM output number, range - [01... 48].

Example: `*147061020#`

EKB6

This operation may be carried out from the PC using the *Eldes Utility*.

EWK2/ KEYBOB

This operation may be carried out from the wireless key fob if pre-assigned using the PC running *Eldes Utility*.

Eldes Utility

This operation may be carried out from the PC using Eldes Utility.

Eldes Security

This operation may be carried out using ELDES Security mobile application.

When the PGM output is turned ON or OFF, the system will send a confirmation by SMS text message to the user phone number that the SMS text message was sent from. To instantly turn OFF an individual PGM output for a determined time period and automatically turn it ON when the time period expires, please refer to the following configuration method.

<div> <div>Pulse ON/OFF output (turn PGM output ON or OFF for a time period)</div> </div>	<div> <div>SMS</div> <div>This operation may be carried out from the mobile phone (via SMS command).</div> </div>
	<div> <div>EKB2/ EKB3/ EKB3W/ EWKB4</div> <div>This operation may be carried out from one of the selected keypads (if it was pre-configured).</div> </div>
	<div> <div>EKB6</div> <div>This operation may be carried out from the wireless touchpad if it was pre-configured.</div> </div>
	<div> <div>EWK2/ KEYBOB</div> <div>This operation may be carried out from the wireless key fob if pre-assigned using the PC running <i>Eldes Utility</i>.</div> </div>
	<div> <div>Eldes Utility</div> <div>This operation may be carried out from the PC using <i>Eldes Utility</i>.</div> </div>
	<div> <div>Eldes Security</div> <div>This operation may be carried out using ELDES Security mobile application.</div> </div>

When the PGM output is turned ON or OFF, the system will send a confirmation by SMS text message to the user phone number that the SMS text message was sent from.

NOTE:

PGM output can be turned ON for a determined time period only when it is in OFF state (and vice versa!).

NOTE for EWK2:

Single EWK2 key fob button can be configured to carry out Partition selection and Control output/Output toggle/Output pulse actions. In such case, the PGM output control action will be executed with a 3-second delay once the button is pressed **and IF it is not followed** within a 3-second period by a press of a button with arm system or disarm system action assigned.

18.8. Automated Control Events (PGM Output Control and System Control)

The system supports up to 48 automated control events (up to 32 automated PGM output controls and 16 automated system controls, inclusively). The automatic action of the determined PGM output can be set as follows:

Switch type outputs:

- **Turn ON** - Determines whether the PGM output is to be turned ON.
- **Turn OFF** - Determines whether the PGM output is to be turned OFF.
- **Switch ON for a time** - Determines whether the current PGM output state is to be changed for a set period of time (in seconds).
- **Switch OFF for a time** - Determines whether the current PGM output state is to be changed for a set period of time (in seconds).

Pulse type outputs:

- **Pulse ON*** - Allows to instantly change (turn ON) PGM output status for a determined time period and automatically change back the output status (turn OFF) when the set time period expires. The range of Pulse duration can be from 1 to 60 seconds.
- **Pulse OFF*** - Allows to instantly change (turn OFF) PGM output status for a determined time period and automatically change back the output status (turn ON) when the set time period expires. The range of Pulse duration can be from 1 to 60 seconds.

The aforementioned PGM output action(-s) can be automatically carried out under the following system events (**NOTE:** sytem events are categorized by **Automation type: System Control** and **Output Control**):

System Control events:

- Arm System
- Disarm System
- Arm Stay
- Disarm from Stay*
- Disarm from any* - System will only track status of selected partitions (with status 'ON'). Action will be performed only if all selected partitions will meet selected system event.
- Arm/Disarm by Zone

Output Control events:

- **System arms** - System is armed in a determined partition (Partitions 1 - 4). Applicable to multiple partitions or to "All partitions".
- **System disarms** - System is disarmed in a determined partition (Partitions 1 - 4). Applicable to a single partition or to "All partitions".
- **System arms Stay** - System is armed in Stay mode. Applicable to multiple partitions or to "All partitions".
- **System disarms from Stay*** - System is disarmed from Stay mode. Applicable to a single partition or to "All partitions".
- **System disarms from any*** - System is disarmed from any mode. Applicable to a single partition or to "All partitions".
- **Alarm begins** - Alarm begins in a determined partition (Partitions 1 - 4). Applicable to multiple partitions or to "All partitions".
- **Alarm stops** - Alarm stops in a determined partition (Partitions 1 - 4). Applicable to a single partition or to "All partitions".
- **Temperature falls** - Temperature falls below the set MIN value of a determined temperature sensor 1-8.
- **Temperature rises** - Temperature rises above the set MAX value of a determined temperature sensor 1-8.
- **By schedule** - Operates based on Start Time of a selected schedule 1-32.
- **Zone violates** - A determined zone ranging from Z1 through Z144 is violated.
- **Zone restores** - A determined zone ranging from Z1 through Z144 is restored.
- **System fault occurs** - A determined system fault is present (for more, please refer to **29. INDICATION OF SYSTEM FAULTS**).

- **System fault restores** - A determined system fault is restored (for more, please refer to **29. INDICATION OF SYSTEM FAULTS**).
 - **Fire alarm begins*** - Performs output control action once a fire alarm starts. Applicable to multiple partitions or to "All partitions".
 - **Fire alarm ends*** - Performs output control action once a fire alarm ends. Applicable to a single partition or to "All partitions".
- *These features are **NOT** available for old firmware versions (i.e. for FW versions **V01.09.15 and earlier**).

18.8.1. Automated Control by Schedule

The system supports up to 32 time period conditions, known as "schedules", that allow to complete the automatic PGM output control or system control action in a certain partition (all partitions) according to the day of the week and time. PGM outputs can automatically operate when a specific event occurs in the system and/or when the scheduled day and time comes. To make it work, user must manually enable the additional time period option for each schedule during the configuration. Each time period option includes the following parameters:

- **Start Time** - Determines the point in time when the automatic PGM output control or system control action can be initiated for Schedule starts event.
- **End Time** - Determines the point in time when the automatic PGM output control or system control action can be initiated for Schedule ends event.
- **On selected days of the week** - Determines days when the automatic PGM output control or system control action is valid.

18.8.2. Automated Control by Condition Event

Condition event specifies the requirements for a determined automatic PGM output operation to be carried out. If this feature is enabled, the PGM output will become dependent on one more condition events that must occur prior or after the aforementioned system control event or output control event. The PGM output will not operate unless the additional condition is also valid:

- **System armed** - System is armed in a determined partition ranging from 1 to 4 or any partition.
- **System disarmed** - System is disarmed in a determined partition ranging from 1 to 4 or any partition.
- **Zone violated** - A determined zone ranging from Z1 to Z144 is violated.
- **Zone restored** - A determined zone ranging from Z1 to Z144 is restored.

Example: PGM output C1 is set to be turned ON when zone Z6 is violated. The Condition event feature is enabled and set to allow this action to be carried out only if system's Partition 2 is disarmed. It means that the PGM output C1 will be turned ON when zone Z6 is violated, but only if system's Partition 2 is disarmed.

Additionally, user is able to choose separate partitions (1 through 4), a combination of partitions (for example, partitions 1 and 3) or any single partition. System will track status of selected partitions only (with status ON). System will perform the predetermined action only if all selected partitions will meet selected Condition event.

Manage PGM output control by event & schedule

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: If the date and time are not set, the system will NOT be able to automatically control the PGM outputs. For more details on how to set date and time, please refer to **9. DATE AND TIME**.

NOTE: When both - a system event is determined and a schedule is selected, the PGM output will operate only if the determined event has occurred in the system during the scheduled time period.

NOTE: When PGM output action is selected as pulse, the PGM output will turn ON or turn OFF for a set period of time based on the PGM output state set up (ON or OFF) for system startup.

18.9. Wireless PGM Output Type Definitions

- **Output** - Operates as normal PGM output that can be controlled by the user or automatically by event and schedule. Normally, this type is used for any device or relay.
- **Siren** - Operates as siren output that automatically activates during alarm. Typically, this type is used for bell/siren connected to EW2 wireless device.

Set output type for individual wireless PGM output

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

19. WIRELESS DEVICES

ESIM484 system has a built-in wireless module for system extension capabilities. The wireless module easily allows the user to pair up to 64 ELDES-made wireless devices with the system. This includes the following:

- EWP2 - wireless PIR sensor (motion detector).
- EWP3 - wireless PIR sensor (motion detector).
- EWD2 - wireless magnetic door contact/shock sensor/flood sensor.
- EWD3 - wireless magnetic door contact/shock sensor/flood sensor.
- EWS3 - wireless indoor siren.
- EWS2/EWS4 - wireless outdoor siren.
- EWK2/EWK2A - wireless key fob.
- KeyBoB - Wireless key fob.
- EKB3W - wireless keypad.
- EWKB4 - wireless keypad.
- EW2 - wireless zone and PGM output expansion module.
- EWF1 - wireless smoke detector.
- EWF1CO - wireless smoke and CO detector.
- EWM1 - wireless power socket.

For more details on technical specifications and installation of the wireless devices, please refer to chapter **41. RADIO SYSTEM INSTALLATION AND SIGNAL PENETRATION - APPENDIX 4** and the latest user manual of the wireless device located at www.eldesalarms.com. The wireless devices can operate at a range of up to 3000m (9842.6ft) range in open areas. The wireless connection is two-way and operates in one of four available channels in ISM868 non-licensed band. When Eldes Utility is launched, the frequency time of attempt of all NOT added wireless devices, that have frequency time of attempt higher than 10 sec. is changed to 10 sec. After Eldes Utility is closed, frequency time of attempt for every individual device is changed as it was.

NOTE: In case if Remote Connection session being activated, the frequency time of attempts for every wireless device will be exactly the same as default Test Time period, indicated below.

The communication link between the wireless device and the alarm system is constantly supervised by a configurable self-test period, known as Test Time. When the wireless device is switched ON, it will initiate the Test Time transmission to the system within its wireless connection range. In order to optimize battery power saving of the wireless device, the Test Time periods vary by itself while the device is switched ON, but still unpaired. When the alarm system is switched OFF or if the wireless device is unpaired or removed the Test Time period of the wireless device is as follows (non-customizable):

- EKB3W, EW2, EWP2, EWS2, EWS3, EWS4, EWF1, EWF1CO, EWM1:
 - First 360 attempts after the device startup (reset) - every 10 seconds.
 - The rest of attempts - every 1 minute.
- EWD2:
 - First 360 attempts after the device startup (reset) - every 10 seconds.
 - The rest of attempts - every 2 minutes.
- **NOTE: Only for EWD3, EWKB4, EWP3**
 - Standard Test Time of all attempts when paired with alarm system - EWP3 - every 1 minute; EWKB4, EWD3 - every 5 minutes.
 - Standard Test Time of all attempts when NOT paired with alarm system or in case wireless connection is lost for more than 48 hours - every 10 minutes.

Once the wireless device is paired, it will attempt to exchange data with ESIM484 system. Due to battery saving reasons, all ELDES wireless devices operate in sleep mode. The data exchange will occur instantly if the wireless device is triggered (zone alarm or tamper alarm) or periodically when the wireless device wakes up to transmit the supervision signal, based on Test Time value, to the system as well as to accept the queued up command (if any) from the system. By increasing the Test Time period, EWS2/EWS3 siren response time will decrease.

Example: The alarm occurred at 09:15:25 and the system queued up the command for EWS3 siren to start sounding. By default, Test Time value of EWS3 siren is 7 seconds, therefore EWS2 siren will sound at 09:15:32.

By default, the Test Time period is as follows (customizable):

- EWKB4, EWD3: every 5 minutes.
- EKB3W, EWD2, EWP2, EWP3: every 60 seconds.
- EWM1, EW2, EWF1, EWF1CO: every 30 seconds.
- EWS2, EWS3, EWS4: every 7 seconds.

To set a different Test Time value, please refer to the following configuration method.

Set custom Test Time

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: Test Time affects the wireless device pairing process due to the alarm system listening for the incoming data from the wireless device. The system pairs with the wireless device only when the first data packet is received.

NOTE for EKB3W/EWKB4: In comparison with other ELDES wireless devices, EKB3W/EWKB4 keypads features some exceptions regarding the wireless communication. For more details on EKB3W/EWKB4 keypad wireless communication and back-light timeout, please refer to **19.5.3. Wireless Communication, Sleep Mode and Back-light Timeout**.

19.1. Pairing, Removing and Replacing Wireless Device

Wireless device management can be easily and conveniently carried out using the graphical interface of *Eldes Utility*. If you intend to manage the wireless devices by SMS text message, an 8-character wireless device ID code will be required in order to pair the device with the system or to remove it from the system. The wireless ID code is printed on a label, which can be located on the inner or outer side of the enclosure or on the printed circuit board (PCB) of the wireless device.

To pair a wireless device, please refer to the following configuration methods.

Pair wireless device with the system

SMS

SMS text message content:

`ssss SET:wless-id`

Value: ssss - 4-digit SMS password; *wless-id* - 8-character wireless device ID code.

Example: `1111 SET:5353185D`

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE FOR EWK2/EWK2A: When pairing EWK2/EWK2A wireless key fob, it is necessary to press several times any button on the device.

Once a wireless device is paired, it occupies one of 64 available wireless device slots and the system adds single or multiple wireless zones and wireless PGM outputs depending on the wireless device model (excepting wireless key fobs EWK2).

To remove a wireless device, please refer to the following configuration methods.

Remove wireless device from the system

SMS

SMS text message content:

`ssss DEL:wless-id`

Value: ssss - 4-digit SMS password; *wless-id* - 8-character wireless device ID code.

Example: `1111 DEL:5353185D`

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Once a wireless device is removed from the system, please restore its default parameters and remove the batteries from it.

To replace an existing wireless device with a new same model device, please refer to the following configuration method.

Replace wireless device

SMS

SMS text message content:

`ssss REP:wless-id < oldwl-id`

Value: ssss - 4-digit SMS password; *wless-id* - 8-character wireless device ID code of the new device; *oldwl-id* - 8-character wireless device ID code of the old device.

Example: `1111 REP:5353185D < 41286652`

When a wireless device is successfully replaced with a new one, the configuration of the old wireless device remains.

ATTENTION: In order to correctly remove the wireless device from the system, the user must remove the device using SMS text message or *Eldes Utility* and restore the parameters of the wireless device to default afterwards. If only one of these actions is carried out, the wireless device and the system will attempt to exchange data to keep the wireless connection alive. This leads to fast battery power drain on the battery-powered wireless device.

NOTE: If you are unable to pair a wireless device, please restore the wireless device's parameters to default and try again. For more details on how to restore the default parameters, please refer to the user manual provided along with the wireless device or visit www.eldesalarms.com to download the latest user manual.

19.2. Wireless Device Information

Once a wireless device is paired, the user can view the following information of a determined wireless device:

- Battery level (expressed in percentage).
- Wireless signal strength (expressed in percentage).
- Error rate (number of failed data transmission attempts in 10-minute period) - indicated only in EKB2 keypad menu.
- Firmware version.
- Test Time period (expressed in milliseconds) of a wireless device - indicated only in SMS text message reply.

To view the wireless device information, please refer to the following configuration methods.

View wireless device information

SMS

SMS text message content:

`ssss RFINFO:wless-id` or `ssss RFINFO:Znn`

Value: `ssss` - 4-digit SMS password/`wless-id` - 8-character wireless device ID code; `nn` - wireless zone number, range - [17... 144].

Example: `1111 RFINFO:595185D`

EKB2

Menu path:

Battery level: `OK` → `iiii` → `OK` → `WIRELESS DEVICES 1...` `2` → `OK` → `wless-dev wless-id` → `OK` → `BATTERY`

Wireless signal: `...` → `wless-dev wless-id` → `OK` → `SIGNAL`

Error rate: `...` → `wless-dev wless-id` → `OK` → `ERROR RATE`

Firmware version: `...` → `wless-dev wless-id` → `OK` → `FW RELEASE`

Value: `iiii` - 4-digit installer code; `wless-dev` - wireless device model; `wless-id` - 8-character wireless device ID code.

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

The system supports up to 32 wireless devices. To view the number of available wireless device slots in the system, please refer to the following configuration methods

View available wireless device slots

SMS

SMS text message content:

`ssss STATUS FREE`

Value: `ssss` - 4-digit SMS password.

Example: `1111 STATUS FREE`

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

19.3. Wireless Signal Status Monitoring

If the wireless signal is lost due to poor signal strength or low battery power on a certain wireless device and does not restore within 4-hour period, the system will cause an alarm (by default, the alarm is disabled). This event is identified as Wireless Signal Loss. By default, indicated as *No wireless signal from wless-dev wless-id Tamper x* in the SMS text message (`wless-dev` = wireless device model; `wless-id` = 8-character wireless device ID code; `x` = tamper number). The user will also be notified by SMS text message as soon as the wireless signal is restored.

The default period for wireless signal loss detection is 4 hours. However, a custom wireless signal loss timeout can be set up that must be at least 3 times longer than the longest Test Time period of a wireless device currently paired with the system. In addition, *Eldes Utility* indicates a timer of the last Test Time signal delivered by a paired and unpaired wireless device. The software will also warn you if the delivery of the Test Time signal is delayed for a time period that is 5 minutes longer than the Test Time period of a paired wireless device. In case the Test Time signal delivery of an unpaired wireless device is delayed for more than 1,5 minute, a warning will follow and the icon of such wireless device will be removed from the software's interface in 10 seconds.

Manage Grade2 wireless communication settings

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

**Disable wireless
signal loss/restore
notification**

EKB2

Menu path:

User phone number: OK → iiiii → OK → SMS MESSAGES 2 → OK → WLESS SIGN LOSS EV → OK
→ 2G/4G USER 1... 10 → OK → DISABLE → OK
SMS text message to all users simultaneously: ... → WLESS SIGN LOSS EV → OK → SMS TO ALL →
OK → DISABLE → OK
SMS delivery report: ... → WLESS SIGN LOSS EV → OK → SMS REPORT → OK → DISABLE → OK
Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: 25 18 up 0 #
SMS text message to all users simultaneously: 21 18 0 #
SMS delivery report: 55 18 0 #
Value: up - user phone number slot, range - [01... 10].
Example: 2518030#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Enable wireless
signal loss/restore
notification**

EKB2

Menu path:

User phone number: OK → iiiii → OK → SMS MESSAGES 2 → OK → WLESS SIGN LOSS EV → OK
→ 2G/4G USER 1... 10 → OK → ENABLE → OK
SMS text message to all users simultaneously: ... → WLESS SIGN LOSS EV → OK → SMS TO ALL
→ OK → ENABLE → OK
SMS delivery report: ... → WLESS SIGN LOSS EV → OK → SMS REPORT → OK → ENABLE → OK
Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: 25 18 up 1 #
SMS text message to all users simultaneously: 21 18 1 #
SMS delivery report: 55 18 1 #
Value: up - user phone number slot, range - [01... 10].
Example: 2518031#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Enable wireless
communication failed
notification**

EKB2

Menu path:

User phone number: OK → iiiii → OK → SMS MESSAGES 2 → OK → WRLESS FAIL 20MIN. → OK
→ 2G/4G USER 1... 10 → OK → ENABLE → OK
SMS text message to all users simultaneously: ... → WRLESS FAIL 20MIN. → OK → SMS TO ALL
→ OK → ENABLE → OK
SMS delivery report: ... → WRLESS FAIL 20MIN. → OK → SMS REPORT → OK → ENABLE → OK
Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: 25 25 up 1 #
SMS text message to all users simultaneously: 21 25 1 #
SMS delivery report: 55 25 1 #
Value: up - user phone number slot, range - [01... 10].
Example: 2525031#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Disable wireless communication failed notification

EKB2

Menu path:

User phone number: OK → iiiii → OK → SMS MESSAGES 2 → OK → WRLESS FAIL 20MIN. → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK
SMS text message to all users simultaneously: ... → WRLESS FAIL 20MIN. → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → WRLESS FAIL 20MIN. → OK → SMS REPORT → OK → DISABLE → OK

Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EWBK4/**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: 25 25 up 0 #

SMS text message to all users simultaneously: 21 25 0 #

SMS delivery report: 55 25 0 #

Value: up - user phone number slot, range - [01... 10].

Example: 252530#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: Once a certain tamper is disabled, the system will NOT deliver any SMS text message regarding the physical tamper violation nor wireless signal loss or restore. For more details on how to manage the tampers, please refer to **16. TAMPERS**.

ATTENTION: The system will NOT deliver any text message regarding wireless signal loss or restore while the physical tamper violation is in progress.

19.4. Disabling and Enabling Siren if Wireless Signal is Lost

If a wireless device loses its wireless signal for 4-hour (by default) or longer, the system will send notification by SMS text message to user phone number and activate the siren/bell. By default, the siren will not be activated when wireless signal is lost. To enable/disable this feature, please refer to the following configuration methods.

Enable Siren if Wireless Signal is Lost

EKB2

Menu path:
OK → **iiii** → OK → PRIMARY SETTINGS → OK → SIREN SETTINGS →OK → SRN IF WLESS LOSS → OK → **ENABLE** → OK
Value: *iiii* - 4-digit installer code.

EKB3/
EKB3W/
EWKB4

Enter parameter 76 and parameter status value:
76 1 #
Example: 761#

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Disable Siren if Wireless Signal is Lost

EKB2

Menu path:
OK → **iiii** → OK → PRIMARY SETTINGS → OK → SIREN SETTINGS →OK → SRN IF WLESS LOSS → OK → **DISABLE** → OK
Value: *iiii* - 4-digit installer code.

EKB3/
EKB3W/
EWKB4

Enter parameter 76 and parameter status value:
76 0 #
Example: 760#

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.






19.5. EKB3W/EWKB4 - Wireless LED Keypad

Main features:

- Alarm system arming and disarming (see 12.5. EKB3W/EWKB4 Keypad and User/Master Code).
- Arming and disarming in Stay mode (see 15. STAY MODE).
- System parameter configuration (see 5. CONFIGURATION METHODS).
- PGM output control (see 18.4. Turning PGM Outputs ON and OFF).
- Visual indication by LED indicators (see 19.5.1. LED Functionality).
- Audio indication by built-in buzzer.
- Keypad partition switch (see 23.3. Keypad Partition and Keypad Partition Switch).


For more details on technical specifications and installation, please refer to the latest user manual of the device located at www.eldesalarms.com

19.5.1. LED Functionality

	INDICATION	DESCRIPTION
 (red)	Steady ON	System armed / exit delay in progress
	Flashing	Configuration mode activated
 (green)	Steady ON	System is ready - no violated zones and/or violated tampers exist
 (orange)	Steady ON	System faults exist
	Flashing	Violated high-numbered zone
 (orange)	Steady ON	Violated zone bypassed
 1-12 (red)	Steady ON	Zone violated / configuration command being typed in

19.5.2. Keys Functionality

	DESCRIPTION
	1st character for STAY-arming
	1st character for violated zone bypass and bypassed zone activation
	1st character for Configuration mode activation or deactivation
	1st character for system fault list indication / 1st character for violated high-numbered zone indication / 1st character for violated tamper indication
0 - 9	Command typing
1 - 4	Keypad partition switch
*	Clear typed in characters
#	Typed in command confirmation



19.5.3. Wireless Communication, Sleep Mode and Back-light Timeout

Once the wireless device is paired, it will attempt to exchange data with ESIM484 system. The communication process follows this pattern:

- Due to battery power saving reasons, most of the time EKB3W/EWKB4 keypad operates in sleep mode and periodically wakes up (by default - every 5 minutes) to transmit the supervision signal, identified as Test Time, to the ESIM484 system. However, when the keypad wakes up, it will NOT activate its buzzer and/or the LED indicators.
- When any EKB3W/EWKB4 key is pressed, the keypad LED indicators and the back-light will activate for a set up period of time (by default - 10 seconds), identified as Back-light Timeout. During the Back-light Timeout, the Test Time will automatically switch to 2 seconds period allowing to indicate system alarms, faults and arm/disarm process on the EKB3W/EWKB4 keypad if it is assigned to the same partition as the one that is violated or being armed/disarmed (see **23. PARTITIONS**).
- The Back-light timeout will expire after 10 seconds (by default) of EKB3W/EWKB4 idling. When the Back-light Timeout expires, the keypad will light OFF the LED indicators and the back-light and return to sleep mode. Meanwhile:
 - if a zone or tamper, which is of the associated EKB3W/EWKB4 keypad, is violated, EKB3W/EWKB4 will instantly wake up and initiate the Back-light Timeout. Meanwhile the keypad buzzer will emit short beeps and the LED indicators will light ON indicating the violated zone or tamper number.
 - if a zone or tamper, which is not of the associated EKB3W/EWKB4 keypad, is violated, EKB3W/EWKB4 keypad will NOT wake up and will NOT initiate the Back-light Timeout as well as the buzzer will NOT emit short beeps and the LED indicators will NOT light ON.

To set a different Back-light Timeout value, please refer to the following configuration method:

Set Back-light Timeout

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

For more details and how to set a different Test Time value, please refer to *Eldes Utility*.

NOTE: By default, the keypad zone and tamper is enabled, therefore a resistor supplied with the EKB3W/EWKB4 keypad must be connected to the keypad zone terminal and the tamper switch must be properly pressed in when inserting the keypad into the holder.


NOTE: To wake up the keypad it is highly recommended to press the [*] key in order not to enter any unnecessary character. If other character is pressed it is already counted in characters sequence meant for arming/disarming or configuration.

19.6. EWF1/EWF1CO - Wireless Smoke/CO Detector

Main features:

- Photoelectric sensor for slow smouldering fires
- Photoelectric Co sensor for slow smouldering fires and carbon monoxide (CO) gas detection
- TEST button
- Non-radioactive technology for environmental friendly
- High and stable sensitivity
- Quick fix mounting plate for easy installation
- LED operation indicator
- Built-in speaker for audio alarm indication
- Auto-reset when smoke/CO clears

For more details on technical specifications and installation, please refer to the latest user manual of the device located at www.eldesalarms.com



19.6.1. Interconnection

The interconnection feature automatically links all wireless smoke/CO detectors that are paired with the alarm system. When any EWF1/EWF1CO detects smoke or carbon monoxide (CO), it will sound the built-in siren and send the signal to the alarm system resulting in an instant alarm followed by built-in siren sound caused by the rest of EWF1/EWF1CO wireless smoke/CO detectors. EWF1/EWF1CO device that detected smoke/CO will auto-reset when the smoke/CO clears, while the rest of EWF1/EWF1CO smoke/CO detectors will continue to sound in accordance with the set time period (by default - 30 seconds).

By default, the interconnection feature is enabled and the siren alarm duration is 30 seconds. To manage these parameters, please refer to the following configuration methods.

Disable interconnection

EKB2	<p>Menu path: OK → iiii → OK → PRIMARY SETT INGS → OK → SIREN SETTINGS → OK → EWF1 SIREN INTERC. → OK → DISABLE → OK</p> <p>Value: iiii - 4-digit installer code.</p>
EKB3/ EKB3W/ EKB4	<p>Enter parameter 50 and parameter status value: 500 #</p> <p>Example: 500#</p>
Eldes Utility	<p>This operation may be carried out from the PC using the <i>Eldes Utility</i>.</p>

Enable interconnection

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETTINGS → OK → SIREN SETTINGS → OK → EWF1 SIREN INTERC. → OK → ENABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 50 and parameter status value:

501#

Example: 501#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Set EWF1/EWF1CO siren alarm duration


**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: The maximum supported EWF1/EWF1CO siren alarm duration is 255 seconds (4 mins. 15 secs.) even if the system's alarm duration value is longer.

NOTE: System's alarm duration has a higher priority against the EWF1/EWF1CO siren alarm duration, therefore EWF1/EWF1CO will sound as long as the system's alarm duration set up, unless the set up value for EWF1/EWF1CO siren alarm duration is shorter.

19.7. EW2 - Wireless Zone and PGM Output Expansion Module



Main features:


- 4 zone terminals.
- 2 open-collector outputs.
- Battery or externally-powered.
- Compatible with any third-party wired sensor or siren.

EW2 is a wireless device intended to expand ELDES alarm system capabilities by providing wireless connection access to any third-party wired devices. EW2 comes equipped with 4 zone terminals designed for wired digital sensor connection, such as magnetic door contact, motion detector etc. In addition, the 2 open-collector outputs on board allow to connect any wired siren as well as to connect and control any electrical appliance, such as gates, lights, watering etc. The device can operate by powering it either using an external power supply or 3 x 1,5V AA type alkaline batteries on board. Once the external power supply is disconnected, EW2 will automatically switch to battery power.

The maximum number of EW2 devices that can be paired with the system depends on the number of the existing zones in system's configuration. In case no keypad zones, no EPGM1 zones, no virtual zones and no other wireless zones exist, the system will support up to 16 EW2 devices.

For more details on technical specifications and installation, please refer to the latest user manual of the device located at www.eldesalarms.com

19.8. EWM1 - Wireless Power Socket



Main features:

- Control your household equipment remotely by wireless key fob, keypad, ELDES Cloud Services or automatically by scheduled time or system event
- Compatible with any 230V electrical appliance
- View real-time, daily and monthly power consumption report
- Fault indication and protection: circuit thermal, overvoltage, over-current, undervoltage, relay fault indication.

EWM1 is a wireless device intended to expand ELDES alarm system capabilities by providing a wireless connection access to any 230V electrical appliance, such as lights, air-conditioner, watering equipment etc. By plugging the appliance into the electrical outlet of EWM1, the user gains a possibility to control it by wireless key fob, keypad, scheduled time or a specific system event. In addition, EWM1 lets you monitor the power consumption and view the reports. In addition, the for safety and protection purposes EWM1 will prevent from powering up the electrical appliance if certain fault conditions are present (see **29. INDICATION OF SYSTEM FAULTS**) In order to start using EWM1, it has to be paired with ELDES alarm system using *Eldes Utility* or by sending a corresponding SMS text message to ELDES alarm system.

It is possible to pair up to 32 EWM1 devices with the ESIM484 system at a time.

The maximum wireless connection range is 150m (492.13ft) (in open areas).

For more on technical specifications and installation, please refer to the user manual of the device located at: www.eldesalarms.com

To monitor real-time power consumption value, view today's or monthly power consumption reports or reset the power consumption counter, please refer to the following configuration methods.

View power consumption reports

SMS

SMS text message content:
ssss EWM1INFO
Value: ssss - 4-digit SMS password.
Example: 1111 EWM1INFO

EKB2

Menu path:

Real-time power consumption: OK → mmmm → OK → PGM OUTPUTS → OK → out-name → OK → REAL TIME ENERGY

Today's power consumption: ... → out-name → OK → TODAY ENERGY

Monthly power consumption: ... → out-name → OK → MONTHLY ENERGY

Value: mmmm - 4-digit master code; out-name - PGM output name associated with a certain EWM1 device.

Reset power consumption counter for individual EWM1 device

SMS

SMS text message content:

ssss EWM1RESET:out-name

Value: ssss - 4-digit SMS password; out-name - PGM output name associated with a certain EWM1 device.

Example: 1111 EWM1RESET:Controll14

EKB2

Menu path:

OK → mmmm → OK → PGM OUTPUTS → OK → out-name → OK → RESET COUNTER → OK → YES → OK

Value: mmmm - 4-digit master code; out-name - PGM output name associated with a certain EWM1 device.

Reset power consumption counter for all EWM1 devices simultaneously

SMS

SMS text message content:

ssss EWM1RESET:ALL

Value: ssss - 4-digit SMS password.

Example: 1111 EWM1RESET:ALL

NOTE: Real-time power consumption value is NOT included in the power consumption report requested by SMS text message and can only be seen on Eldes Cloud.

20. WIRED SIREN/BELL

When the system is in alarm state, the siren/bell will sound until the set time (by default - 1 minute) expires or until the system is disarmed. To set the alarm duration, please refer to the following configuration methods.

Set alarm duration

SMS

SMS text message content:

ssss SIREN:t

Value: ssss - 4-digit SMS password; t - alarm duration, range - [0... 5] minutes.

Example: 1111 SIREN:4

EKB2

Menu path:

OK → iiiii → OK → PRIMARY SETT INGS → OK → SIREN SETTINGS → OK → ALARM DURATION → OK → tt → OK

Value: iiiii - 4-digit installer code; tt - alarm duration, range - [1... 10] minutes.

EKB3/
EKB3W/
EKB4

Enter parameter 10 and alarm duration:

10 tt #

Value: tt - alarm duration, range - [00... 10] minutes.

Example: 1007#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

View alarm duration

SMS

SMS text message content:

ssss SIREN

Value: ssss - 4-digit SMS password

Example: 1111 SIREN

EKB2

Menu path:

OK → iiiii → OK → PRIMARY SETT INGS → OK → SIREN SETTINGS → OK → ALARM DURATION

Value: iiiii - 4-digit installer code.

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

For siren/bell wiring diagram, please refer to **2.3.3. Siren**.

NOTE: The maximum supported alarm duration is 30 minutes that can be set up using *Eldes Utility* only. "0" value disables the siren/bell.

NOTE: Due to battery power saving reasons, the wireless siren will sound for up to 6 minutes max. regardless of the set up alarm duration value when it is longer than 6 minutes

20.1. BELL Output Status Monitoring

The system constantly supervises the BELL output. If the siren/bell is disconnected/cut-off, the system may send the notification by SMS text message (by default - disabled) to the listed user phone number and indicate system fault condition on the keypad (see **29. INDICATION OF SYSTEM FAULTS**). Once the bell/siren is connected/fixed, the system may notify the listed user by SMS text message (by default - disabled) and the keypad will no longer indicate system fault. Please, note that in order to use this feature, the resistors must be connected to BELL output. Resistors must be connected to BELL output to meet the monitored resistance value of 1k0hm-2.2k0hm if the siren itself does not have this resistance (see **2.3.3. Siren**).

By default, the notification by SMS text message regarding the BELL output status is disabled. To enable/disable this notification, please refer to the following configuration methods.

Enable Siren Fail/ Restore notification

EKB2

Menu path:

User phone number: **OK → iiiii → OK → SMS MESSAGES 1 → OK → SIREN FAIL/REST EV → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK**

SMS text message to all users simultaneously: **... → SIREN FAIL/REST EV → OK → SMS TO ALL → OK → ENABLE → OK**

SMS delivery report: **... → SIREN FAIL/REST EV → OK → SMS REPORT → OK → ENABLE → OK**

Value: *iiii* - 4-digit installer code.

EKB3/
EKB3W/
EWKB4

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 08 up 1 #**

SMS text message to all users simultaneously: **21 08 1 #**

SMS delivery report: **55 08 1 #**

Value: *up* - user phone number slot, range - [01... 10].

Example: 2508021#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Disable Siren Fail/ Restore notification

EKB2

Menu path:

User phone number: **OK → iiiii → OK → SMS MESSAGES 1 → OK → SIREN FAIL/REST EV → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK**

SMS text message to all users simultaneously: **... → SIREN FAIL/REST EV → OK → SMS TO ALL → OK → DISABLE → OK**

SMS delivery report: **... → SIREN FAIL/REST EV → OK → SMS REPORT → OK → DISABLE → OK**

Value: *iiii* - 4-digit installer code.

EKB3/
EKB3W/
EWKB4

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 08 up 0 #**

SMS text message to all users simultaneously: **21 08 0 #**

SMS delivery report: **55 08 50 #**

Value: *up* - user phone number slot, range - [01... 10].

Example: 2508040#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

For more details on how *Send SMS text message to all users simultaneously* and *SMS Cascade* parameters affect the SMS text message transmission, please refer to **27. SYSTEM NOTIFICATIONS**.

20.2. Bell Squawk

If enabled, the siren/bell indicates the completed system arming and disarming process. After the system is successfully armed, the siren/bell will emit 2 short beeps and 1 long beep after the system is disarmed. To enable/disable the Bell Squawk feature, please refer to the following configuration methods. **NOTE:** wireless siren **always** emits 3 beeps regardless of arming or disarming was done.

Enable Bell Squawk

EKB2

Menu path:

OK → iiiii → OK → PRIMARY SETTINGS → OK → SIREN SETTINGS → OK → BELL SQUAWK → OK → ENABLE → OK

Value: *iiii* - 4-digit installer code.

Disable Bell Squawk

**EKB3/
EKB3W/
EWKB4**

Enter parameter 29 and parameter status value:

29 1 #

Example: 291#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETT INGS → OK → SIREN SETTINGS → OK → BELL SQUAWK → OK
→ DISABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 29 and parameter status value:

29 0 #

Example: 290#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

20.3. Bell Squawk in Stay Mode

If enabled, the Bell Squawk will be available when arming/disarming the system in Stay mode (see **15. STAY MODE**). To enable/disable this feature, please refer to the following configuration methods

Enable Bell Squawk in Stay Mode

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETT INGS → OK → SIREN SETTINGS → OK → BELL SQUAWK STAY
→ OK → ENABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 95 and parameter status value:

95 1 #

Value: 951#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Disable Bell Squawk in Stay Mode

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETT INGS → OK → SIREN SETTINGS → OK → BELL SQUAWK STAY
→ OK → DISABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 95 and parameter status value:

95 0 #

Value: 950#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

20.4. Indication by EWS2 - Wireless Outdoor Siren Indicators

When enabled, the built-in LED indicators of EWS2 wireless outdoor siren will flash during the alarm. To enable/disable this feature, please refer to the following configuration methods.

Enable EWS2 LED indication

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETT INGS → OK → SIREN SETTINGS → OK → EWS2 LED → OK → **ENABLE** → OK

Value: *iiii* - 4-digit installer code.

EKB3/
EKB3W/
EWS2

Enter parameter 88 and parameter status value:

88 1 #

Example: *881#*

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Disable EWS2 LED indication

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETT INGS → OK → SIREN SETTINGS → OK → EWS2 LED → OK → **DISABLE** → OK

Value: *iiii* - 4-digit installer code.

EKB3/
EKB3W/
EWS2

Enter parameter 88 and parameter status value:

88 0 #

Example: *880#*

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

20.5. Indication by EWS3 - Wireless Indoor Siren Indicators

When enabled, the built-in LED indicators of EWS3 wireless indoor siren will flash during the alarm. In the event of burglary, 24-hour or tamper alarm, EWS3 will flash the blue LED indicators, while in case of a fire alarm, the device can flash the red LED indicator. To enable/disable these features, please refer to the following configuration methods.

Enable EWS3 LED indication

EKB2

Menu path:
Burglary/24-hour/tamper alarm LED: OK → **iiii** → OK → PRIMARY SETT INGS → OK → SIREN SETTINGS → OK → EWS3 ALARM LED → OK → **ENABLE** → OK
Fire alarm LED: ... → SIREN SETTINGS → OK → EWS3 FIRE LED → OK → **ENABLE** → OK
Value: *iiii* - 4-digit installer code.

EKB3/
EKB3W/
EWS3

Enter parameter 94/93 and parameter status value:
Burglary/24-hour/tamper alarm LED: **94 1 #**
Fire alarm LED: **93 1 #**
Example: 931#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Disable EWS3 LED indication

EKB2

Menu path:
Burglary/24-hour/tamper alarm LED: OK → **iiii** → OK → PRIMARY SETT INGS → OK → SIREN SETTINGS → OK → EWS3 ALARM LED → OK → **DISABLE** → OK
Fire alarm LED: ... → SIREN SETTINGS → OK → EWS3 FIRE LED → OK → **DISABLE** → OK
Value: *iiii* - 4-digit installer code.

EKB3/
EKB3W/
EWS3

Enter parameter 94/93 and parameter status value:
Burglary/24-hour/tamper alarm LED: **94 0 #**
Fire alarm LED: **93 0 #**
Example: 940#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

21. BACKUP BATTERY, MAINS POWER STATUS MONITORING AND MEMORY

21.1. Backup Battery Status Monitoring

The system may come equipped with a backup battery maintaining power supply of the system when the mains power is temporally lost. The implemented feature allows the system to perform a self-test on the backup battery and notify the user by SMS text message as well as to indicate system fault by the keypad (see **29. INDICATION OF SYSTEM FAULTS**) if:

- battery has failed and requires replacement - battery resistance is 2Ω or higher; self-tested every 24 hours.
- battery is dead or missing - battery is not present or battery voltage is below 5V; self-tested every 1 minute.
- battery power is running low - battery voltage is 10.5V or lower; constantly self-tested.

By default, all notifications regarding the backup battery status are enabled. To disable/enable a determined backup battery notification, please refer to the following configuration methods.

Disable Battery Failed notification

EKB2

Menu path:

User phone number: OK → iii → OK → SMS MESSAGES 1 → OK → BATTERY FAILED → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → BATTERY FAILED → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → BATTERY FAILED → OK → SMS REPORT → OK → DISABLE → OK

Value: iii - 4-digit installer code.

EKB3/
EKB3W/
EKB4

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: 25 05 up 0 #

SMS text message to all users simultaneously: 21 05 0 #

SMS delivery report: 55 05 0 #

Value: up - user phone number slot, range - {01... 10}.

Example: 2105010#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Enable Battery Failed notification

EKB2

Menu path:

User phone number: OK → iii → OK → SMS MESSAGES 1 → OK → BATTERY FAILED → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → BATTERY FAILED → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → BATTERY FAILED → OK → SMS REPORT → OK → ENABLE → OK

Value: iii - 4-digit installer code.

EKB3/
EKB3W/
EKB4

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: 25 05 up 1 #

SMS text message to all users simultaneously: 21 05 1 #

SMS delivery report: 55 05 1 #

Value: up - user phone number slot, range - {01... 10}.

Example: 2505031#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Disable Battery Dead or Missing notification

EKB2

Menu path:

User phone number: OK → iii → OK → SMS MESSAGES 1 → OK → BATTERY DEAD/MISS → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → BATTERY DEAD/MISS → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → BATTERY DEAD/MISS → OK → SMS REPORT → OK → DISABLE → OK

Value: iii - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 06 up 0 #**

SMS text message to all users simultaneously: **21 06 0 #**

SMS delivery report: **55 06 0 #**

Value: up - user phone number slot, range - [01... 10].

Example: 5506070#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Enable Battery Dead
or Missing notification**

EKB2

Menu path:

User phone number: OK → iiiii → OK → SMS MESSAGES 1 → OK → BATTERY DEAD/MISS → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → BATTERY DEAD/MISS → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → BATTERY DEAD/MISS → OK → SMS REPORT → OK → ENABLE → OK

Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 06 up 1 #**

SMS text message to all users simultaneously: **21 06 1 #**

SMS delivery report: **55 06 1 #**

Value: up - user phone number slot, range - [01... 10].

Example: 5506101#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Disable Low Battery
notification**

EKB2

Menu path:

User phone number: OK → iiiii → OK → SMS MESSAGES 1 → OK → LOW BATTERY → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → LOW BATTERY → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → LOW BATTERY → OK → SMS REPORT → OK → DISABLE → OK

Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 07 up 0 #**

SMS text message to all users simultaneously: **21 07 0 #**

SMS delivery report: **55 07 0 #**

Value: up - user phone number slot, range - [01... 10].

Example: 2107100#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Enable Low Battery
notification**

EKB2

Menu path:

User phone number: OK → iiiii → OK → SMS MESSAGES 1 → OK → LOW BATTERY → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → LOW BATTERY → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → LOW BATTERY → OK → SMS REPORT → OK → ENABLE → OK

Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 07 up 1 #**

SMS text message to all users simultaneously: **21 07 1 #**

SMS delivery report: **55 07 1 #**

Value: up - user phone number slot, range - [01... 10].

Example: 2107021#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

For more details on how *Send SMS text message to all users simultaneously* and *SMS Cascade* parameters affect the SMS text message transmission, please refer to **27. SYSTEM NOTIFICATIONS**.

NOTE: In order to view the backup battery voltage, resistance, please refer to Diagnostic Management feature available on *Eldes Utility*.

21.2. Mains Power Status Monitoring

If the household electricity is unstable in the system installation area, the system may temporally lose its power supply and continue operating on the backup battery power. The system supervises the mains power and notifies the user by SMS text message as well as indicates system fault condition on the keypad (see **29. INDICATION OF SYSTEM FAULTS**) when the mains power is lost. When the mains power restores, the system will notify the user by SMS text message and the keypad will no longer indicate system fault.

By default, system notification by SMS text message regarding mains power status is enabled. To disable/enable this notification, please refer to the following configuration methods.

**Disable mains
power loss/restore
notification**

EKB2

Menu path:

User phone number: **OK → iii → OK → SMS MESSAGES 1 → OK → MAIN POWER L/R → OK → 2G/4G USER 1... 10 → OK → DISBLE → OK**

SMS text message to all users simultaneously: **... → MAIN POWER L/R → OK → SMS TO ALL → OK → DISABLE → OK**

SMS delivery report: **... → MAIN POWER L/R → OK → SMS REPORT → OK → DISABLE → OK**

Value: iii - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 04 up 0 #**

SMS text message to all users simultaneously: **21 04 0 #**

SMS delivery report: **55 04 0 #**

Value: up - user phone number slot, range - [01... 10].

Example: 2504050#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Enable mains
power loss/restore
notification**

EKB2

Menu path:

User phone number: **OK → iii → OK → SMS MESSAGES 1 → OK → MAIN POWER L/R → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK**

SMS text message to all users simultaneously: **... → MAIN POWER L/R → OK → SMS TO ALL → OK → ENABLE → OK**

SMS delivery report: **... → MAIN POWER L/R → OK → SMS REPORT → OK → ENABLE → OK**

Value: iii - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 04 up 1 #**

SMS text message to all users simultaneously: **21 04 1 #**

SMS delivery report: **55 04 1 #**

Value: up - user phone number slot, range - [01... 10].

Example: 2514091#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

By default, mains power loss and restore delay are 30 and 120 seconds respectively. To set a different mains power loss and restore delay duration, please refer to the following configuration methods.

Set mains power loss delay

EKB2

Menu path:

OK → iii → OK → PRIMARY SETT INGS → OK → MAIN POWER STATUS → OK → LOSS DELAY → OK → IIIII → OK

Value: *iiii* - 4-digit installer code; *IIII* - mains power loss delay duration, range - [0... 65535] seconds.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 70 and loss delay duration:

70 IIIII #

Value: *IIII* - mains power loss delay duration, range - [0... 65535] seconds.

Example: 7043#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Set mains power restore delay

EKB2

Menu path:

OK → IIIII → OK → PRIMARY SETT INGS → OK → MAIN POWER STATUS → OK → RESTORE DELAY → OK → rrrrr → OK

Value: *iiii* - 4-digit installer code; *rrrrr* - mains power restore delay duration, range - [0... 65535] seconds.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 71 and restore delay duration:

71 rrrrr #

Value: *rrrrr* - mains power restore delay duration, range - [0... 65535] seconds.

Example: 71150#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

For more details on how *Send SMS text message to all users simultaneously* and *SMS Cascade* parameters affect the SMS text message transmission, please refer to **27. SYSTEM NOTIFICATIONS**.

21.3. Memory

The configuration settings and event log records are stored in a built-in memory, therefore even if the system is fully shut down, the configuration and event log remain. For more details regarding the event log, please refer to **28. EVENT AND ALARM LOG**.

22. 2G/4G CONNECTION AND ANTENNA STATUS MONITORING

22.1. 2G/4G Connection Status Monitoring

The system supervises the 2G/4G connection every 10 minutes. When the 2G/4G connection loss is detected, the system indicator NETW will light OFF and the system will attempt to restore the 2G/4G connection. In case the system fails to restore the 2G/4G connection within a 3-minute period (by default), the keypad will indicate the system fault condition (see **29. INDICATION OF SYSTEM FAULTS**) and the system will continue the attempt to restore the 2G/4G connection. In addition, the system may turn ON a determined PGM output to indicate the 2G/4G connection loss fault (by default - disabled).

Once the 2G/4G signal restores, the system may notify the listed user by SMS text message (by default - disabled), the keypad will no longer indicate system fault and the determined PGM output will turn OFF (if set up).

By default, the notifications by SMS text message regarding 2G/4G signal loss is disabled. To enable/disable this notification, please refer to the following configuration methods.

Enable 2G/4G Connection Failed notification

EKB2

Menu path:

User phone number: OK → **iiii** → OK → SMS MESSAGES 2 → OK → 2G/4G CONNECT FAILED → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → 2G/4G CONNECT FAILED → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → 2G/4G CONNECT FAILED → OK → SMS REPORT → OK → ENABLE → OK

Value: **iiii** - 4-digit installer code.

EKB3/
EKB3W/
EWKB4

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 11 up 1 #**

SMS text message to all users simultaneously: **21 11 1 #**

SMS delivery report: **55 11 1 #**

Value: **up** - user phone number slot, range - [01... 10].

Example: 21111#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Disable 2G/4G Connection Failed notification

EKB2

Menu path:

User phone number: OK → **iiii** → OK → SMS MESSAGES 2 → OK → 2G/4G CONNECT FAILED → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → 2G/4G CONNECT FAILED → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → 2G/4G CONNECT FAILED → OK → SMS REPORT → OK → DISABLE → OK

Value: **iiii** - 4-digit installer code.

EKB3/
EKB3W/
EWKB4

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 11 up 0 #**

SMS text message to all users simultaneously: **21 11 0 #**

SMS delivery report: **55 11 0 #**

Value: **up** - user phone number slot, range - [01... 10].

Example: 2511020#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Manage 2G/4G signal loss indication by PGM output

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

By default, the PGM output for 2G/4G signal loss indication is not set. To set the PGM output and delay duration for 2G/4G signal loss indication, please refer to the following configuration method.

For more details on how *Send SMS text message to all users simultaneously* and *SMS Cascade* parameters affect the SMS text message transmission, please refer to **27. SYSTEM NOTIFICATIONS**.

22.2. 2G/4G antenna Status Monitoring

The system constantly monitors the 2G/4G antenna status. If the 2G/4G antenna is disconnected/cut-off, the system may send notification by SMS text message (by default - disabled) to the listed user and the keypad will indicate system fault condition (see **29. INDICATION OF SYSTEM FAULTS**). Once the antenna is connected/fixed, the system may notify the user by SMS text message (by default - disabled) and the keypad will no longer indicate system fault.

By default, the notification by SMS text message regarding the 2G/4G antenna status is disabled. To enable/disable this notification, please refer to the following configuration methods.

Enable 2G/4G Antenna Fail/Restore notification

EKB2

Menu path:

User phone number: **OK → iiiii → OK → SMS MESSAGES 2 → OK → 2G/4G ANT FAIL/REST → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK**

SMS text message to all users simultaneously: **... → 2G/4G ANT FAIL/REST → OK → SMS TO ALL → OK → ENABLE → OK**

SMS delivery report: **... → 2G/4G ANT FAIL/REST → OK → SMS REPORT → OK → ENABLE → OK**

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 12 up 1 #**

SMS text message to all users simultaneously: **21 12 1 #**

SMS delivery report: **55 12 1 #**

Value: *up* - user phone number slot, range - [01... 10].

Example: 2512031#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Disable 2G/4G Antenna Fail/Restore notification

EKB2

Menu path:

User phone number: **OK → iiiii → OK → SMS MESSAGES 2 → OK → 2G/4G ANT FAIL/REST → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK**

SMS text message to all users simultaneously: **... → 2G/4G ANT FAIL/REST → OK → SMS TO ALL → OK → DISABLE → OK**

SMS delivery report: **... → 2G/4G ANT FAIL/REST → OK → SMS REPORT → OK → DISABLE → OK**

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

User phone number: **25 12 up 0 #**

SMS text message to all users simultaneously: **21 12 0 #**

SMS delivery report: **55 12 0 #**

Value: *up* - user phone number slot, range - [01... 10].

Example: 2512030#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

For more details on how *Send SMS text message to all users simultaneously* and *SMS Cascade* parameters affect the SMS text message transmission, please refer to **27. SYSTEM NOTIFICATIONS**.

23. PARTITIONS

ESIM484 system comes equipped with a partitioning feature that can divide the alarm system into four independently controlled areas identified as Partition 1 through 4, which are all supervised by one alarm system unit. Partitioning can be used in installations where shared alarm system is more practical, such as a house and a garage or within a single multi-storey building. When partitioned, each system element, like zone, user phone number, keypad, user/master code, iButton key and wireless key fob can be assigned to single or multiple partitions. The user will then be able to arm/disarm the system partition (-s) that the zones and arm/disarm method are assigned to. The following table reflects the values used for system element assignment to partitions when configuring via EKB2/EKB3/EKB3W/EWKB4 keypad. A sum of values is used to assign the element to multiple partitions.

Partition	Value
Partition 1	1
Partition 2	2
Partition 3	4
Partition 4	8

Example1: The user wants to assign a certain iButton key to Partition 4 only. According to the table value 8 reflects Partition 4. He would then have to enter value 8.

Example2: The user wants to assign a certain user code to Partition 2 and 3. According to the table value 2 reflects Partition 2, while value 4 reflects Partition 3, therefore 2 + 4 = 6. He would then have to enter value 6.

Example3: The user wants to assign a certain zone to Partition 1, 3 and 4. According to the table value 1 reflects Partition 1, while values 4 and 8 reflect Partitions 3 and 4 respectively, therefore 1 + 4 + 8 = 13. He would then have to enter value 13.

23.1. Zone Partition

Zone partition determines which system partition (-s) the zone will operate in.

Set zone partition

EKB2

Menu path:
On-board zone: OK → iiiii → OK → ZONES → OK → ONBOARD ZONES → OK → ZONE 1... 16 → OK → PARTITION → OK → pv → OK
Wireless zone: ... → WIRELESS ZONE 17... 144 → OK → PARTITION → OK → pv → OK
Keypad zone: ... → KEYPAD ZONES → OK → 1ST... 4TH KEYPAD ZONE → OK → PARTITION → OK → pv → OK
EPGM1 zone: ... → EPGM1 ZONES 1-16... EPGM1 ZONES 17-32 → OK → EPGM1 ZONE 1... 32 → OK → PARTITION → OK → pv → OK
Value: iiiii - 4-digit installer code; pv - partition value, range - [1... 15] (see 23. PARTITIONS).

**EKB3/
EKB3W/
EWKB4**

Enter parameter 57, zone number and partition value:
57 nn pv #
Value: nn - zone number, range - [01... 144]; pv - partition value, range - [1... 15].
Example: 57032#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: Wireless siren EWS2/EWS3 siren will sound only if wireless zone of the siren is assigned to the same partition as the one that has been alarmed.

23.2. User Phone Number Partition

User phone number partition determines which system partition (-s) can be armed/disarmed from a certain user phone number by dialing system's phone number or sending an SMS text message.

Set user phone number partition

EKB2

Menu path:
OK → iiiii → OK → PRIMARY SETTINGS → OK → CALL/SMS SETTINGS → OK → USERS → OK → 2G/4G USER 1... 10 → OK → PARTITION → pv → OK
Value: iiiii - 4-digit installer code; pv - partition value, range - [01... 15].

**EKB3/
EKB3W/
EWKB4**

Enter parameter 59, user phone number slot and partition value:
59 us pv #
Value: us - user phone number slot, range - [01... 10]; pv - partition value, range - [01... 15].
Example: 591013#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

23.3. Keypad Partition and Keypad Partition Switch

Keypad partition determines which system partition the keypad will operate in. To identify which partition the keypad is operating in:

- **EKB2** – Refer to partition name (by default – PART1) indicated in home screen view.
 - **EKB3W/EWKB4/EKB3** (2-partition mode) – Refer to the location of the illuminated indicator ✓ on the keypad. The indicator will be illuminated under section A or B, which represent Partition 1 and Partition 2 respectively.
- EKB3 keypad can operate in the following modes:
- **2-partition mode** – This parameter determines whether EKB3 keypad can operate only in one of the first two system partitions allowing to arm/disarm them and switch the keypad partition using [1]... [2] keys. This mode is set up by default.
 - **4-partition mode** – This parameter determines whether EKB3 keypad can operate in one of the four system partitions allowing to arm/disarm them, indicate arm/disarm status, partition state (alarmed/not alarmed) on [1]... [4] keys (see **32.1.2. EKB3 - LED Keypad**) and switch the keypad partition using [1]... [4] keys.

The keypad must be assigned to the same partition as the user/master code (see **23.4. User/Master Code Partition**) in order to arm/disarm the system by the keypad. For more details on system arming/disarming by the keypad, please refer to **12.3. EKB2 Keypad and User/Master Code**, **12.4. EKB3 Keypad and User/Master Code** and **12.5. EKB3W/EWKB4 Keypad and User/Master Code**.

Set EKB3 partition mode as 2-partition or 4-partition

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Set keypad partition

EKB2

Menu path:

EKB2 partition: OK → **iiii** → OK → PRIMARY SETTINGS → OK → KEYPAD PARTITION → OK → KEYPAD PARTITION → OK → [k] EKB2 → OK → PARTITION 1... 4 → OK → DISABLE | ENABLE → OK

EKB3 partition: ... → KEYPAD PARTITION → OK → [k] EKB3 → OK → PARTITION 1... 4 → OK

EKB3W partition: ... → KEYPAD PARTITION → OK → EKB3W PARTITION → OK → EKB3W wless-id → OK → PARTITION 1... 2 → OK

EWKB4 partition: ... → KEYPAD PARTITION → OK → EWKB4 PARTITION → OK → EWKB4 wless-id → OK → PARTITION 1... 2 → OK

Value: *iiii* – 4-digit installer code; *k* – keypad slot, range – [1... 4]; *wless-id* – 8-character wireless device ID code.

EKB3/
EKB3W/
EWKB4

Enter parameter 51, keypad slot and partition number:

EKB3 partition: **51 kk p #**

EKB3W/EWKB4 partition: **51 kw r #**

Value: *kk* – EKB3 keypad slot, range – [01... 04]; *kw* – EKB3W/EWKB4 keypad slot, range – [05... 08]; *p* – EKB3 partition number, range – [1... 4]; *r* – EKB3W/EWKB4 partition number, range – [1... 2].

Example: 51062#

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: 4-partition mode must be enabled in order to assign EKB3 keypad to Partition 3 or Partition 4.

NOTE: EKB2 keypad can operate in multiple partitions, while EKB3 keypad can operate only in a single partition.

NOTE: EKB3W/EWKB4 keypad assignment is restricted to Partition 1 and Partition 2.

NOTE: The slots for EKB3W/EWKB4 keypads are automatically assigned to the paired keypad in the chronological order, hence the earliest paired keypad would acquire slot 5, while the latest paired keypad would acquire slot 8.

Keypad partition switch allows to quickly change the EKB3/EKB3W/EWKB4 keypad partition. When the keypad partition is changed and when 1 minute after the last key-stroke expires, the keypad will return to the assigned keypad partition. Typically, this feature is used for viewing arm/disarm status and alarms of a different partition or when arming/disarming a different system partition by EKB3/EKB3W/EWKB4 keypad than the keypad is assigned to.

By default, keypad partition switch is disabled. To enable/disable this feature, please refer to the following configuration methods.

Enable keypad partition switch

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETTINGS → OK → KEYPAD PARTITION → OK → PARTITION SWITCH → OK → **ENABLE** → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 77 and parameter status value:

77 1#

Example: 771#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Disable keypad partition switch

EKB2

Menu path:

OK → **iiii** → OK → PRIMARY SETTINGS → OK → KEYPAD PARTITION → OK → PARTITION SWITCH → OK → **DISABLE** → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 77 and parameter status value:

77 0 #

Example: 770#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: Keypad partition switch can only be used when the system is partitioned.

23.4. User/Master Code Partition

User/master code partition determines which system partition (-s) can be armed/disarm using a certain user/master code. User/master code must be assigned to the same partition as the keypad (see **23.3. Keypad Partition and Keypad Partition Switch**) in order to arm/disarm the system by EKB2/EKB3/EKB3W/EKB4 keypad. For more details on system arming/disarming by the keypad, please refer to **12.3. EKB2 Keypad and User/Master Code**, **12.4. EKB3 Keypad and User/Master Code** and **12.5. EKB3W/EKB4 Keypad and User/Master Code**.

Set user/master code partition

EKB2

Menu path:

Master code: OK → **mmmm** → OK → CODES → OK → MASTER CODE → OK → PARTITION → OK → **pv** → OK

User code 2... 17: ... → CODES → OK → USER CODE (2-17) → OK → USER CODE 2... 17 → OK → PARTITION → OK → **pv** → OK

User code 18... 30: ... → CODES → OK → USER CODE (18-30) → OK → USER CODE 18... 30 → OK → PARTITION → OK → **pv** → OK

Value: *mmmm* - 4-digit master code; *pv* - partition value, range - [01... 15].

**EKB3/
EKB3W/
EKB4**

Press **...**, 5, enter 01/user code slot, partition value and master code:

Master code: **...5 01 pv mmmm #**

User code: **...5 us pv mmmm #**

Value: *us* - user code slot, range - [02... 30]; *pv* - partition value, range - [01... 15]; *mmmm* - 4-digit master code.

Example: ...504081111#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE for EKB3/EKB3W/EKB4: The Configuration mode must be deactivated, while managing user and master code partition.

23.5. iButton Key Partition

iButton key partition determines which system partition (-s) can be armed/disarmed using a certain key. iButton key must be assigned to the partition (-s) that the user desires to arm. For more details on system arming/disarming by iButton key, please refer to **12.6. iButton Key**.

Set iButton key partition

EKB2

Menu path:
OK → *iiii* → OK → IBUTTON KEYS → OK → IBUTTON → OK → IBUTTON 1... 16 → OK → PARTITION → OK → *pv* → OK

Value: *iiii* - 4-digit installer code; *pv* - partition value, range - [1... 15]..

EKB3/
EKB3W/
EKB4

Enter parameter 60, iButton key slot and partition value:
60 is *pv* #

Value: *is* - iButton key slot, range - [01... 16]; *pv* - partition value, range - [1... 15].
Example: 60059#

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

23.6. EWK2 Wireless Key fob Partition

EWK2 wireless key fob partition determines which system partition can be armed/disarmed using a certain EWK2 wireless key fob. For more details on system arming/disarming by EWK2 wireless key fob, please refer to **12.7. EWK2 Wireless Key fob**.

Set EWK2/EWK2A partition

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

24. TEMPERATURE SENSORS

The system may be equipped with on-board temperature sensors and/or wireless devices with built-in temperature sensors intended for temperature measurement in the surrounding areas. This feature allows to monitor the temperature of up to 8 different areas in real-time and receive a notification by SMS text message to the listed user phone number and/or monitoring station's middle-ware when the set temperature thresholds are exceeded. The temperature is measured at 0,5 degree centigrade (°C) accuracy and automatically rounded to the higher value when 0,5 or above, e.g. temperature ranging from 23,5°C through 24,4°C will be treated as 24°C. For this purpose you may use the on-board temperature sensors or the built-in temperature sensor of the following wireless devices:

- EWP2 - wireless motion detector.
- EWKB4 - wireless keypad.
- EWP3 - wireless motion detector.
- EWD2 - wireless magnetic door contact/shock sensor/flood sensor.
- EWD3 - wireless magnetic door contact/shock sensor/flood sensor.
- EWS3 - wireless indoor siren.
- EWS2 - wireless outdoor siren.
- EWF1 - wireless smoke detector.
- EWF1C0 - wireless smoke and CO detector.
- EW2 - wireless zone and PGM output expansion module (an external temperature sensor (-s) must be connected to EW2 for this purpose).

24.1. Adding, Removing and Replacing On-Board Dallas Temperature Sensors

To add a temperature sensor to the system, do the following:

- a) Shut down the system.
- b) Wire up the temperature sensor to the 1-Wire interface terminals (see **2.3.5. Temperature Sensor and iButton Key Reader for temperature sensor wiring diagram**).
- c) Power up the system.
- d) Run *Eldes Utility*, check if the temperature sensor has been recognized by the system and assign it to the desired temperature sensor slot.
- e) If more than one temperature sensor is required, shut down the system again and wire another sensor in parallel to the previous one. By default, the first added temperature sensor will be identified as primary and the second one - as secondary temperature sensor (see **24.2. Primary and Secondary Temperature Sensors**).
- f) Repeat the procedure as mentioned in steps from a) to d).
- g) Add as many temperature sensors as necessary - wire up one after another in parallel - until the number of 8 sensors is reached.

To view the real-time temperature values measured by each temperature sensor, please refer to the following configuration methods.

View real-time temperature values of individual temperature sensor

SMS

SMS text message content:

`ssssITEMP:ts`

Value: `ssss` - 4-digit SMS password; `ts` - temperature sensor slot, range - [1... 8].

Example: `1111ITEMP:4`

EKB2

Menu path:

`OK → uumm → OK → TEMP SENSORS INFO → OK → 1. tm.p C (PRIM) | (SEC)... 8. tm.p C`

Value: `uumm` - 4-digit user/master code; `tm.p` - real-time temperature value.

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

View real-time temperature values of all temperature sensors

SMS

SMS text message content:

`ssssITEMP:?`

Value: `ssss` - 4-digit SMS password.

Example: `1111ITEMP:?`

EKB2

Menu path:

`OK → uumm → OK → TEMP SENSORS INFO → OK → 1. tm.p C (PRIM) | (SEC)... 8. tm.p C`

Value: `uumm` - 4-digit user/master code; `tm.p` - real-time temperature value.

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

If an on-board temperature sensor is faulty, it is recommended to remove it or replace it by a functional sensor. In order to assign the temperature sensor slot of the damaged temperature sensor to the new temperature sensor, please follow the procedure:

- a) Shut down the system.
- b) Disconnect the faulty temperature sensor and replace it with a new one.
- c) Power up the system.
- d) Run *Eldes Utility*.
- e) Select the newly replaced temperature sensor ID from the drop-down list of the temperature sensor slot that was previously associated

with a faulty temperature sensor.

Remove/replace
individual
temperature sensor

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

24.2. Primary and Secondary Temperature Sensors

Any out of 8 available temperature sensors can be set as primary or secondary. The real-time temperature values of the primary and secondary temperature sensors are included in the Info SMS text message (see **26. SYSTEM INFORMATION. INFO SMS**) as well as the temperature measured by the primary temperature sensor is indicated in the home screen view of EKB2 keypad.

To set temperature sensors as primary or secondary, please refer to the following configuration methods.

Set primary
temperature sensor

SMS

SMS text message content:

ssss TEMPI:PRIM:ts

Value: ssss - 4-digit SMS password; ts - temperature sensor slot, range - [1... 8].

Example: 1111 TEMPI:PRIM:4

EKB2

Menu path:

OK → iiii → OK → PRIMARY SETTINGS → OK → TEMP SENSORS → OK → PRIMARY TEMP SENS
→ OK → 1... 8 CONNECTED → OK

Value: iiii - 4-digit installer code.

EKB3/
EKB3W/
EKB4

Enter parameter 89 and temperature sensor slot:

89 ts #

Value: ts - temperature sensor slot, range - [01... 08].

Example: 8903#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Set secondary
temperature sensor

SMS

SMS text message content:

ssss TEMPI:SEC:ts

Value: ssss - 4-digit SMS password; ts - temperature sensor slot, range - [1... 8].

Example: 1111 TEMPI:SEC:3

EKB2

Menu path:

OK → iiii → OK → PRIMARY SETTINGS → OK → TEMP SENSORS → OK → SECOND. TEMP SENS
→ OK → 1... 8 CONNECTED → OK

Value: iiii - 4-digit installer code.

EKB3/
EKB3W/
EKB4

Enter parameter 90 and temperature sensor slot:

90 ts #

Value: ts - temperature sensor slot, range - [01... 08].

Example: 9005#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

To view the slot number of primary and secondary temperature sensors, please refer to the following configuration methods.

View primary and
secondary temperature
sensor slot number

SMS

SMS text message content:

ssss TEMPI:?

Value: ssss - 4-digit SMS password.

Example: 1111 TEMPI:?

View primary and secondary temperature sensor real-time temperature values

EKB2

Menu path:

Primary: OK → uumm → OK → TEMP SENSORS INFO → OK → 1... 8 tm.p C (PRIM)

Secondary: ... → TEMP SENSORS INFO → OK → 1... 8 tm.p C (SEC)

Value: uumm - 4-digit user/master code; tm.p - real-time temperature value.

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

SMS

SMS text message content:

ssss INFO

Value: ssss - 4-digit SMS password.

Example: 1111 INFO

EKB2

Menu path:

Primary: OK → uumm → OK → TEMP SENSORS INFO → OK → 1... 8 tm.p C (PRIM)

Secondary: ... → TEMP SENSORS INFO → OK → 1... 8 tm.p C (SEC)

Value: uumm - 4-digit user/master code; tm.p - real-time temperature value.

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: Primary and secondary temperature sensors can be set by a single SMS text message, **Example:** 1111 TEMPI:PRIM:4,SEC:3

24.3. Setting Up MIN and MAX Temperature Thresholds. Temperature Info SMS

The system supports an SMS text message identified as the Temperature Info SMS, which is automatically delivered to the listed user phone number if the specified minimum (MIN) or maximum (MAX) temperature threshold of any temperature sensor is exceeded by at least 1°C. In case of temperature threshold's is exceeded, an event data message will be sent to the monitoring station. To set the MIN and MAX temperature thresholds for a certain temperature sensor, please refer to the configuration methods.

Set MIN and MAX temperature boundaries

SMS

SMS text message content:

ssss TEMPTs:MIN:mnn,MAX:mxX

Value: ssss - 4-digit SMS password; ts - temperature sensor slot, range - [1... 8]; mnn - MIN boundary, range - [-55... 125] °C; mxX - MAX boundary, range - [-55... 125] °C.

Example: 1111 TEMP2:MIN:-5,MAX:28

EKB2

Menu path:

MIN: OK → iiiii → OK → PRIMARY SETTINGS → OK → TEMP SENSORS → OK → TEMPERATURE SENS 1... 8 → OK → TEMP. MIN → OK → mnn → OK

MAX: ... → TEMPERATURE SENS 1... 8 → OK → TEMP. MAX → OK → mxX → OK

Value: iiiii - 4-digit installer code; mnn - MIN boundary, range - [-55... 125] °C; mxX - MAX boundary, range - [-55... 125] °C.

Keys P1 or P2 are used to enter minus character, e.g. -20.

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

View MIN and MAX temperature boundaries

SMS

SMS text message content:

ssss TEMPTs

Value: ssss - 4-digit SMS password; ts - temperature sensor slot, range - [1... 8].

Example: 1111 TEMP4

EKB2

Menu path:

MIN: OK → iiiii → OK → PRIMARY SETTINGS → OK → TEMP SENSORS → OK → TEMPERATURE SENS 1... 8 → OK → TEMP. MIN

MAX: ... → TEMPERATURE SENS 1... 8 → OK → TEMP. MAX

Value: iiiii - 4-digit installer code

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

For more details on how *Send SMS text message to all users simultaneously* and *SMS Cascade* parameters affect the SMS text message

transmission, please refer to **27. SYSTEM NOTIFICATIONS**.

NOTE: MIN and MAX thresholds can also be set separately by multiple SMS text messages, **Example:** 1111 TEMP1:MIN:6 and 1111 TEMP1:-MAX:40

24.4. Temperature Sensor Names

The temperature sensor name is included in the Temperature Info SMS when delivered to the listed user phone number. This feature allows easier identification of the temperature sensor and normally it is used when monitoring temperature changes in different areas.

Set temperature sensor name

SMS

SMS text message content:
ssss TEMPtS:NAME:temp-sens-name

Value: ssss - 4-digit SMS password; ts - temperature sensor slot, range - [1... 8]; temp-sens-name - 4 to 15 characters temperature sensor name.
Example: 1111 TEMP3:NAME:Warehouse

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

View temperature sensor name

SMS

SMS text message content:
ssss TEMPtS

Value: ssss - 4-digit SMS password; ts - temperature sensor slot, range - [1... 8].
Example: 1111 TEMP3

EKB2

Menu path:
OK → iiiii → OK → PRIMARY SETTINGS → OK → TEMP SENSORS → OK → TEMPERATURE SENS
1... 8 → OK → NAME

Value: iiiii - 4-digit installer code.

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Delete temperature sensor name

SMS

SMS text message content:
ssss TEMPtS:NAME:

Value: ssss - 4-digit SMS password; ts - temperature sensor slot, range - [1... 8].
Example: 1111 TEMP2:NAME:

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

25. SYSTEM INFORMATION. INFO SMS

The system supports an informational SMS text message identified as the Info SMS, which can be delivered upon request. Once requested, the system will reply with Info SMS that provides the following:

- System date and time.
- System status: partition armed (ON)/disarmed (OFF).
- 2G/4G signal strength.
- Mains power status.
- Temperature of the area surrounding primary and secondary temperature sensors (if any).
- State of zones (OK/alarm).
- Name and status (ON/OFF) of PGM outputs.

Request for system information

SMS

SMS text message content:
ssss INFO
Value: ssss - 4-digit SMS password.
Example: 1111 INFO

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

25.1. Periodic Info SMS

By default, the system sends Info SMS to User 1 phone number periodically once a day at 11:00 (frequency - 1 day; time - 11). The minimum period is every 5 minutes, which can be set using *Eldes Utility*. Typically, this feature is used to verify the power supply and online status of the system.

To set a different frequency and time or disable periodic Info SMS, please refer to the following configuration methods.

Set periodic Info SMS frequency and time

SMS

SMS text message content:
ssss INFO:fff.it
Value: ssss - 4-digit SMS password; fff - frequency, range - [0... 99] days; it - time, range - [0... 23].
Example: 1111 INFO:3.15

EKB2

Menu path:
Frequency: OK → iii → PRIMARY SETTINGS → OK → PERIODIC INFO → OK → FREQUENCY (DAYS) → fff → OK
Time: ... → PERIODIC INFO → OK → TIME → it → OK
Value: iii - 4-digit installer code; fff - frequency, range - [00... 125] days; it - time, range - [00... 23].

EKB3/
EKB3w/
EWKB4

Enter parameter 11, time and frequency:
11it fff #
Value: it - time, range - [01... 23]; fff - frequency, range - [00... 125] days.
Example: 110412#

Eldes Utility

This operation may be carried out from the PC using the *ELDES* software.

Disable periodic Info SMS

SMS

SMS text message content:
ssss INFO:00.00
Value: ssss - 4-digit SMS password.
Example: 1111 INFO:00.00

EKB2

Menu path:
Frequency: OK → iii → PRIMARY SETTINGS → OK → PERIODIC INFO → OK → FREQUENCY (DAYS) → 0 → OK
Time: ... → PERIODIC INFO → OK → TIME → 0 → OK
Value: iii - 4-digit installer code.

EKB3/
EKB3W/
EWKB4

Enter parameter 11 and parameter status value:

11 00 00 #

Example: 110000#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: Unlike Info SMS upon request, periodic Info SMS text message does not include zone states, PGM output names and status.

26. SYSTEM NOTIFICATIONS

By default, in case of a certain event, the system attempts to send an SMS text message to the first listed user phone number only. If the user phone number is unavailable and the system fails to receive the SMS delivery report during 45 seconds, it will attempt to send the SMS text message to the next listed user phone number, assigned to the same partition as the previous one. The user phone number may be unavailable due to the following reasons:

- mobile phone was switched off.
- was out of 2G/4G signal coverage.

The system will continue sending the SMS text message to the next listed user phone numbers in the priority order until one is available. The system sends the SMS text message only once and will not return to the first user phone number if the last one was unavailable.

To change the SMS text message delivery algorithm, user can enable/disable the following parameters for certain events:

- **SMS Cascade enabled** - In case of specified event, system sends SMS text message to first user in a row. Only in case of failed attempt (user phone is turned off or etc.) system will send to another user in a row until first successful attempt.
- **SMS Cascade disabled** - If 'SMS Cascade' option is disabled, the system simultaneously sends a certain SMS text message to all available users regardless if the previous one has received the SMS text message or not.

The following table provides the description of system notifications by SMS text message sent to the user phone number.

Seq. No.	Event	Description
1	System armed	SMS text message sent to the user regarding armed system.
2	System disarmed	SMS text message sent to the user about disarmed system.
3	General alarm	SMS text message sent to the user in case of system alarm occurrence.
4	Mains power loss/restore	SMS text message sent to the user in case the mains power is lost or restored
5	Battery failed	SMS text message sent to the user in case the backup battery resistance is 2Ω or higher (battery requires replacement).
6	Battery dead or missing	SMS text message sent to the user in case the backup battery is not present or the battery voltage runs below 5V.
7	Low battery	SMS text message sent to the user in case the backup battery voltage is 10.5V or lower.
8	Siren fail/restore	SMS text message sent to the user in case the siren is disconnected/broken or connected/fixed.
9	Date/time not set	SMS text message sent to the user in case system date and time is not set.
10	2G/4G connection failed	SMS text message sent to the user in case the 2G/4G connection is lost.
11	2G/4G antenna fail/restore	SMS text message sent to the user in case the 2G/4G antenna is disconnected/broken or connected/fixed.
12	Tamper alarm	SMS text message sent to the user in case of tamper violation. Indicated as <i>Tamper x</i> .
13	Communication bus fail/restore	SMS text message sent to the user in case the RS485 device, such as keypad or zone and PGM output expansion module is disconnected/broken or disconnected/broken or connected/fixed.
14	Temperature info	SMS text message sent to the user in case of temperature deviation by the set values.
15	System started	SMS text message sent to the user on system startup.
16	Periodical info	Info SMS text message sent to the user periodically by the set values.
17	Wireless signal loss/restore	SMS text message sent to the user in case the wireless signal is lost or restored.. Indicated as <i>No wireless signal from wless-dev wless-id Tamper x and Wireless signal restored. From wless-dev wless-id Tamper x</i> respectively. This notification does NOT apply to EWM1 device.
18	Unable to arm	SMS text message sent to the user in case the system denies arming due to existing violated zone (-s)/tamper (-s)/other system fault (see 19.3. Wireless Signal Status Monitoring).
19	CO level critical	SMS text message sent to the user in case the critical level 4 of carbon monoxide (CO) concentration detected by EWF1CO is reached.
20	Report/Control zone triggered	SMS text message sent to the user in case the Report/Control-type zone is triggered.
21	Zone autobypass	SMS text message sent to the user in case a violated zone is bypassed automatically.
22	EWM1 wireless signal loss/restore	SMS text message sent to the user in case the wireless signal with EWM1 device is lost or restored. Indicated as <i>No wireless signal from wless-dev wless-id Tamper x and Wireless signal restored. From wless-dev wless-id Tamper x</i> respectively. This notification cannot be managed via EKB2.
23	Incoming SMS forwarding	SMS text message sent to the user in case the SMS forwarding of the incoming SMS text messages is enabled (see 27.3 SMS Forward). This notification can be managed via EKB3/EKB3W/EWKB4 and Eldes Utility only.
24	Wireless communication failed	SMS text message sent to the user in case the wireless signal failure is lasting for 20 minutes. This event is a warning and does NOT cause an alarm (see 19.3. Wireless Signal Status Monitoring).
25	RF jammer detected	SMS text message sent to the user in case the wireless signal is blocked by jammer.
26	Communication with MS failed	SMS text message sent to user in case the system ends up with all unsuccessful attempts by all connections to deliver data message to the monitoring station. This event can be managed using Eldes Utility only.

To enable/disable a certain system notification, please refer to the following configuration methods.

Menu path:

System armed:

User phone number: OK → iiiii → OK → SMS MESSAGES 1 → OK → SYS ARMED EVENT → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → SYS ARMED EVENT → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → SYS ARMED EVENT → OK → SMS REPORT → OK → DISABLE → OK

System disarmed:

User phone number: ... → SYS DISARMED EVENT → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → SYS DISARMED EVENT → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → SYS DISARMED EVENT → OK → SMS REPORT → OK → DISABLE → OK

General alarm:

User phone number: ... → GENERAL ALARM EV → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → GENERAL ALARM EV → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → GENERAL ALARM EV → OK → SMS REPORT → OK → DISABLE → OK

Mains power loss/restore:

User phone number: ... → MAIN POWER L/R EV → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → MAIN POWER L/R EV → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → MAIN POWER L/R EV → OK → SMS REPORT → OK → DISABLE → OK

Battery failed:

User phone number: ... → BATTERY FAILED → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → BATTERY FAILED → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → BATTERY FAILED → OK → SMS REPORT → OK → DISABLE → OK

Battery dead or missing:

User phone number: ... → BATTERY DEAD/MISS → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → BATTERY DEAD/MISS → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → BATTERY DEAD/MISS → OK → SMS REPORT → OK → DISABLE → OK

Low battery:

User phone number: ... → LOW BATTERY EVENT → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → LOW BATTERY EVENT → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → LOW BATTERY EVENT → OK → SMS REPORT → OK → DISABLE → OK

Siren fail/restore:

User phone number: ... → SIREN FAIL/REST EV → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → SIREN FAIL/REST EV → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → SIREN FAIL/REST EV → OK → SMS REPORT → OK → DISABLE → OK

RF jammer detected:

User phone number: ... → RF JAMMER DETECTED → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → RF JAMMER DETECTED → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → RF JAMMER DETECTED → OK → SMS REPORT → OK → DISABLE → OK

Date/time not set:

User phone number: ... → OK → DATE/TIME NOT SET → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → DATE/TIME NOT SET → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → DATE/TIME NOT SET → OK → SMS REPORT → OK → DISABLE → OK

2G/4G connection failed:

User phone number: ... → OK → 2G/4G CONNECT FAILED → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → OK → 2G/4G CONNECT FAILED → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → 2G/4G CONNECT FAILED → OK → SMS REPORT → OK → DISABLE → OK

2G/4G antenna fail/restore:

User phone number: ... → 2G/4G ANT FAIL/REST → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → 2G/4G ANT FAIL/REST → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → 2G/4G ANT FAIL/REST → OK → SMS REPORT → OK → DISABLE → OK

Tamper alarm:

User phone number: ... → TAMPER ALARM → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → TAMPER ALARM → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → TAMPER ALARM → OK → SMS REPORT → OK → DISABLE → OK

Communication bus fail/restore:

User phone number: ... → COMM BUS FAIL/RST → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → COMM BUS FAIL/RST → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → COMM BUS FAIL/RST → OK → SMS REPORT → OK → DISABLE → OK

Temperature info:

User phone number: ... → TEMP INFO EVENT → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → TEMP INFO EVENT → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → TEMP INFO EVENT → OK → SMS REPORT → OK → DISABLE → OK

System started:

User phone number: ... → SYSTEM STARTED EV → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → SYSTEM STARTED EV → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → SYSTEM STARTED EV → OK → SMS REPORT → OK → DISABLE → OK

Periodical info:

User phone number: OK → iiiii → OK → SMS MESSAGES 2 → PERIOD INFO SMS EV → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → PERIOD INFO SMS EV → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → PERIOD INFO SMS EV → OK → SMS REPORT → OK → DISABLE → OK

Wireless signal loss/restore:

User phone number: ... → WLESS SIGN LOSS EV → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → WLESS SIGN LOSS EV → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → WLESS SIGN LOSS EV → OK → SMS REPORT → OK → DISABLE → OK

Unable to arm:

User phone number: ... → FAIL TO ARM SMS → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → FAIL TO ARM SMS → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → FAIL TO ARM SMS → OK → SMS REPORT → OK → DISABLE → OK

CO level critical:

User phone number: ... → CO LEVEL CRITICAL → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → CO LEVEL CRITICAL → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → CO LEVEL CRITICAL → OK → SMS REPORT → OK → DISABLE → OK

Report/Control zone triggered:

User phone number: ... → REPORT/CTRL TRIG → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → REPORT/CTRL TRIG → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → REPORT/CTRL TRIG → OK → SMS REPORT → OK → DISABLE → OK

Zone bypass:

User phone number: ... → ZONE BYPASS EV → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → ZONE BYPASS EV → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → ZONE BYPASS EV → OK → SMS REPORT → OK → DISABLE → OK

Wireless communication failed:

User phone number: ... → WRLESS FAIL 20MIN. → OK → 2G/4G USER 1... 10 → OK → DISABLE → OK

SMS text message to all users simultaneously: ... → WRLESS FAIL 20MIN. → OK → SMS TO ALL → OK → DISABLE → OK

SMS delivery report: ... → WRLESS FAIL 20MIN. → OK → SMS REPORT → OK → DISABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

System armed event

User phone number: 25 01 up 0 #

SMS text message to all users simultaneously: 21 01 0 #

SMS delivery report: 55 01 0 #

System disarmed event

User phone number: 25 02 up 0 #

SMS text message to all users simultaneously: 21 02 0 #

SMS delivery report: 55 02 0 #

General alarm

User phone number: 25 03 up 0 #

SMS text message to all users simultaneously: 21 03 0 #

SMS delivery report: 55 03 0 #

Main power loss/restore

User phone number: 25 04 up 0 #

SMS text message to all users simultaneously: 21 04 0 #

SMS delivery report: 55 04 0 #

Battery failed

User phone number: 25 05 up 0 #

SMS text message to all users simultaneously: 21 05 0 #

SMS delivery report: 55 05 0 #

Battery dead or missing

User phone number: 25 06 up 0 #

SMS text message to all users simultaneously: 21 06 0 #

SMS delivery report: 55 06 0 #

Low battery

User phone number: 25 07 up 0 #

SMS text message to all users simultaneously: 21 07 0 #

SMS delivery report: 55 07 0 #

Siren fail/restore

User phone number: 25 08 up 0 #

SMS text message to all users simultaneously: 21 08 0 #

SMS delivery report: 55 08 0 #

RF jammer detected

User phone number: 25 09 up 0 #

SMS text message to all users simultaneously: 21 09 0 #

SMS delivery report: 55 09 0 #

Date/time not set

User phone number: 25 10 up 0 #

SMS text message to all users simultaneously: 21 10 0 #

SMS delivery report: 55 10 0 #

2G/4G connection failed

User phone number: 25 11 up 0 #

SMS text message to all users simultaneously: 21 11 0 #

SMS delivery report: 55 11 0 #

2G/4G antenna fail/restore

User phone number: 25 12 up 0 #

SMS text message to all users simultaneously: 21 12 0 #

SMS delivery report: 55 12 0 #

Tamper alarm

User phone number: 25 13 up 0 #

SMS text message to all users simultaneously: 21 13 0 #

SMS delivery report: 55 13 0 #

Communication bus fail/restore

User phone number: 25 14 up 0 #

SMS text message to all users simultaneously: 21 14 0 #

SMS delivery report: 55 14 0 #

Temperature info

User phone number: 25 15 up 0 #

SMS text message to all users simultaneously: 21 15 0 #

SMS delivery report: 55 15 0 #

System started

User phone number: 25 16 up 0 #

SMS text message to all users simultaneously: 21 16 0 #

SMS delivery report: 55 16 0 #

Periodical info

User phone number: 25 17 up 0 #

SMS text message to all users simultaneously: 21 17 0 #

SMS delivery report: 55 17 0 #

Wireless signal loss/restore

User phone number: 25 18 up 0 #

SMS text message to all users simultaneously: 21 18 0 #

SMS delivery report: 55 18 0 #

Unable to arm

User phone number: 25 19 up 0 #

SMS text message to all users simultaneously: 21 19 0 #

SMS delivery report: 55 19 0 #

Zone bypass

User phone number: 25 20 up 0 #

SMS text message to all users simultaneously: 21 20 0 #

SMS delivery report: 55 20 0 #

CO level critical

User phone number: 25 21 up 0 #

SMS text message to all users simultaneously: 21 21 0 #

SMS delivery report: 55 21 0 #

EWM1 wireless signal loss/restore

User phone number: 25 22 up 0 #

SMS text message to all users simultaneously: 21 22 0 #

SMS delivery report: 55 22 0 #

Report/Control zone triggered

User phone number: 25 23 up 0 #

SMS text message to all users simultaneously: 21 23 0 #

SMS delivery report: 55 23 0 #

Incoming SMS forwarding

User phone number: 25 24 up 0 #

SMS text message to all users simultaneously: 21 24 0 #

SMS delivery report: 55 24 0 #

Wireless communication failed

User phone number: 25 25 up 0 #

SMS text message to all users simultaneously: 21 25 0 #

SMS delivery report: 55 25 0 #

Value: up - user phone number slot, range - [01...10].

Example: 2517040#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Menu path:

System armed:

User phone number: OK → iiiii → OK → SMS MESSAGES 1 → OK → SYS ARMED EVENT → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → SYS ARMED EVENT → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → SYS ARMED EVENT → OK → SMS REPORT → OK → ENABLE → OK

System disarmed:

User phone number: ... → SYS DISARMED EVENT → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → SYS DISARMED EVENT → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → SYS DISARMED EVENT → OK → SMS REPORT → OK → ENABLE → OK

General alarm:

User phone number: ... → GENERAL ALARM EV → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → GENERAL ALARM EV → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → GENERAL ALARM EV → OK → SMS REPORT → OK → ENABLE → OK

Mains power loss/restore:

User phone number: ... → MAIN POWER L/R EV → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → MAIN POWER L/R EV → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → MAIN POWER L/R EV → OK → SMS REPORT → OK → ENABLE → OK

Battery failed:

User phone number: ... → BATTERY FAILED → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → BATTERY FAILED → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → BATTERY FAILED → OK → SMS REPORT → OK → ENABLE → OK

Battery dead or missing:

User phone number: ... → BATTERY DEAD/MISS → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → BATTERY DEAD/MISS → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → BATTERY DEAD/MISS → OK → SMS REPORT → OK → ENABLE → OK

Low battery:

User phone number: ... → LOW BATTERY EVENT → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → LOW BATTERY EVENT → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → LOW BATTERY EVENT → OK → SMS REPORT → OK → ENABLE → OK

Siren fail/restore:

User phone number: ... → SIREN FAIL/REST EV → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → SIREN FAIL/REST EV → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → SIREN FAIL/REST EV → OK → SMS REPORT → OK → ENABLE → OK

RF jammer detected:

User phone number: ... → RF JAMMER DETECTED → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → RF JAMMER DETECTED → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → RF JAMMER DETECTED → OK → SMS REPORT → OK → ENABLE → OK

Date/time not set

User phone number: ... → OK → DATE/TIME NOT SET → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → DATE/TIME NOT SET → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → DATE/TIME NOT SET → OK → SMS REPORT → OK → ENABLE → OK

2G/4G connection failed:

User phone number: ... → OK → 2G/4G CONNECT FAILED → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → 2G/4G CONNECT FAILED → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → 2G/4G CONNECT FAILED → OK → SMS REPORT → OK → ENABLE → OK

2G/4G antenna fail/restore:

User phone number: ... → 2G/4G ANT FAIL/REST → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → 2G/4G ANT FAIL/REST → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → 2G/4G ANT FAIL/REST → OK → SMS REPORT → OK → ENABLE → OK

Tamper alarm:

User phone number: ... → TAMPER ALARM → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → TAMPER ALARM → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → TAMPER ALARM → OK → SMS REPORT → OK → ENABLE → OK

Communication bus fail/restore:

User phone number: ... → COMM BUS FAIL/REST → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → COMM BUS FAIL/REST → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → COMM BUS FAIL/REST → OK → SMS REPORT → OK → ENABLE → OK

Temperature info:

User phone number: ... → TEMP INFO EVENT → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → TEMP INFO EVENT → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → TEMP INFO EVENT → OK → SMS REPORT → OK → ENABLE → OK

System started:

User phone number: ... → SYSTEM STARTED EV → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → SYSTEM STARTED EV → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → SYSTEM STARTED EV → OK → SMS REPORT → OK → ENABLE → OK

Periodical info:

User phone number: OK → iiiii → OK → SMS MESSAGES 2 → PERIOD INFO SMS EV → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → PERIOD INFO SMS EV → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → PERIOD INFO SMS EV → OK → SMS REPORT → OK → ENABLE → OK

Wireless signal loss/restore:

User phone number: ... → WLESS SIGN LOSS EV → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → WLESS SIGN LOSS EV → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → WLESS SIGN LOSS EV → OK → SMS REPORT → OK → ENABLE → OK

Unable to arm:

User phone number: ... → FAIL TO ARM SMS → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → FAIL TO ARM SMS → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → FAIL TO ARM SMS → OK → SMS REPORT → OK → ENABLE → OK

CO level critical:

User phone number: ... → CO LEVEL CRITICAL → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → CO LEVEL CRITICAL → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → CO LEVEL CRITICAL → OK → SMS REPORT → OK → ENABLE → OK

Report/Control zone triggered:

User phone number: ... → REPORT/CTRL TRIG → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → REPORT/CTRL TRIG → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → REPORT/CTRL TRIG → OK → SMS REPORT → OK → ENABLE → OK

Zone bypass:

User phone number: ... → ZONE BYPASS EV → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → ZONE BYPASS EV → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → ZONE BYPASS EV → OK → SMS REPORT → OK → ENABLE → OK

Value: *iiii* - 4-digit installer code.

Wireless communication failed:

User phone number: ... → WRLESS FAIL 20MIN. → OK → 2G/4G USER 1... 10 → OK → ENABLE → OK

SMS text message to all users simultaneously: ... → WRLESS FAIL 20MIN. → OK → SMS TO ALL → OK → ENABLE → OK

SMS delivery report: ... → WRLESS FAIL 20MIN. → OK → SMS REPORT → OK → ENABLE → OK

Value: *iiii* - 4-digit installer code.

Enter parameter 25/21/55, event number, user phone number slot and parameter status value:

System armed event

User phone number: 25 01 up 1 #

SMS text message to all users simultaneously: 21 01 1 #

SMS delivery report: 55 01 1 #

System disarmed event

User phone number: 25 02 up 1 #

SMS text message to all users simultaneously: 21 02 1 #

SMS delivery report: 55 02 1 #

General alarm

User phone number: 25 03 up 1 #

SMS text message to all users simultaneously: 21 03 1 #

SMS delivery report: 55 03 1 #

Main power loss/restore

User phone number: 25 04 up 1 #

SMS text message to all users simultaneously: 21 04 1 #

SMS delivery report: 55 04 1 #

Battery failed

User phone number: 25 05 up 1 #

SMS text message to all users simultaneously: 21 05 1 #

SMS delivery report: 55 05 1 #

Battery dead or missing

User phone number: 25 06 up 1 #

SMS text message to all users simultaneously: 21 06 1 #

SMS delivery report: 55 06 1 #

Low battery

User phone number: 25 07 up 1 #

SMS text message to all users simultaneously: 21 07 1 #

SMS delivery report: 55 07 1 #

Siren fail/restore

User phone number: 25 08 up 1 #

SMS text message to all users simultaneously: 21 08 1 #

SMS delivery report: 55 08 1 #

RF jammer detected

User phone number: 25 09 up 1 #

SMS text message to all users simultaneously: 21 09 1 #

SMS delivery report: 55 09 1 #

Date/time not set

User phone number: 25 10 up 1 #

SMS text message to all users simultaneously: 21 10 1 #

SMS delivery report: 55 10 1 #

2G/4G connection failed

User phone number: 25 11 up 1 #

SMS text message to all users simultaneously: 21 11 1 #

SMS delivery report: 55 11 1 #

2G/4G antenna fail/restore

User phone number: 25 12 up 1 #

SMS text message to all users simultaneously: 21 12 1 #

SMS delivery report: 55 12 1 #

Tamper alarm

User phone number: 25 13 up 1 #

SMS text message to all users simultaneously: 21 13 1 #

SMS delivery report: 55 13 1 #

Communication bus fail/restore

User phone number: 25 14 up 1 #

SMS text message to all users simultaneously: 21 14 1 #

SMS delivery report: 55 14 1 #

Temperature info

User phone number: 25 15 up 1 #

SMS text message to all users simultaneously: 21 15 1 #

SMS delivery report: 55 15 1 #

System started

User phone number: 25 16 up 1 #

SMS text message to all users simultaneously: 21 16 1 #

SMS delivery report: 55 16 1 #

Periodical info

User phone number: 25 17 up 1 #

SMS text message to all users simultaneously: 21 17 1 #

SMS delivery report: 55 17 1 #

Wireless signal loss/restore

User phone number: 25 18 up 1 #

SMS text message to all users simultaneously: 21 18 1 #

SMS delivery report: 55 18 1 #

Unable to arm

User phone number: 25 19 up 1 #

SMS text message to all users simultaneously: 21 19 1 #

SMS delivery report: 55 19 1 #

Zone bypass

User phone number: 25 20 up 1 #

SMS text message to all users simultaneously: 21 20 1 #

SMS delivery report: 55 20 1 #

CO level critical

User phone number: 25 21 up 1 #

SMS text message to all users simultaneously: 21 21 1 #

SMS delivery report: 55 21 1 #

EWM1 wireless signal loss/restore

User phone number: 25 22 up 1 #

SMS text message to all users simultaneously: 21 22 1 #

SMS delivery report: 55 22 1 #

Report/Control zone triggered

User phone number: 25 23 up 1 #

SMS text message to all users simultaneously: 21 23 1 #

SMS delivery report: 55 23 1 #

Incoming SMS forwarding

User phone number: 25 24 up 1 #

SMS text message to all users simultaneously: 21 24 1 #

SMS delivery report: 55 24 1 #

Wireless communication failed

User phone number: 25 25 up 1 #

SMS text message to all users simultaneously: 21 25 1 #

SMS delivery report: 55 25 1 #

Value: up - user phone number slot, range - [01... 10].

Example: 2517041#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

By default, the system is restricted to send out up to 50 SMS text messages daily and up to 1000 SMS text messages monthly. The send out message quantity is counted not only by delivered once, but also by number of attempts to send a message. To change the limits of SMS text message delivery restrictions, on Eldes Utility software open *System settings* --> *SMS Messaging* section, where you'll be able to configure and choose further options.

Global SMS settings

In *System settings* --> *SMS Messaging* section you'll find *Global SMS settings* and you'll be able to choose a preferred option from a drop-down list. There are 3 possible options (see below):

- *SMS disabled* - disables all types of SMS and denies further SMS sending, until other selection is made.
- *SMS Only to CMS* - if selected, then CID events will be sent to CMS, while SMS sending ban is activated. Allows to set a preferred number of daily and monthly SMS sending limits.
- *Full SMS support* (default option) - support all available types of SMS messaging and also allows to set a preferred number of daily and monthly SMS sending limits.

Manage SMS text message delivery limits

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

When the daily or monthly SMS text message delivery limit is exceeded, the system will notify the administrator by SMS text message, stating that "Day SMS sending limit exceeded"/ "Month SMS sending limit exceeded" respectively. The limit counter will automatically reset once the 24 hour (daily) or 30 days (monthly) restriction period is over. That will happen **ONLY** if you have set date and time values. You can reset the limits by referring to the following configuration method.

Reset SMS text message delivery limit counter

SMS

SMS text message content:
`ssss REMOVEBAN`
Value: ssss - 4-digit SMS password.
Example: 1111 REMOVEBAN

See also **9.1. Time Synchronization.**
26.2. SMSC (Short Message Service Center) Phone Number

An SMS center (SMSC) is a 2G/4G network element, which routes SMS text messages to the destination user and stores the SMS text message if the recipient is unavailable. Typically, the phone number of the SMS center is already stored in the SIM card provided by the 2G/4G operator. If the user fails to receive replies from the system, the SMS center phone number, provided by the 2G/4G operator, must be set manually.

Set SMSC phone number

SMS

SMS text message content:
`ssss SMS +ttteeellnnuumm`
Value: ssss - 4-digit SMS password; `ttteeellnnuumm` - up to 15 digits SMSC phone number.
Example: 1111 SMS +44170311XXXX1

ATTENTION: Before setting the SMSC phone number, please check the credit balance of the system's SIM card. The system will fail to reply if the credit balance is insufficient.

26.3. SMS Forward
ESIM484 comes up with a feature, called SMS forward. The system allows user to forward any received message from devices' SIM card to the administrators' mobile phone number. There are 4 basic SMS forwarding options:

- **Forward All received SMS** - if this option is enabled, then every single message, coming to devices' SIM card, will be forwarded to the administrators' phone number.
- **Forward All received SMS from unknown users** - allows user to receive only those messages, coming from unlisted phone numbers.
- **Forward All received SMS from registered users with wrong syntax or wrong password** - user will receive only those messages from listed phone numbers, containing "wrong syntax" or "wrong password" notification.
- **Forward All received SMS from specified Phone Number** - allows you to enter one specified phone number and exploit every single message that comes from it to your devices' SIM card.

By default, SMS forward feature is disabled. To enable/disable this feature, please refer to the following configuration method.

Enable/disable SMS forward

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: If a single forwarded SMS message size exceeds 160 characters, it won't be transmitted properly.

ATTENTION: User is able to add the administrator phone number as a specified phone number (by enabling the option *Forward All received SMS from specified Phone Number*), but none of SMS messages will be forwarded to administrator himself in any case!

27. EVENT AND ALARM LOG

27.1. Event Log

The event log allows to chronologically register up to 1024 timestamped records regarding the following system events:

- System start.
- System arming/disarming.
- Zone violated/restored.
- Tamper violated/restored.
- Zone bypassing.
- Wireless device management.
- Temperature deviation by MIN and MAX boundaries.
- System faults.
- Configuration via USB.
- User phone number that initiated the remote configuration.
- Communication with monitoring station status.

The event log is of FIFO (first in, first out) type that allows the system to automatically replace the oldest records with the latest ones.

View event log

EKB2

Menu path:
OK → mmmm → OK → VIEW EVENT LOG → OK
Value: mmmm - 4-digit master code.

Export/clear event log

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Disable event log

EKB2

Menu path:
OK → iiiii → OK → PRIMARY SETTINGS → OK → EVENT LOG → OK → DISABLE → OK
Value: iiiii - 4-digit installer code.

EKB3/
EKB3W/
EWK4

Enter parameter 36 and parameter status value:
36 0 #
Example: 360#

Enable event log

EKB2

Menu path:
OK → iiiii → OK → PRIMARY SETTINGS → OK → EVENT LOG → OK → ENABLE → OK
Value: iiiii - 4-digit installer code.

EKB3/
EKB3W/
EWK4

Enter parameter 36 and parameter status value:
36 1 #
Example: 361#

Eldes Utility


This operation may be carried out from the PC using the *Eldes Utility*.

ESIM484 Installation and Configuration Manual v1.1

EN

123

27.2. Alarm Log

The alarm log provides a list of last 16 alarm events generated after last arming period. The alarm log can be viewed via EKB2 and includes only the alarms of the partition that the user/master code is assigned to. Each alarm record includes alarm type, partition number and zone number. When highlighted, the date and time of the alarm occurrence can be viewed at the bottom of EKB2 screen. In case of alarm,  icon will appear in home screen view of EKB2. The alarm log auto-clears when the next system arming follows or after viewing it via the keypad.

View alarm log

EKB2

Menu path:

OK → uumm → OK → ALARM LOG → OK

Value: uumm - 4-digit user/master code.

Syntax of alarm log record: [alarm-type P:p Z:nn]

Value: alarm-type - BURGLARY/FIRE/24H/SILENT/TAMPER/WS LOST, p - partition number, range - [1... 4], nn - zone/tamper number, range - [1... 144].

#1 example of alarm log record: BURGLARY P:1 Z:1

Value: BURGLARY - Instant, Int. Follower or Delay-type zone alarm; P:1 - Partition 1; Z:1 - zone Z1.

#2 example of alarm log record: TAMPER P:2 Z:13

Value: TAMPER - tamper alarm; P:2 - Partition 2; Z:13 - tamper 13.

#3 example of alarm log record: FIRE P:4 Z:9

Value: FIRE - Fire-type zone alarm; P:4 - Partition 4; Z:9 - zone Z9.

#4 example of alarm log record: WS LOST P:2 Z:14

Value: WS LOST - wireless signal loss alarm; P:2 - Partition 2; Z:14 - tamper 14.

28. INDICATION OF SYSTEM FAULTS

The system comes equipped with self-diagnostic feature allowing to indicate the presence of any system fault by the keypad as well as by SMS text message notification to the listed user phone number. By default the indication for all system faults is indicated on the keypad. To disable/enable the indication of a certain system fault, please refer to the following configuration method.


Disable/enable individual system fault indication on keypad

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: After enabling/disabling a certain system fault indication, it is necessary to restart the system locally by powering down and powering up the system the system or remotely (see **34. REMOTE SYSTEM RESTART**).

EKB2

 icon displayed in home screen view indicates presence of system and/or EWM1 device faults. In order to view the currently present system faults, please enter a valid user/master code to access menu section **FAULTS**. The description on each system fault is provided in the table below.

View system faults

Menu path:
OK → uumm → OK → FAULTS → OK

Value: uumm - 4-digit user/master code.

Name	Description
MAIN POWER LOSS	Mains power is lost
LOW BATTERY	Low backup battery power - backup battery voltage is 10.5V or lower
BATTERY DEAD/MISS	Backup battery is not present or the battery voltage runs below 5V
BATTERY FAILED	Backup battery requires replacement - backup battery resistance is 2Ω or higher
SIREN FAILED	Wired siren is disconnected/broken
VIOLATED TAMPER	One or more tamperers are violated
DATE/TIME NOT SET	Date/time not set
2G/4G CONNECT FAILED	2G/4G connection is lost
2G/4G ANTENNA FAILED	2G/4G antenna is disconnected/broken
WLESS ANTENNA FAIL	Wireless antenna is disconnected/broken
COMM BUS FAILED	RS485 device, such as keypad, ELAN3-ALARM or EPGM1 is disconnected/broken
CO LEVEL CRITICAL	Critical level 4 of carbon monoxide (CO) concentration detected by EWF1CO is reached
EWM1 FAULT	One or more EWM1 device faults exist - enter this menu item to view the existing EWM1 device faults.
WLESS BATT LOW	Low wireless device battery power - battery level is running below 5%
RF JAMMER DETECTED	Wireless signal is blocked by jammer
MS COMM. FAILED	Communication with monitoring station failed


Alternatively, existing EWM1 device faults can be viewed by accessing menu section **FAULTS** of the PGM output associated with a certain EWM1 device.

View EWM1 faults

Menu path:
OK → mmmm → OK → PGM OUTPUTS → OK → out-name → OK → FAULTS → OK

Value: mmmm - 4-digit master code; out-name - PGM output name associated with a certain EWM1 device.

Name	Description
OVERVOLTAGE	Voltage has increased above 260VAC
UNDERVOLTAGE	Voltage has dropped below 190VAC
OVERCURRENT	Current has increased above 12,5A
RELAY FAULT	Unable to power up the appliance due to faulty relay
TEMP. FAULT	Environmental temperature has dropped below -35°C (-31°F) or increased above +90°C (+194°F)

In order to clear the existing faults, please press the  button on EWM1, turn OFF the electrical appliance or turn OFF the wireless PGM output associated with EWM1. For more details on EWM1 device, please refer to **19.9. EWM1 - Wireless Power Socket**.

1. Steady ON or flashing indicator  represents certain system faults. For more details, please refer to the following table below.

Indication	Description
Steady ON	One or more tampers are violated; other system faults (see below)
Flashing	One or more high-numbered zones (Z13-Z144) are violated (see below)

2. In order to find out more on a certain system fault, please enter the following command.

View system faults

Enter command:

... #

After this procedure the keypad will illuminate red indicators for 15 seconds. All indications are listed in the table below.

LED #	Description
1	Mains power is lost
2	Low backup battery power - backup battery voltage is 10.5V or lower
3	Backup battery is not present or the battery voltage runs below 5V
4	Backup battery requires replacement - backup battery resistance is 2Ω or higher
5	Wired siren is disconnected/broken
6	Wireless signal is blocked by jammer
7	One or more tampers are violated (see step #4)
8	Date/time not set
9	One or more high-numbered zones (Z13-Z144) are violated (see step #3)
10	2G/4G connection is lost / Communication with monitoring station failed
11	2G/4G antenna is disconnected/broken
12	Wireless antenna is disconnected/broken

ATTENTION: ESIM484 (When user updates ESIM484 firmware to the newest version (v01.02.00 and up), he won't be able to view violated high-numbered zones on EWKB4 keypad, since the mentioned function (command) will be permanently disabled. Eventually, user won't be able to bypass a violated high-numbered zone by keypad and arm the system, UNLESS he configures system's settings as suggested further. In order to avoid this issue, user has to do the following: 1) open Eldes Utility and go to EWKB4 settings; 2) enable EWKB4 partition switch feature; 3) arrange selected zones (i.e. keypad LED indicators) in a preferred order; 4) assign 12 zones to each partition separately (partitions 1-4 allow user to assign any 48 zones (combined)).

3. In order to find out the violated high-numbered zone, please enter the following command and refer to the table below.

View violated high-numbered zones

Enter command:

... 1

4. To find out which particular tamper is violated, enter the following command. In case there is a combination of flashing and illuminated red indicators on the keypad, refer to the table below to find out the violated high-numbered tamper (Tamper 13 - 144).

View violated tampers

Enter command:

... 2

The following table provides the combinations of red indicators belonging to a certain indicator section (A or B) on the keypad. The combination of the flashing red indicator in section A and illuminated (steady ON) red indicator in section B represents the respective number of a violated high-numbered zone or tamper.

A (flashing)	B (steady ON)	LED #7	LED #8	LED #9	LED #10	LED #11	LED #12
LED #1		Z13	Z19	Z25	Z31	Z37	Z43
LED #2		Z14	Z20	Z26	Z32	Z38	Z44
LED #3		Z15	Z21	Z27	Z33	Z39	Z45
LED #4		Z16	Z22	Z28	Z34	Z40	Z46
LED #5		Z17	Z23	Z29	Z35	Z41	Z47
LED #6		Z18	Z24	Z30	Z36	Z42	Z48

29. MONITORING STATION

The system can be configured to report events to the monitoring station by transmitting data messages to the monitoring station. The system connects to the monitoring station when the MS (Monitoring Station) mode is enabled. When using the MS mode, the data messages transmitted to the monitoring station (see **30.1. Data Messages - Events**) will gain the highest priority for the delivery, therefore based on the communication method (see **30.2. Communication**), a constant and stable connection with the monitoring station must be ensured. In case of connection failure, the system will attempt to restore the connection and if the monitoring is unavailable for a lengthy period of time, the system might consume a large amount of voice calls/data resulting in additional charges applied by the 2G/4G operator according to the cell phone service plan.

Enable MS mode

SMS

SMS text message content:

`ssss SCNSET:ON`

Value: ssss - 4-digit SMS password.

Example: 1111 SCNSET:ON

EKB2

Menu path:

OK → iiii → OK → MS SETTINGS → OK → MS MODE → OK → ENABLE → OK

Value: iiii - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 23 and parameter status value:

`23 1 #`

Example: 231#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Disable MS mode

SMS

SMS text message content:

`ssss SCNSET:OFF`

Value: ssss - 4-digit SMS password.

Example: 1111 SCNSET:OFF

EKB2

Menu path:

OK → iiii → OK → MS SETTINGS → OK → MS MODE → OK → DISABLE → OK

Value: iiii - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 23 and parameter status value:

`23 0 #`

Example: 230#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Account is a 4-character combination (By default - 9999) required to identify the alarm system unit by the monitoring station. The combination may consist of digits [0...9] and letters [A...F] (can be set using *Eldes Utility* only). Server 2 Account and Server 3 Account are used only when necessary to set up to 3 server IP addresses (see **30.2.1. 2G/4G Network and ELAN3-ALARM**)

Set account

EKB2

Menu path:

Main Account: OK → iiii → OK → MS SETTINGS → OK → ACCOUNT → OK → cccc → OK

Server 2 Account: OK → iiii → OK → MS SETTINGS → OK → IP SETTINGS → OK → SERVER2 IP

→ OK → ACCOUNT → OK → cccc → OK

Server 3 Account: ... → SERVER3 IP → OK → ACCOUNT → OK → cccc → OK

Value: iiii - 4-digit installer code; cccc - 4-character account, range - [0000... 9999].

**EKB3/
EKB3W/
EKB4**

Enter parameter 27 and account number/parameter 96, parameter number and account number:

Main Account: `27 cccc #`

Server 2 Account: `96 12 cccc #`

Server 3 Account: `96 13 cccc #`

Value: cccc - 4-character account, range - [0000... 9999].

Example: 27853#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: The system will NOT send any data to the monitoring station while remote connection, remote firmware update is in progress. However, during the remote connection session, the data messages will be queued up and transmitted to the monitoring station after the remote connection session is over, while during the remote firmware update process NO data will be queued up and all data messages will be lost.

ATTENTION: Phone calls via 2G/4G network to the listed user phone number in case of alarm are disabled by force when MS mode is enabled.

NOTE: Additional charges may apply for voice calls/data traffic based on your cell phone service plan when using the MS mode.

29.1. Data Messages - Events

The configuration of data messages is based on Ademco Contact ID protocol. The data messages can either be transmitted to the monitoring station alone or with duplication by SMS text message to listed user phone number. For more details on system notifications by SMS text message, please refer to **27. SYSTEM NOTIFICATIONS**.

Seq. No.	Event Code	Event	Description
1	1110	Fire alarm	Transmitted in case a zone of Fire type is violated.
2	3110	Fire restore	Transmitted in case a zone of Fire type is restored.
3	1120	Silent/Panic zone alarm	Transmitted in case a zone of Silent/Panic type is violated.
4	3120	Silent/Panic zone restore	Transmitted in case a zone of Silent/Panic type is restored.
5	1121	Disarmed by user (Duress code)	Transmitted in case the system is disarmed by Duress code.
6	3121	Armed by user (Duress code)	Transmitted in case the system is armed by Duress code.
7	1130	Burglary alarm	Transmitted in case a zone of Delay (if not disarmed before entry delay countdown is completed), Interior Follower or Instant type is violated.
8	3130	Burglary restore	Transmitted in case a zone of Delay (if not disarmed before entry delay countdown is completed), Interior Follower or Instant type is restored.
9	1133	24-Hour zone alarm	Transmitted in case of zone of 24-Hour type is violated.
10	3133	24-Hour zone restore	Transmitted in case of zone of 24-Hour type is restored.
11	1144	Tamper alarm	Transmitted in case the tamper is violated.
12	3144	Tamper restore	Transmitted in case the tamper is restored.
13	1146	Instant Silent zone alarm	Transmitted in case of zone of Instant Silent type is violated.
14	3146	Instant Silent zone restore	Transmitted in case of zone of Instant Silent type is restored.
15	1150	Report/Control zone trigger	Transmitted in case of zone of Report/Control type is triggered.
16	3150	Report/Control zone restore	Transmitted in case of zone of Report/Control type is restored.
17	1158	Temperature risen	Transmitted in case of the temperature has increased above the MAX set value.
18	1159	Temperature fallen	Transmitted in case of temperature has decreased below the MIN set value.
19	1162	CO level critical	Transmitted in case the critical level 4 of carbon monoxide (CO) concentration detected by EWF1CO is reached.
20	1301	Mains power loss	Transmitted in case the mains power is lost.
21	3301	Mains power restore	Transmitted in case the mains power is restored.
22	1302	Low battery	Transmitted in case the backup battery voltage is 10.5V or lower / the wireless device battery level runs below 5%.
23	1308	System shutdown	When the system is running on backup battery power, it transmits the data message before the backup battery power is fully depleted.
24	1309	Battery failed	Transmitted in case the backup battery resistance is 2Ω or higher.
25	1311	Battery dead or missing	Transmitted in case the backup battery is not present or the battery voltage runs below 5V.
26	3311	Battery connection restore	Transmitted in case the backup battery connection is fixed.
27	1321	Siren fail	Transmitted in case the siren is disconnected/broken.
28	3321	Siren restore	Transmitted in case the siren is connected/fixed.
29	1330	Communication bus fail	Transmitted in case the RS485 device, such as keypad, ELAN3-ALARM or EPGM1 is disconnected/broken.
30	3330	Communication bus restore	Transmitted in case the RS485 device, such as keypad, ELAN3-ALARM or EPGM1 is connected/fixed.
31	1344	RF jammer detected	Transmitted in case the wireless signal is blocked by jammer.
32	3344	RF jamming stopped	Transmitter in case the wireless signal is restored after jamming.
33	1354	Communication with MS failed	Transmitted in case the system ends up with all unsuccessful attempts by all connections to deliver data message to the monitoring station. This event can be managed using <i>Eldes Utility</i> only.

34	3354	Communication with MS restored	Transmitted in case the system has successfully delivered the data message to the monitoring station within the repeated data delivery cycle initiated after <i>Delay after last communication attempt</i> time has expired. This event can be managed using <i>Eldes Utility</i> only.
35	1358	2G/4G connection failed	Transmitted in case the 2G/4G connection is lost.
36	3358	SMS sending limit removed	Transmitted in case the SMS text message limit is removed by user or automatically after the set period of time has come.
37	1358	SMS sending limit reached	Transmitted in case the SMS text message limit is reached.
38	1359	2G/4G antenna fail	Transmitted in case the 2G/4G antenna is disconnected/broken
39	3359	2G/4G antenna restore	Transmitted in case the 2G/4G antenna is connected/fixed.
40	1360	IP connection failed	Transmitted in case the 2G/4G connection or Ethernet connection via ELAN3-ALARM is lost.
41	1380	CO sensor lifetime exceeded	Transmitted in case the lifetime of EWF1C0 built-in CO sensor is expired.
42	1381	Wireless signal loss	Transmitted in case the connection with any wireless device is lost.
43	3381	Wireless signal restore	Transmitted in case the connection with any wireless device is restored.
44	1401	Disarmed by user	Transmitted in case the system is disarmed by user/master code, wireless key fob, iButton key, SMS text message, free of charge phone call, ELDES Cloud Services, Eldes Utility, EGR100 middle-ware or Arm-Disarm by Zone method.
45	3401	Armed by user	Transmitted in case the system is armed by user/master code, wireless key fob, iButton key, SMS text message, free of charge phone call, ELDES Cloud Services, Eldes Utility, EGR100 middle-ware or Arm-Disarm by Zone method.
46	1403	Disarmed automatically	Transmitted in case the system is disarmed automatically according to scheduled time.
47	3403	Armed automatically	Transmitted in case the system is armed automatically according to scheduled time.
48	1412	Configuration via remote connection started	Transmitted in case the remote connection session is opened.
49	1441	Disarmed in Stay mode	Transmitted in case the system is disarmed in Stay mode.
50	3441	Armed in Stay mode	Transmitted in case the system is armed in Stay mode.
51	1454	Failed to arm	Transmitted in case remote arming failed due to one or more system zones or tam-pers are violated or system fault occurs.
52	3456	Armed by user (partial arm)	Transmitted in case the system is armed, while violated zone (-s) with Force attribute enabled exist.
53	3463	SGS code entered	Transmitted in case the SGS code is entered.
54	1570	Zone bypassed	Transmitted in case a violated zone is bypassed.
55	3570	Bypassed zone activated	Transmitted in case a bypassed zone is activated.
56	3602	Test event/Kronos ping	Transmitted for system online status verification purposes.
57	3626	Date/time not set	Transmitted in case system date and time is not set.
58	1900	System started	Transmitted on system startup.

The following table refers to user IDs included in arm/disarm data messages.

Type	ID	Type	ID	Type	ID
User Phone Number 1	0	iButton 7	16	User Code 7	32
User Phone Number 2	1	iButton 8	17	User Code 8	33
User Phone Number 3	2	iButton 9	18	User Code 9	34
User Phone Number 4	3	iButton 10	19	User Code 10	35
User Phone Number 5	4	iButton 11	20	User Code 11	36
User Phone Number 6	5	iButton 12	21	User Code 12	37
User Phone Number 7	6	iButton 13	22	User Code 13	38
User Phone Number 8	7	iButton 14	23	User Code 14	39
User Phone Number 9	8	iButton 15	24	User Code 15	40
User Phone Number 10	9	iButton 16	25	User Code 16	41
iButton 1	10	Master Code	26	User Code 17	42
iButton 2	11	User Code 2	27	User Code 18	43
iButton 3	12	User Code 3	28	User Code 19	44
iButton 4	13	User Code 4	29	User Code 20	45
iButton 5	14	User Code 5	30	User Code 21	46
iButton 6	15	User Code 6	31	User Code 22	47
User Code 23	48	User Code 8 on ELDES Cloud Services	64	User Code 24 on ELDES Cloud Services	80
User Code 24	49	User Code 9 on ELDES Cloud Services	65	User Code 25 on ELDES Cloud Services	81
User Code 25	50	User Code 10 on ELDES Cloud Services	66	User Code 26 on ELDES Cloud Services	82

Type	ID
User Code 26	51
User Code 27	52
User Code 28	53
User Code 29	54
User Code 30	55
Remote Code (EGR100)	56
Master Code on ELDES Cloud Services	57
User Code 2 on ELDES Cloud Services	58
User Code 3 on ELDES Cloud Services	59
User Code 4 on ELDES Cloud Services	60
User Code 5 on ELDES Cloud Services	61
User Code 6 on ELDES Cloud Services	62
User Code 7 on ELDES Cloud Services	63

Type	ID
User Code 11 on ELDES Cloud Services	67
User Code 12 on ELDES Cloud Services	68
User Code 13 on ELDES Cloud Services	69
User Code 14 on ELDES Cloud Services	70
User Code 15 on ELDES Cloud Services	71
User Code 16 on ELDES Cloud Services	72
User Code 17 on ELDES Cloud Services	73
User Code 18 on ELDES Cloud Services	74
User Code 19 on ELDES Cloud Services	75
User Code 20 on ELDES Cloud Services	76
User Code 21 on ELDES Cloud Services	77
User Code 22 on ELDES Cloud Services	78
User Code 23 on ELDES Cloud Services	79

Type	ID
User Code 27 on ELDES Cloud Services	83
User Code 28 on ELDES Cloud Services	84
User Code 29 on ELDES Cloud Services	85
User Code 30 on ELDES Cloud Services	86
Key fob 1-Key fob 16	145-160
Arm/Disarm by Zone Z1-Z16	167-182
Arm/Disarm by Schedule	183-214

Disable data message

EKB2

Menu path:

Burglary alarm/restore: OK → iiiii → OK → MS SETTINGS → OK → DATA MESSAGES 1 → OK → BURGLR ALM/REST EV → OK → DISABLE → OK

Mains power loss/restore: ... → MAIN POWER L/R EV → OK → DISABLE → OK

Armed/disarmed by user: ... → ARM/DISARM EVENT → OK → DISABLE → OK

Battery failed: ... → BATTERY FAILED → OK → DISABLE → OK

Battery dead or missing/battery connection restore: ... → BATTERY DEAD/MISS → OK → DISABLE → OK

Test event: ... → TEST EVENT → OK → DISABLE → OK

Tamper alarm/restore: ... → TAMPER ALM/REST EV → OK → DISABLE → OK

Instant Silent zone alarm/restore: ... → INST SILENT EV → OK → DISABLE → OK

System started: ... → SYSTEM STARTED EV → OK → DISABLE → OK

Fire alarm/restore: ... → FIRE ALM/REST EV → OK → DISABLE → OK

24-Hour zone alarm/restore: ... → 24H ALM/REST EVENT → OK → DISABLE → OK

Low battery: ... → LOW BATTERY EVENT → OK → DISABLE → OK

Temperature risen: ... → TEMP HIGH EVENT → OK → DISABLE → OK

Temperature fallen: ... → TEMP LOW EVENT → OK → DISABLE → OK

Wireless signal loss/restore: ... → WLESS SIGNAL R EV → OK → DISABLE → OK

Disarmed by user (Duress code): OK → iiiii → OK → MS SETTINGS → OK → DATA MESSAGES 2 → OK → DISARM DURESS EV → OK → DISABLE → OK

SGS code entered: ... → ARM/DARM SGS EVENT → OK → DISABLE → OK

Armed by user (partial arm): ... → ARM PARTIAL EV → OK → DISABLE → OK

Siren fail/restore: ... → SIREN FAIL/REST EV → OK → DISABLE → OK

RF jammer detected/RF jamming stopped: ... → RF JAMMER DETECTED → OK → DISABLE → OK

Date/time not set: ... → DATE/ TIME NOT SET → OK → DISABLE → OK

2G/4G connection failed: ... → 2G/4G CONNECT FAILED → OK → DISABLE → OK

2G/4G antenna fail/restore: ... → 2G/4G ANT FAIL/REST → OK → DISABLE → OK

System shutdown: ... → SYSTEM SHUTDOWN EV → OK → DISABLE → OK

Communication bus fail/restore: ... → COMM BUS FAIL/RST → OK → DISABLE → OK

IP connection failed: ... → 2G/4G CONNECT FAIL → OK → DISABLE → OK

Zone bypassed/activated: ... → ZONE BYPASS → OK → DISABLE → OK

CO sensor lifetime exceeded: ... → CO SENS LFTIME EXC → OK → DISABLE → OK

CO level critical: ... → CO LEVEL CRITICAL → OK → DISABLE → OK

Report/Control zone triggered/restored: ... → REPORT → OK → DISABLE → OK

EKB2

Armed/disarmed in STAY mode: OK → iiiii → OK → MS SETTINGS → OK → DATA MESSAGES 3 → OK → ARM/DARM STAY EV → OK → DISABLE → OK

Configuration via remote connection started: ... → CFG VIA REMOTE EV → OK → DISABLE → OK

Panic/Silent zone alarm/restore: ... → PA/SIL ALM/REST EV → OK → DISABLE → OK

Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 24, event number and parameter status value:

24 01 0 # - Burglary alarm/restore
24 02 0 # - Mains power loss/restore
24 03 0 # - Armed/disarmed by user
24 04 0 # - Test event
24 05 0 # - Battery failed
24 06 0 # - Battery dead or missing/battery connection restore
24 07 0 # - Tamper alarm/restore
24 08 0 # - Instant Silent zone alarm/restore
24 09 0 # - Kronos ping
24 10 0 # - System started
24 13 0 # - 24-Hour zone alarm/restore
24 14 0 # - Fire zone alarm/restore
24 15 0 # - Low battery
24 16 0 # - Temperature risen
24 17 0 # - Temperature fallen
24 18 0 # - Wireless signal loss/restore
24 19 0 # - Disarmed by user (Duress code)
24 20 0 # - SGS code entered
24 21 0 # - Armed by user (partial arm)
24 22 0 # - Siren fail/restore
24 23 0 # - RF jammer detected/RF jamming stopped
24 24 0 # - Date/time not set
24 25 0 # - 2G/4G connection failed
24 26 0 # - 2G/4G antenna fail/restore
24 27 0 # - System shutdown
24 28 0 # - Communication bus fail/restore
24 29 0 # - IP connection failed
24 31 0 # - Zone bypassed/activated
24 32 0 # - CO sensor lifetime exceeded
24 33 0 # - CO level critical
24 34 0 # - Report/Control zone triggered/restored
24 35 0 # - Armed/disarmed in STAY mode
24 36 0 # - Configuration via remote connection started
24 37 0 # - Panic/Silent zone alarm/restore
24 38 0 # - Armed/disarmed automatically
24 39 0 # - SMS sending limit reached/removed

Example: 24080#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Menu path:

Burglary alarm/restore: OK → iiiii → OK → MS SETTINGS → OK → DATA MESSAGES 1 → OK → BURGLR ALM/REST EV → OK → ENABLE → OK

Mains power loss/restore: ... → MAIN POWER L/R EV → OK → ENABLE → OK

Armed/disarmed by user: ... → ARM/DISARM EVENT → OK → ENABLE → OK

Battery failed: ... → BATTERY FAILED → OK → ENABLE → OK

Battery dead or missing/battery connection restore: ... → BATTERY DEAD/MISS → OK → ENABLE → OK

Test event: ... → TEST EVENT → OK → ENABLE → OK

Tamper alarm/restore: ... → TAMPER ALM/REST EV → OK → ENABLE → OK

Instant Silent zone alarm/restore: ... → INST SILENT EV → OK → ENABLE → OK

System started: ... → SYSTEM STARTED EV → OK → ENABLE → OK

Fire alarm/restore: ... → FIRE ALM/REST EV → OK → ENABLE → OK

24-Hour zone alarm/restore: ... → 24H ALM/REST EVENT → OK → ENABLE → OK

Low battery: ... → LOW BATTERY EVENT → OK → ENABLE → OK

Temperature risen: ... → TEMP HIGH EVENT → OK → ENABLE → OK

Temperature fallen: ... → TEMP LOW EVENT → OK → ENABLE → OK

Wireless signal loss/restore: ... → WLESS SIGN L/R EV → OK → ENABLE → OK

Disarmed by user (Duress code): OK → iiiii → OK → MS SETTINGS → OK → DATA MESSAGES 2 → OK → DISARM DURESS EV → OK → ENABLE → OK

SGS code entered: ... → ARM/DARM SGS EVENT → OK → ENABLE → OK

Armed by user (partial arm): ... → ARM PARTIAL EV → OK → ENABLE → OK

Siren fail/restore: ... → SIREN FAIL/REST EV → OK → ENABLE → OK

RF jammer detected/RF jamming stopped: ... → RF JAMMER DETECTED → OK → ENABLE → OK

Date/time not set: ... → DATE/ TIME NOT SET → OK → ENABLE → OK

2G/4G connection failed: ... → 2G/4G CONNECT FAILED → OK → ENABLE → OK

2G/4G antenna fail/restore: ... → 2G/4G ANT FAIL/REST → OK → ENABLE → OK

System shutdown: ... → SYSTEM SHUTDOWN EV → OK → ENABLE → OK

Communication bus fail/restore: ... → COMM BUS FAIL/RST → OK → ENABLE → OK

IP connection failed: ... → 2G/4G CONNECT FAIL → OK → ENABLE → OK

Zone bypassed/activated: ... → ZONE BYPASS → OK → ENABLE → OK

CO sensor lifetime exceeded: ... → CO SENS LFTIME EXC → OK → ENABLE → OK

CO level critical: ... → CO LEVEL CRITICAL → OK → ENABLE → OK

Report/Control zone triggered/restored: ... → REPORT → OK → ENABLE → OK

Armed/disarmed in STAY mode: OK → iiiii → OK → MS SETTINGS → OK → DATA MESSAGES 3 → OK → ARM/DARM STAY EV → OK → ENABLE → OK

Configuration via remote connection started: ... → CFG VIA REMOTE EV → OK → ENABLE → OK

Panic/Silent zone alarm/restore: ... → PA/SIL ALM/REST EV → OK → ENABLE → OK

Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 24, event number and parameter status value:

24 01 1 # - Burglary alarm/restore
24 02 1 # - Mains power loss/restore
24 03 1 # - Armed/disarmed by user
24 04 1 # - Test event
24 05 1 # - Battery failed
24 06 1 # - Battery dead or missing/battery connection restore
24 07 1 # - Tamper alarm/restore
24 08 1 # - Instant Silent zone alarm/restore
24 09 1 # - Kronos ping
24 10 1 # - System started
24 13 1 # - 24-Hour zone alarm/restore
24 14 1 # - Fire zone alarm/restore
24 15 1 # - Low battery
24 16 1 # - Temperature risen
24 17 1 # - Temperature fallen
24 18 1 # - Wireless signal loss/restore
24 19 1 # - Disarmed by user (Duress code)
24 20 1 # - SGS code entered
24 21 1 # - Armed by user (partial arm)
24 22 1 # - Siren fail/restore
24 23 1 # - RF jammer detected/RF jamming stopped
24 24 1 # - Date/time not set
24 25 1 # - 2G/4G connection failed
24 26 1 # - 2G/4G antenna fail/restore
24 27 1 # - System shutdown
24 28 1 # - Communication bus fail/restore
24 29 1 # - IP connection failed
24 31 1 # - Zone bypassed/activated
24 32 1 # - CO sensor lifetime exceeded
24 33 1 # - CO level critical
24 34 1 # - Report/Control zone triggered/restored
24 35 1 # - Armed/disarmed in STAY mode
24 36 1 # - Configuration via remote connection started
24 37 1 # - Panic/Silent zone alarm/restore
24 38 1 # - Armed/disarmed automatically
24 39 1 # - SMS sending limit reached/removed

Example: 24031#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

29.2. Communication


The system supports the following communication methods and protocols:

- 2G/4G network – EGR100, Kronos, SIA IP protocol (ANSI/SIA DC-09-2007 and ANSI/SIA DC-09-2013; configurable as encrypted and non-encrypted).
- Voice calls (2G/4G audio channel) – Ademco Contact ID protocol.
- PSTN (landline) – Ademco Contact ID protocol.
- ELAN3-ALARM – EGR100, Kronos, SIA IP protocol (ANSI/SIA DC-09-2007 and ANSI/SIA DC-09-2013; configurable as encrypted and non-encrypted).

Any communication method can be set as primary or backup connection. The user can set up to 5 backup connections in any sequence order.

Initially, the system communicates via primary connection with the monitoring station. By default, if the initial attempt to transmit data is unsuccessful, the system will make additional attempts until the data is successfully delivered. If all attempts are unsuccessful, the system will follow this pattern:

- a) The system switches to the backup connection that follows in the sequence (presumably - Backup 1).
- b) The system then attempts to transmit data by the backup connection.
- c) If the initial attempt is unsuccessful, the system will make additional attempts until the data is successfully delivered.
- d) If the system ends up with all unsuccessful attempts, it will switch to the next backup connection in the sequence (presumably - Backup 2) and will continue to operate as described in the previous steps. The connection is considered unsuccessful under the following conditions:
 - 2G/4G network/ELAN3-ALARM – The system has not received the ACK data message from the monitoring station within 40 seconds.
 - Voice calls:
 - The system has not received the “handshake” signal from the monitoring station within 20 seconds.
 - The system has not received the “kiss-off” signal from the monitoring station within 5 attempts each lasting 1 second.
 - PSTN:
 - The system has not received the “handshake” signal from the monitoring station within 20 seconds.
 - The system has not received the “kiss-off” signal from the monitoring station within 5 attempts each lasting 1 second.
 - SMS – The system has not received the SMS delivery report from the SMSC (Short Message Service Center) within 45 seconds.
- e) If one of the attempts is successful, the system will transmit all queued up data messages by this connection.
- f) The system then returns to the primary connection and attempts to transmit the next data messages by primary connection.
- g) If the system ends up with all unsuccessful attempts by all connections, the keypad will indicate system fault and the listed user may be notified by SMS text message (by default - disabled), while the system will hold until the *Delay after last communication attempt* time (by default – 1200 seconds) expires and will return to the primary connection afterwards. Once the repeated data message delivery cycle has started, the system will skip the connections with disabled *Retry after delay* function (permanently enabled for IP communication methods - 2G/4G network and ELAN3-ALARM). In the event of successful data message delivery, the keypad will no longer indicate system fault.
- h) If a new data message, except Test Event (ping), is generated within the *Delay after last communication attempt* time-frame, the system will immediately attempt to transmit it to the monitoring station, regardless of *Delay after last communication attempt* being in progress.



NOTE: The number of attempts indicated in the diagram is the default value.

Set primary connection

EKB2

Menu path:

2G/4G network - Server 1... 3: OK → iiiii → OK → MS SETTINGS → OK → PRIMARY CONNECTION → OK → 2G/4G IP1... IP3 → OK

Voice calls: ... → PRIMARY CONNECTION → OK → VOICE CALLS → OK

PSTN: ... → PRIMARY CONNECTION → OK → PSTN → OK

SMS: ... → PRIMARY CONNECTION → OK → SMS → OK

ELAN3-ALARM - Server 1... 3: ... → PRIMARY CONNECTION → OK → ELAN3-ALARM IP1... IP3 → OK

Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 48 and communication method number:

48 0 # - 2G/4G network - Server 1

48 1 # - Voice calls

48 3 # - PSTN

48 4 # - SMS

48 5 # - ELAN3-ALARM - Server 1

48 6 # - 2G/4G network - Server 2

48 7 # - 2G/4G network - Server 3

48 8 # - ELAN3-ALARM - Server 2

48 9 # - ELAN3-ALARM - Server 3

Example: 484#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Set backup connection 1... 5

EKB2

Menu path:

2G/4G network - Server 1... 3: OK → iiiii → OK → MS SETTINGS → OK → BACKUP CONNECTION1... 5 → OK → 2G/4G IP1... IP3 → OK

Voice calls: ... → BACKUP CONNECTION1... 5 → OK → VOICE CALLS → OK

PSTN: ... → BACKUP CONNECTION1... 5 → OK → PSTN → OK

SMS: ... → BACKUP CONNECTION1... 5 → OK → SMS → OK

ELAN3-ALARM - Server 1... 3: ... → BACKUP CONNECTION1... 5 → OK → ELAN3-ALARM IP1... IP3 → OK

connection not in use: ... → BACKUP CONNECTION1... 5 → OK → N/A → OK

Value: iiiii - 4-digit installer code.

**EKB3/
EKB3W/
EKB4**

Enter parameter 83, backup connection slot number and communication method number:

83 bb 0 # - 2G/4G network - Server 1

83 bb 1 # - Voice calls

83 bb 3 # - PSTN

83 bb 4 # - SMS

83 bb 5 # - ELAN3-ALARM - Server 1

83 bb 6 # - 2G/4G network - Server 2

83 bb 7 # - 2G/4G network - Server 3

83 bb 8 # - ELAN3-ALARM - Server 2

83 bb 9 # - ELAN3-ALARM - Server 3

Value: bb - backup connection slot, range - [01... 05].

Example: 83024#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

If all attempts by all set connections are unsuccessful, the system will wait until the delay time (by default - 1200 seconds) expires and will attempt to transmit data to the monitoring station again starting with the primary connection.

Set delay after last communication attempt

EKB2

Menu path:

OK → **iiii** → OK → MS SETTINGS → OK → DELAY LAST ATTEMPT → OK → **aaapp** → OK

Value: **iiii** - 4-digit installer code; **aaapp** - duration of delay after last attempt, range - [0... 65535] seconds.

EKB3/

EKB3W/

EWKB4

Enter parameter 69 and duration of delay after last attempt:

69 aaapp #

Value: **aaapp** - duration of delay after last attempt, range - [0... 65535] seconds.

Example: 69200#

Eldes

Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: 0 value disables delay after last communication attempt.

NOTE: The system is fully compatible with Kronos NET/Kronos LT/ Securithor monitoring station software for communication via 2G/4G or LAN network. When using a different monitoring station software, EGR100 middleware, which is freeware and can be downloaded at www.eldesalarms.com. Alternatively, you can use ESR100 digital receiver device.

29.2.1. 2G/4G Network and ELAN3-ALARM

ATTENTION: Hybrid alarm control panels ESIM364 and ESIM484 were designed as 2G/4G panels. We do recommend to use Ethernet communicator ELAN3-ALARM for backup purposes only. ELAN3-ALARM can speed up communication and save on 2G/4G costs, but at the same time keeping active SIM card is highly recommended for: Remote connection in case of Internet loss (power or service loss, change of network configuration etc.); Remote Firmware updates (FOTA); Additional communication channels like SMS, phone calls.

The system supports up to 3 server IP addresses for data transmission to the monitoring station via IP-based networks by 2G/4G network or Ethernet connection using ELAN3-ALARM device. The supported data formats are the following:

- EGR100
- Kronos
- SIA IP

To set up the system for data transmission via 2G/4G network or Ethernet using ELAN3-ALARM, please follow the basic configuration steps:

1. Enable MS Mode parameter (see **30. MONITORING STATION**).
2. Set 4-character Main Account number (see **30. MONITORING STATION**). In addition, you may set the Account for up to 3 servers individually.
3. Set Server 1 IP address, which is a public IP address of ESR100 digital receiver, the machine running EGR100, Kronos or SIA IP-based monitoring station software. In addition, you can set up to 3 server IP addresses in total.
4. Set Server 1 port, which is a port of ESR100 digital receiver, the machine running EGR100, Kronos or SIA IP-based monitoring station software. In addition, you may set the port for up to 3 servers individually.
5. Select TCP or UDP protocol for Server 1. In addition, you may select the protocol for up to 3 servers individually.
6. Select data format for Server 1: EGR100, Kronos or SIA IP. In addition, you may select the data format for up to 3 servers individually.
7. In case EGR100 is selected, set 4-digit Unit ID numbers. Unit ID number can be identical to Account number. In addition, you may set the Unit ID for up to 3 servers individually.
8. When using 2G/4G network connection, it is necessary to set up APN, user name and password provided by the 2G/4G operator. Depending on the 2G/4G operator, only APN might be required to set up.
9. In case EGR100 is selected, for security reasons it is highly recommended to set up the 4-digit encryption key matching the 4-digit encryption key set up in EGR100 middle-ware. In case of encryption key mismatch, the data delivered by the system will be rejected by EGR100 middle-ware. By default, the encryption key is not used.
10. In case more than one server IP address is set up, you may wish to enable parallel data transmission to all IP addresses simultaneously. By default, this feature is disabled, therefore the system will switch to the next IP address (if set up and selected in the connection priority sequence) in the event of failed connection with the previous server.

For detailed step-by-step instructions on how to establish the communication between ESIM484 alarm system and EGR100 middleware, please refer to the middleware's HELP file.

Set server IP address

SMS

SMS text message content:

Server 1: **ssss SET2G/4G:IP: add.add.add.add**

Value: **ssss** - 4-digit SMS password; **add.add.add.add** - server IP address.

Example: 1111 SET2G/4G:IP:65.82.119.5

EKB2**Menu path:**

Server 1: OK → **iiii** → OK → MS SETTINGS → OK → IP SETTINGS → OK → SERVER IP → OK → SERVER IP → OK → add.add.add.add → OK

Server 2: ... → SERVER2 IP → OK → SERVER IP → OK → add.add.add.add → OK

Server 3: ... → SERVER3 IP → OK → SERVER IP → OK → add.add.add.add → OK

Value: *iiii* - 4-digit installer code; *add.add.add.add* - server IP address.

**EKB3/
EKB3W/
EKB4****Enter parameter 40 and server IP address/parameter 96, parameter number and server IP address:**

Server 1: **40** add add add add #

Server 2: **96 02** add add add add #

Server 3: **96 03** add add add add #

Value: *add add add add* - server IP address.

Example: 40065082119005#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Set server port**SMS****SMS text message content:**

Server 1: **ssss SET2G/4G:PORT:pprrt**

Value: *ssss* - 4-digit SMS password; *pprrt* - server port number, range - [1... 65535].

Example: 1111 SET2G/4G:PORT:5521

EKB2**Menu path:**

Server 1: OK → **iiii** → OK → MS SETTINGS → OK → IP SETTINGS → OK → SERVER IP → SERVER PORT → OK → pprrt → OK

Server 2: ... → SERVER2 IP → SERVER PORT → OK → pprrt → OK

Server 3: ... → SERVER3 IP → SERVER PORT → OK → pprrt → OK

Value: *iiii* - 4-digit installer code; *pprrt* - server port number, range - [1... 65535].

**EKB3/
EKB3W/
EKB4****Enter parameter 44 and server port number/parameter 96, parameter number and port number:**

Server 1: **44** pprrt #

Server 2: **96 04** pprrt #

Server 3: **96 05** pprrt #

Value: *pprrt* - server port number, range - [1... 65535].

Example: 443365#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Set DNS1 server IP
address****EKB2****Menu path:**

OK → **iiii** → OK → 2G/4G SETTINGS → OK → DNS1 → OK → add.add.add.add → OK

Value: *iiii* - 4-digit installer code; *add.add.add.add* - DNS1 server IP address.

**EKB3/
EKB3W/
EKB4****Enter parameter 41 and DNS1 server IP address:**

41 add add add add #

Value: *add add add add* - DNS1 server IP address.

Example: 41065082119001#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

**Set DNS2 server IP
address****EKB2****Menu path:**

OK → **iiii** → OK → 2G/4G SETTINGS → OK → DNS2 → OK → add.add.add.add → OK

Value: *iiii* - 4-digit installer code; *add.add.add.add* - DNS2 server IP address.

EKB3/
EKB3W/
EWKB4

Enter parameter 42 and DNS2 server IP address:

42 add add add add #

Value: add add add add - DNS2 server IP address.

Example: 42065082119002#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Set protocol

SMS

SMS text message content:

Server 1: ssss SET2G/4G;PROTOCOL:ptc

Value: ssss - 4-digit SMS password; ptc - protocol, range - [TCP...UDP].

Example: 1111 SET2G/4G;PROTOCOL:UDP

EKB2

Menu path:

Server 1: OK → iiiii → OK → MS SETTINGS → OK → IP SETTINGS → OK → SERVER IP → OK → PROTOCOL → OK → TCP | UDP → OK

Server 2: ... → SERVER2 IP → OK → PROTOCOL → OK → TCP | UDP → OK

Server 3: ... → SERVER3 IP → OK → PROTOCOL → OK → TCP | UDP → OK

Value: iiiii - 4-digit installer code.

EKB3/
EKB3W/
EWKB4

Enter parameter 43 and protocol number/parameter 96, parameter number and protocol number:

Server 1: 43 0 # - TCP | 43 1 # - UDP

Server 2: 96 06 0 # - TCP | 96 06 1 # - UDP

Server 3: 96 07 0 # - TCP | 96 07 1 # - UDP

Example: 431#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

**Set data format as
Kronos, EGR100 or
SIA IP**

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

**Manage SIA IP data
format parameters**

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

**Set encryption key
for EGR100 data
format**

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: It is necessary to restart the system locally by powering down and powering up the system the system or remotely (see **34. REMOTE SYSTEM RESTART**) after changing the IP address or switching from TCP to UDP.

NOTE: Kronos NET/Kronos LT software communicates via TCP protocol, while EGR100 middle-ware v1.2 and up supports both - TCP and UDP protocols.

By default, if the initial attempt to transmit data to the monitoring station via 2G/4G network or Ethernet method is unsuccessful, the system will make up to 3 additional attempts. If all attempts are unsuccessful, the system will switch to next backup connection that follows in the sequence and will attempt to transmit data until it is successfully delivered to the monitoring station.

Set attempts

EKB2

Menu path:

Server 1: OK → **iiii** → OK → MS SETTINGS → OK → IP SETTINGS → OK → SERVER IP → OK → IP ATTEMPTS → OK → att → OK

Server 2: ... → SERVER2 IP → OK → IP ATTEMPTS → OK → att → OK

Server 3: ... → SERVER3 IP → OK → IP ATTEMPTS → OK → att → OK

Value: *iiii* - 4-digit installer code; *att* - number of attempts, range - [1... 255].

**EKB3/
EKB3W/
EKB4**

Enter parameter 68 and number of attempts/parameter 96, parameter number and number of attempts:

Server 1: **68 att #**

Server 2: **96 08 att #**

Server 3: **96 09 att #**

Value: *att* - number of attempts, range - [01... 255].

Example: 6809#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

To report the online status, the system periodically transmits (by default - every 180 seconds) Test Event data message (ping) to the monitoring station via 2G/4G network or Ethernet.

Set test period

EKB2

Menu path:

Server 1: OK → **iiii** → OK → MS SETTINGS → OK → IP SETTINGS → OK → SERVER IP → OK → TEST PERIOD → OK → tteesstpp → OK

Server 2: ... → SERVER2 IP → OK → TEST PERIOD → OK → tteesstpp → OK

Server 3: ... → SERVER3 IP → OK → TEST PERIOD → OK → tteesstpp → OK

Value: *iiii* - 4-digit installer code; *tteesstpp* - test period, range - [0... 65535] seconds.

**EKB3/
EKB3W/
EKB4**

Enter parameter 46 and number of attempts/parameter 96, parameter number and number of attempts:

Server 1: **46 tteesstpp #**

Server 2: **96 10 tteesstpp #**

Server 3: **96 11 tteesstpp #**

Value: *tteesstpp* - test period, range - [0... 65535] seconds.

Example: 46120#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: 0 value disables test period. However, disabling the test period is HIGHLY UNRECOMMENDED.

Unit ID is a 4-digit number (By default - 0000) required to identify the alarm system unit by EGR100 middle-ware. It is RECOMMENDED to change the default Unit ID before using EGR100.

Set unit ID

EKB2

Menu path:

Server 1: OK → **iiii** → OK → MS SETTINGS → OK → IP SETTINGS → OK → SERVER IP → OK → UNIT ID → OK → unid → OK

Server 2: ... → SERVER2 IP → OK → UNIT ID → OK → unid → OK

Server 3: ... → SERVER3 IP → OK → UNIT ID → OK → unid → OK

Value: *iiii* - 4-digit installer code; *unid* - 4-digit unit ID number.

**EKB3/
EKB3W/
EKB4**

Enter parameter 47 and unit ID number/parameter 96, parameter number and unit ID number:

Server 1: **47 unid #**

Server 2: **96 14 unid #**

Server 3: **96 15 unid #**

Value: *unid* - 4-digit unit ID number.

Example: 472245#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

For communication via 2G/4G network, the 2G/4G parameters provided by the 2G/4G operator are necessary to be set up. To set those parameters, please refer to the following configuration methods.

Set APN	SMS	<p>SMS text message content: <code>ssss SET2G/4G:APN:acc-point-name</code></p> <p>Value: ssss - 4-digit SMS password; <i>acc-point-name</i> - up to 31 character APN (Access Point Name) provided by the 2G/4G operator. Example: 1111 SET2G/4G:APN:internet</p>
	Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .
Set user name	SMS	<p>SMS text message content: <code>ssss SET2G/4G:USER:usr-name</code></p> <p>Value: ssss - 4-digit SMS password; <i>usr-name</i> - up to 31 character user name provided by the 2G/4G operator. Example: 1111 USER:mobileusr</p>
	Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .
Set password	SMS	<p>SMS text message content: <code>ssss SET2G/4G:PSW:password</code></p> <p>Value: ssss - 4-digit SMS password; <i>password</i> - up to 31 character password provided by the 2G/4G operator. Example: 1111 SET2G/4G:PSW:mobilepsw</p>
	Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .
View IP and 2G/4G network settings	SMS	<p>SMS text message content: <code>ssss SET2G/4G?</code></p> <p>Example: 1111 SET2G/4G?</p>
	EKB2	<p>Menu path: Server IP: OK → <code>iiii</code> → OK → MS SETTINGS → OK → IP SETTINGS → OK → SERVER IP... SERVER 2... 3 IP → OK → SERVER IP</p> <p>Server port: OK → <code>iiii</code> → OK → MS SETTINGS → OK → IP SETTINGS → OK → SERVER IP... SERVER 2... 3 IP → OK → SERVER PORT</p> <p>DNS1: OK → <code>iiii</code> → OK → 2G/4G SETNGS → OK → DNS1</p> <p>DNS2: OK → <code>iiii</code> → OK → 2G/4G SETNGS → OK → DNS2</p> <p>Protocol: OK → <code>iiii</code> → OK → MS SETTINGS → OK → IP SETTINGS → OK → SERVER IP... SERVER 2... 3 IP → OK → PROTOCOL</p> <p>APN: OK → <code>iiii</code> → OK → 2G/4G SETTINGS → OK → APN</p> <p>User name: OK → <code>iiii</code> → OK → 2G/4G SETTINGS → OK → USERS</p> <p>Password: OK → <code>iiii</code> → OK → 2G/4G SETTINGS → OK → PASSWORD</p> <p>Value: <i>iiii</i> - 4-digit installer code.</p>
	Eldes Utility	This operation may be carried out from the PC using the <i>Eldes Utility</i> .

Enable parallel data transmission

EKB2

Menu path:

OK → **iiii** → OK → MS SETTINGS → OK → IP SETTINGS → OK → PARAL.DS.MODE → OK → ENABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter command 96, parameter number and parameter status value:

96 01 1 #

Example: 96011#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Disable parallel data transmission

EKB2

Menu path:

OK → **iiii** → OK → MS SETTINGS → OK → IP SETTINGS → OK → PARAL.DS.MODE → OK → DISABLE → OK

Value: *iiii* - 4-digit installer code.

**EKB3/
EKB3W/
EWKB4**

Enter command 96, parameter number and parameter status value:

96 01 0 #

Example: 96010#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

29.2.2. Voice Calls

The system supports up to 3 monitoring station phone numbers for communication with the alarm system by Voice Calls communication method using Ademco Contact ID. Tel. Number 1 is mandatory, the other two can be used as backup phone numbers and are not necessary. The supported phone number formats are the following:

- **International (with plus)** - The phone numbers must be entered starting with plus and an international country code in the following format: +[international code][area code][local number], example for UK: +44170911XXXX1. This format can be used when setting up the phone number by *Eldes Utility*.
- **International (with 00)** - The phone numbers must be entered starting with 00 and an international country code in the following format: 00[international code][area code][local number], example for UK: 0044170911XXXX1. This format can be used when setting up the phone number by EKB2/EKB3/EKB3W/EWKB4 keypad.
- **Local** - The phone numbers must be entered starting with an area code in the following format: [area code][local number], example for UK: 0170911XXXX1. This format can be used when setting up the phone number by EKB2/EKB3/EKB3W/EWKB4 keypad and *Eldes Utility*.

To set up the system for data transmission via Voice Calls, please follow the basic configuration steps:

1. Enable MS Mode parameter (see **30. MONITORING STATION**).
2. Set 4-digit Main Account number (see **30. MONITORING STATION**).
3. Set Tel. Number 1... 3.

Set monitoring station phone number

EKB2

Menu path:

OK → **iiii** → OK → MS SETTINGS → OK → VOICE CALLS/SMS ST → OK → TEL. NUMBER 1... 3 → OK → **ttteeellnnuumm** → OK

Value: *iiii* - 4-digit installer code; *ttteeellnnuumm* - up to 15 digits monitoring station phone number.

**EKB3/
EKB3W/
EWKB4**

Enter parameter 26, phone number slot and phone number:

26 ps ttteeellnnuumm #

Value: *ps* - phone number slot, range - [01... 03]; *ttteeellnnuumm* - up to 15 digits monitoring station phone number.

Example: 26010044170911XXXX1#

**Eldes
Utility**

This operation may be carried out from the PC using the *Eldes Utility*.

Delete monitoring station phone number

EKB2

Menu path:

OK → *iiii* → OK → MS SETTINGS → OK → VOICE CALLS/SMS ST → OK → TEL. NUMBER 1... 3 → OK → OK

Value: *iiii* - 4-digit installer code.

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

By default, if the initial attempt to transmit data to the monitoring station's Tel Number 1 via Voice Calls or SMS method is unsuccessful, the system will make up to 2 additional attempts. After all unsuccessful attempts, the system will continue to communicate with the monitoring station by switching to the next phone number that follows in the sequence and making up to 2 additional attempts if the initial attempt was unsuccessful. If all attempts to all phone numbers are unsuccessful, the system will switch to next backup connection that follows in the sequence and will attempt to transmit data until it is successfully delivered to the monitoring station.

Set attempts

EKB2

Menu path:

OK → *iiii* → OK → MS SETTINGS → OK → VOICE CALLS/SMS ST → OK → ATTEMPTS → OK → at → OK

Value: *iiii* - 4-digit installer code; *at* - number of attempts, range - [1... 10].

EKB3/
EKB3W/
EWKB4

Enter parameter 37 and number of attempts:

37 at #

Value: *at* - number of attempts, range - [01... 10].

Example: 3706#

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Due to the individual configuration of each monitoring station, the system may fail to deliver the data message via Voice Calls communication method. In such cases it is recommended to adjust the speaker level until the optimal value is discovered, leading to successful data message delivery.

ATTENTION: When using the SMS data transmission method, the system will notify the monitoring station and the user once the SMS delivery limit is exceeded. In such case, the system will no longer be able to send out any SMS text messages neither to the monitoring station nor to the user, unless the SMS text message delivery limit is reset by the user or automatically. For more details, please refer to **27.1. SMS Text Message Delivery Restrictions**.

29.2.3. PSTN

The system supports up to 3 monitoring station phone numbers for communication with the alarm system by PSTN communication method using Ademco Contact ID data format. Tel. Number 1 is mandatory, the other two can be used as backup phone numbers and are not necessary. The supported phone number formats are the following:

- **International (with 00)** - The phone numbers must be entered starting with 00 and an international country code in the following format: 00[international code][area code][local number], example for UK: 0044170911XXXX1. This format can be used when setting up the phone number by EKB2/EKB3/EKB3W/EWKB4 keypad and *Eldes Utility*.
- **Local** - The phone numbers must be entered starting with an area code in the following format: [area code][local number], example for UK: 0170911XXXX1. This format can be used when setting up the phone number by EKB2/EKB3/EKB3W/EWKB4 keypad and *Eldes Utility*.

To set up the system for data transmission via PSTN, please follow the basic configuration steps:

1. Enable MS Mode parameter (see **30. MONITORING STATION**).
2. Set 4-digit Main Account number (see **30. MONITORING STATION**).
3. Set Tel. Number 1... 3.

Set monitoring station phone number

EKB2 **Menu path:**
OK → *iiii* → OK → MS SETTINGS → OK → PSTN SETTINGS → OK → TEL. NUMBER 1... 3 → OK → *ttteeellnnuumm* → OK
Value: *iiii* - 4-digit installer code; *ttteeellnnuumm* - up to 15 digits monitoring station phone number.

**EKB3/
EKB3W/
EWKB4** **Enter parameter 58, phone number slot and phone number:**
58 *ps ttteeellnnuumm #*
Value: *ps* - phone number slot, range - [01... 03]; *ttteeellnnuumm* - up to 15 digits monitoring station phone number.
Example: 58020044170911XXXX1#

Eldes Utility This operation may be carried out from the PC using the *Eldes Utility*.

Delete monitoring station phone number

EKB2 **Menu path:**
OK → *iiii* → OK → MS SETTINGS → OK → PSTN SETTINGS → OK → TEL. NUMBER 1... 3 → OK → OK
Value: *iiii* - 4-digit installer code.

Eldes Utility This operation may be carried out from the PC using the *Eldes Utility*.

By default, if the initial attempt to transmit data to the monitoring station's Tel Number 1 via PSTN method is unsuccessful, the system will make up to 2 additional attempts. After all unsuccessful attempts, the system will switch to the next phone number that follows in the sequence and will make up to 2 additional attempts if the initial attempt was unsuccessful. If all attempts to all phone numbers are unsuccessful, the system will switch to next backup connection that follows in the sequence and will attempt to transmit data until it is successfully delivered to the monitoring station.

Set attempts

EKB2 **Menu path:**
OK → *iiii* → OK → MS SETTINGS → OK → PSTN SETTINGS → OK → ATTEMPTS → OK → *at* → OK
Value: *iiii* - 4-digit installer code; *at* - number of attempts, range - [1... 10].

**EKB3/
EKB3W/
EWKB4** **Enter parameter 91 and number of attempts:**
91 *at #*
Value: *at* - number of attempts, range - [01... 10].
Example: 9108#

Eldes Utility This operation may be carried out from the PC using the *Eldes Utility*.

Alternatively, the phone number entries can be treated as phone numbers for receiving calls in case of alarm. For more details on how this method operates, please refer to **17. ALARM INDICATIONS AND NOTIFICATIONS FOR USER**.

To enable/disable this feature, please refer to the following configuration method.

Enable/disable Treat
PSTN Call as User Call

Eldes
Utility

This operation may be carried out from the PC using the *Eldes Utility*.

30. WIRED DEVICES

30.1. RS485 Interface

The system comes equipped with RS485 interface used for the communication with the following devices:

- EKB2 - LCD keypad. Up to 4 units supported.
- EKB3 - LED keypad. Up to 4 units supported.
- EPGM1 - hardwired zone and PGM output expansion module. Up to 2 units.
- ELAN3-ALARM - Ethernet communicator. 1 unit supported.

The terminals of RS485 interface are Y (yellow wire) and G (green wire) terminals, which are data bus. The devices, connected to RS485 interface, must be powered from the AUX+ and AUX- terminals or by an external power supply.

For more details on RS485 device wiring, please refer to **3.2.7. RS485**.

For more details on technical specifications and installation, please refer to the latest user manual of the device located at

www.eldesalarms.com

30.1.1. EKB2 - LCD Keypad









Main features:


- Alarm system arming and disarming (see **12.3. EKB2 Keypad and User/Master Code**).
- Arming and disarming in Stay mode (see **15. STAY MODE**).
- System parameter configuration (see **5. CONFIGURATION METHODS**).
- PGM output control (see **18.4. Turning PGM Outputs ON and OFF**).
- System information display (see **32.1.1.1. Icons and Messages**).
- Audio indication by built-in buzzer.
- Wireless device information display (see **19.2. Wireless Device Information and Signal Status Monitoring**).
- Temperature display (see **32.1.1.1. Icons and Messages**).
- Time display (see **32.1.1.1. Icons and Messages**).


For more details on technical specifications and installation, please refer to the latest user manual of the device located at


www.eldesalarms.com

30.1.1.1. Icons and Messages


Icon / Message	Description
 (by default - disabled)	Partition is armed and menu is locked
 (by default - disabled)	Partition is disarmed and menu is unlocked
	Configuration mode activated
!!!	Zone or tamper alarm in partition
✓	Partition is ready to be armed.
X	Partition is not ready to be armed - one or more zones / tampers violated.
	One or more system faults present
	One or more violated zones bypassed
	One or more partitions STAY-armed
	One or more Fire-type zones violated
	Alarms in alarm log present
SERVICE MODE	Service mode activated









see **32.1.1.3. Installer Menu Tree**







Continued from previous page




Continued on next page



Continued on next page



Continued on next page







30.1.2. EKB3 - LED Keypad

Main features:





- Alarm system arming and disarming (see **12.4. EKB3 Keypad and User/Master Code**).
- Arming and disarming in Stay mode (see **15. STAY MODE**).
- System parameter configuration (see **5. CONFIGURATION METHODS**).
- PGM output control (see **18.4. Turning PGM Outputs ON and OFF**).
- Visual indication by LED indicators (see **32.1.2.1. LED Functionality**).
- Audio indication by built-in buzzer.
- Keypad partition switch (see **23.3. Keypad Partition and Keypad Partition Switch**).


For more details on technical specifications and installation, please refer to the latest user manual of the device located at www.eldesalarms.com

30.1.2.1. LED Functionality

	INDICATION	DESCRIPTION
 (red)	Steady ON	System armed / exit delay in progress
	Flashing	Configuration mode activated
 (green)	Steady ON	System is ready - no violated zones and/or violated tampers exist
	Flashing	Violated high-numbered zone
 (orange)	Steady ON	System faults exist
	Flashing	Violated zone bypassed
 (orange)	Steady ON	Zone violated / configuration command being typed in
	1-12 (red)	

30.1.2.2. Keys Functionality

	DESCRIPTION
	1st character for STAY-arming
	1st character for violated zone bypass and bypassed zone activation
	1st character for Configuration mode activation or deactivation
	1st character for system fault list indication / 1st character for violated high-numbered zone indication / 1st character for violated tamper indication
0 - 9	Command typing
	Keypad partition switch
1 - 4	LED indication
	Steady ON: partition armed Flashing: partition violated
0	Simultaneous 4-partition arming
*	Clear typed in characters
#	Typed in command confirmation



30.2. 1-Wire Interface

1-Wire interface is used for the system to communicate with an iButton key reader and up to 8 temperature sensors. 1-Wire interface COM and DATA terminals are ground and data respectively. When connecting single or multiple temperature sensors, the +5V terminal must be used along.

For more details on 1-Wire device wiring, please refer to **2.3.4. iButton Key Reader and Buzzer** and **2.3.5. Temperature Sensor and iButton Key Reader**.

31. SERVICE MODE

The system comes equipped with Service mode allowing to carry out system maintenance tasks, such as detection device replacement, tamper switch installation, wireless device battery replacement without causing zone or tamper alarm when Service mode is activated. To activate/deactivate Service mode, please refer to the following configuration methods:

Activate Service mode

SMS

SMS text message content:

ssss SERVICEMODE:ON

Value: ssss - 4-digit SMS password.

Example: 1111 SERVICEMODE:ON

EKB2

Menu path:

OK → iiiii → OK → SERVICE MODE → OK → ENABLE → OK

Value: iiiii - 4-digit installer code.

EKB3/
EKB3W/
EWKB4

Enter parameter 67 and parameter status value:

67 1 #

Example: 671#

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

Deactivate Service mode

SMS

SMS text message content:

ssss SERVICEMODE:OFF

Value: ssss - 4-digit SMS password.

Example: 1111 SERVICEMODE:OFF

EKB2

Menu path:

OK → iiiii → OK → SERVICE MODE → OK → DISABLE → OK

Value: iiiii - 4-digit installer code.

EKB3/
EKB3W/
EWKB4

Enter parameter 67 and parameter status value:

67 0 #

Example: 670#

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

NOTE: Alternatively, the Service mode automatically deactivates when 1-hour timeout period expires or after arming the system.

32. REMOTE SYSTEM RESTART

In some critical situations, a system restart may be required. To remotely carry out system restart, please refer to the following configuration method.

Restart the system

SMS

SMS text message content:

ssss RESET

Value: ssss - 4-digit SMS password.

Example: 1111 RESET

33. ELDES CLOUD SERVICES

ELDES Cloud Services is a cloud-based platform providing a user-friendly graphical interface intended for system status monitoring and control:

- Arm/disarm the system
- View system faults and alerts
- Monitoring temperature, 2G/4G signal strength and backup battery level (these last two features are available for Administrator only).
- Control electrical appliance connected to the PGM outputs

The connection with the platform can be established via 2G/4G network and can be accessed via smartphone application Eldes Security, developed for Android and iOS-based devices (iPhone, iPad).

In order to start using ELDES Cloud Services, please enable it using the following configuration methods.

Enable ELDES Cloud Services

SMS

SMS text message content:

ssss SMART:ON

Value: ssss - 4-digit SMS password.

Example: 1111 SMART:ON

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

To begin using new Eldes Security app, you will have to visit Google Play store (Android) or App Store (iOS) and download the application (or update it to the latest version!), install the application on your smartphone, launch the app (open it) and sign in or create your new personal account. Then log in to your ELDES Cloud Services account and add a device by following the step-by-step instructions provided on our website www.eldesalarms.com. When adding the device to your account, you will be prompted for ELDES Cloud Services ID, which can be obtained using Eldes Utility software or by sending the following SMS text message to the system's phone number.

Request for ELDES Cloud Services ID

SMS

SMS text message content:

ssss SMART ID

Value: ssss - 4-digit SMS password.

Example: 1111 SMART ID

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

To disable ELDES Cloud Services, please refer to the following configuration methods.

Disable ELDES Cloud Services

SMS

SMS text message content:

ssss SMART:OFF

Value: ssss - 4-digit SMS password.

Example: 1111 SMART:OFF

Eldes Utility

This operation may be carried out from the PC using the *Eldes Utility*.

ATTENTION: In case you DO NOT wish to use ELDES Cloud Services and your device is not associated with any ELDES Cloud Services account, please **DO NOT** leave ELDES Cloud Services enabled. Otherwise **additional charges may apply** for data traffic based on your cell phone service plan.

NOTE: Additional charges may apply for data traffic based on your cell phone service plan when using ELDES Cloud Services platform.

NOTE: ELDES Cloud Services platform will remain operational even when using Automatic or Manual dual-SIM modes.

34. IP cameras support

ESIM484 offers a possibility to enable video monitoring, by adding any type of IP cameras via Eldes Security app (limitless number of cameras for a single location). For more information about this solution, please visit our website:

<https://eldesalarms.com/rtp-possibilities/>

35. TECHNICAL SUPPORT

35.1. Troubleshooting

Indication	Possible reason
Indicator STAT is off	<ul style="list-style-type: none">· No mains power· Wiring done improperly· Blown fuse
Indicator NETW is off or flashing	<ul style="list-style-type: none">· Missing SIM card· PIN code is enabled· SIM card is inactive· Disconnected antenna· 2G/4G network signal too weak· 2G/4G network unavailable· Microcontroller is not started due to electrical mains noise or static discharge
System does not send any SMS text messages and/or does not ring	<ul style="list-style-type: none">· SIM card credit balance depleted· Incorrect SMS centre phone number· No 2G/4G network signal· User number is not added (or function "system's remote connection from any phone number" is disabled)· SIM card changed before disconnecting main power supply or backup battery
Received SMS text message "Wrong syntax"	<ul style="list-style-type: none">· Incorrect SMS text message structure· Extra space character might be typed in SMS text message
Missing temperature indication in Info SMS text message/EKB2 keypad	<ul style="list-style-type: none">· Temperature sensor not connected· Temperature sensor broken· Connection wires too long
24H and/or Fire zones do not work	<ul style="list-style-type: none">· Specified zone must be enabled by SMS, <i>Eldes Utility</i>, EKB2, EKB3 or EKB3W/EWKB4

For product warranty repair service please , contact your local retail store where this product was purchased. If your problem could not be fixed by the self-guide above, please contact your local distributor. More up to date information about your device and other products can be found at the manufacturer's website www.eldesalarms.com

35.2. Restoring Default Parameters

1. Disconnect the power supply and backup battery.
2. Short circuit (connect) DEF pins.
3. Power up the device for 7 seconds.
4. Power down the device.
5. Remove short circuit from DEF pins.
6. Parameters restored to default.

35.3. Updating the Firmware via USB Cable Locally

1. Disconnect the power supply and backup battery.
2. Short circuit (connect) DEF pins.
3. Connect the device via USB cable to the PC.
4. The new window must pop-up where you will find the .bin file. Otherwise open *My Computer* and look for *Boot Disk* drive.
5. Delete the .bin file found in the drive.
6. Copy the new firmware .bin file to the very same window.
7. Power down the device.
8. Unplug USB cable.
9. Remove short circuit from DEF pins.
10. Power up the device.
11. Firmware updated.

35.4. Updating Firmware via 2G/4G Connection Remotely

ATTENTION: The system will NOT transmit any data to monitoring station while updating the firmware remotely via 2G/4G network. All data messages will be lost and will NOT be transmitted to the monitoring station after the firmware upgrade process is over.

ATTENTION: Each night, the device checks for updates and installs them if needed. As long as the SIM card is connected to ELDES Cloud, you don't need to worry about updates – the firmware will be updated automatically via FOTA.

Before updating the firmware remotely via 2G/4G connection, make sure that:

- SIM card is inserted into SIM CARD slot of ESIM484 device (see **2.2. Main Unit, LED and Connector Functionality**).
- Mobile internet service (2G/4G) is enabled on the SIM card.
- Power supply is connected to ESIM484.
- Default SMS password is changed to a new 4-digit password (see **6. SMS PASSWORD AND INSTALLER CODE**).
- At least User 1 phone number is set up (see **8. USER PHONE NUMBERS**).
- APN, user name and password are set up (see **30.2.1. 2G/4G Network and ELAN3-ALARM**).

Initiate FOTA manually

ESIM484 alarm system supports FOTA (firmware-over-the-air) feature. This allows to upgrade the firmware remotely via 2G/4G connection. Once the upgrade process is initiated, the system connects to the specified FTP server address where the firmware file is hosted and begins downloading and re-flashing the firmware. The firmware file must be located in a folder titled **firmware** (folder's title MUST be written in non-capital letters). In order to initiate the upgrade process, please send the following SMS message.

SMS

SMS text message content:

ssss FOTA

Value: ssss - 4-digit SMS password.

Example: 1111 FOTA

Notice that latest firmware file can be obtained from www.eldesalarms.com

ATTENTION: Firmware filename MUST be renamed in lowercase format before using it.

ATTENTION: Comma and underscore character is NOT allowed to use in user name, password and firmware file name.

35.5. Frequently Asked Questions

Question	Answer
1. Can ESIM484 operate as standalone device without SIM card inserted?	Yes, ESIM484 device can fully operate without any SIM card inserted. In this case you will not be able to configure and control the device by SMS and calls nor to receive any SMS reports and calls.
2. I am unable to arm the alarm system when one of the zones (some zones) is violated. Is there a way to arm the alarm system while the zone is violated?	Due to security reasons it is recommended to restore the violated zone (-s) before arming the alarm system. However, you can enable a Force attribute or use the Bypass feature in order to arm the alarm system despite the violated zone (-s) being present. Please, refer to 14.5. Zone Type Definitions and 14.7. Bypassing and Activating Zones .
3. When ESIM484 fully powers down my configuration becomes lost and I have to re-configure the device again. What's wrong?	This might have happened due to the jumper left on DEF pins or it is a hardware failure. Please, remove the jumper if it is present on DEF pins or contact your supplier for warranty service.
4. I have a smoke detector connected to ESIM484 system. How do I reset the smoke detector when the "Fire" zone is violated?	If the smoke detector is connected to one of the ESIM484 PGM outputs you can reset it by turning the PGM output OFF and then back ON. This can be performed by SMS, EKB2 keypad, EKB3 keypad, EKB3W/EWKB4 keypad and <i>Eldes Utility</i> . Please, refer to 18.4. Turning PGM Outputs ON and OFF .
5. What happens if I switch backup battery pole terminals places?	Switching backup battery pole terminals places is forbidden. Otherwise this will lead to blown fuse and ESIM484 alarm system will have to be repaired.
6. How do I disable SMS reports and calls in case of tamper violation when alarm system is disarmed?	The SMS reports on tamper violation can be disabled by EKB2, EKB3, EKB3W/EWKB4 keypads or <i>Eldes Utility</i> . For more details, please refer to 16. TAMPERS or to the software's HELP section. However, due to security reasons it is not recommended to disable this feature.
7. Is any additional configuration necessary when connecting EPGM1 module after wiring is done according to EPGM1 user manual?	No additional configuration is required in order to make EPGM1 module operational.
8. Does the number of EPGM1 zones duplicate when ATZ mode is activated in the system?	No, the number of EPGM1 zones does not duplicate in ATZ mode as EPGM1 module does not support ATZ mode. Only ESIM484 on-board zones duplicate in ATZ mode.

Question	Answer
9. I connect the wired siren to ESIM484 and I hear a silent sound alarm even when the alarm system is disarmed. In case of alarm system alarm the siren provides a loud sound alarm as it should. Why?	Please, connect the resistor of 3,3 kΩ nominal to the BELL- / BELL+ contacts. This should solve the problem.
10. The buzzer remains active when I disarm the alarm system using the keypad. Why?	The buzzer is intended for iButton indication only and it is not related to disarming process by keypad.
11. One of wireless devices connected to ESIM484 system sends a tamper alarm from time to time, although no tamper was violated. Why?	This happens due to wireless connection loss. There might be several reasons: <ol style="list-style-type: none"> 1. ELDES wireless device is installed too close or too far from ESIM484 system. 2. Interference of other electronic equipment. 3. Physical interference (building walls, floors etc.) 4. Metal material interference.
12. I have connected a wired magnetic door sensor, but I receive tamper alarm instead of zone alarm. What's wrong?	This happens due to incorrect resistor connection. Please, refer to corresponding connection circuit according to the selected zone connection type (Type 1 - 5). See 2.3.2 Zone Connection Types for more details.
13. I disconnected the backup battery, but did not receive any SMS report on this event. How do I enable SMS report on backup battery disconnection?	By default, this notification is enabled. The system checks the backup battery resistance once a day and sends an SMS report to User 1 on backup battery replacement if more than 2Ω resistance is detected. For more details, please refer to 21. BACKUP BATTERY, Mains power STATUS MONITORING AND MEMORY .
14. I have set zone names and/or PGM output names containing some Cyrillic and/or non-English characters. The zone names and PGM output names do not fully fit in the SMS message. What's wrong?	According to 2G/4G standards 1 SMS text message may consist of up to 160 Latin alphabet/English characters maximum. If the message contains at least one non-latin/non-English character, the length of SMS message becomes at least half shorter, since those characters occupy more size of the SMS text message than the Latin ones. It is recommended not to use any non-Latin/ non-English characters in zone names and PGM output names.
15. I am unable to run <i>Eldes Utility</i> - I receive error messages in Windows. Why?	Microsoft .NET Framework v3.5 is not installed in Windows system. Please, download this package from official Microsoft website free of charge and install it to your Windows system. Also, if you are using our new Eldes Utility software, you need to check the Open GL version that is used on your PC. The Open GL version must be v2.0 or higher.
16. Info SMS report comes with wrong date and time. How do I correct it?	Please, set the correct system date and time using either <i>Eldes Utility</i> , EKB2, EKB3, EKB3W/EWB4 or SMS text message.
17. I receive an error message when attempting to configure the device or update the firmware remotely. What's wrong?	It appears that the device is unable to establish a communication with configuration / FTP server. Please, check the 2G/4G settings in ESIM484 configuration (APN, user name, password), the location of the firmware file (must be located in the FTP server folder titled Firmware) and the mobile internet feature presence on the SIM card used with ESIM484. If this does not solve the problem, please contact your 2G/4G operator (and ISP - for remote configuration problems) in order to request a list of blocked TCP ports.
18. I waited for at least 5 minutes, but did not receive any SMS message confirming that remote configuration via 2G/4G connection has stopped. What's wrong?	<ol style="list-style-type: none"> 1. Send the <i>ssss endconfig</i> SMS text message. 2. In <i>Eldes Utility</i> press Disconnect button and repeat the procedure as described in 5.4.1. Remote Connection.
19. The SMS password is changed and I have User 1 phone number added. However, whenever I send a text message, such as <i>ssss INFO</i> the system always replies with „Wrong password“. What's wrong?	Most likely you have wrong character encoding set up in your SMS text messaging settings on your smart-phone. Please, ensure that you have 2G/4G Alphabet selected, NOT Unicode or any other type of character encoding.

36. RELATED PRODUCTS




EKB2 - LCD keypad



EKB3 - LED keypad



ME1 - metal cabinet



EPGM1 - hardwired zone and PGM output expansion module



DS1990A-F5 - iButton key



DS18S20 - temperature sensor



ED1T - plastic enclosure with iButton key reader and temperature sensor



EWS4 - wireless external siren



EWF1 - wireless smoke detector
EWF1CO - wireless smoke and CO detector



EKB3W/EWKB4 - wireless LED keypad



EWK3 - wireless key fob



EWD2 - wireless door contact/shock sensor/flood sensor



EWS3 - wireless indoor siren



EWD3 - wireless door contact/shock sensor/flood sensor



EW2 - wireless zone and PGM output expansion module



EWP2/EWP3 - wireless motion detector



Vinson DS18B20 - digital thermometer
with 3m (9.84ft) wire



ESR100 - digital receiver

37. GLOSSARY - APPENDIX 1

TERM	DESCRIPTION
AC	Alternating current is an electric current that reverses its direction of flow at regular intervals.
Actuator	A mechanism of the switch or switch enclosure that operates the contacts.
Alarm Log	Contains information about alarms that are currently active on the system or information about alarms that have been raised and then resolved on the system. This log can be useful in analyzing problems and trends in the system.
Ampere (A)	The electrical rate of flow in a circuit.
Arming/Disarming	A process of enabling/disabling system's security.
Backup battery	The secondary power source of the system. In case of a main power failure, the backup battery will take over.
Bell squawk	If enabled, the siren/bell indicates the completed system arming and disarming process (except the arming in STAY mode). After the system is successfully armed, the siren/bell will emit 2 short beeps and 1 long beep after the system is disarmed. By default, the parameter is disabled.
Bypass/Activate Zone	Zone bypassing allows the user to deactivate a violated zone and arm the system without restoring the zone. If a bypassed zone is violated or restored during exit/entry delay, or when then system is armed, it will be ignored. The zone will remain bypassed until the system is disarmed. Zones can only be bypassed and activated when the system is not armed.
Circuit	A complete path, or closed loop, that electricity requires to flow and do work.
Confirmation timeout	Specifies the time in which a cross zone must be violated that the system could confirm alarm on the associated zone.
Current	An electrical rate of flow, measured in amperes.
DC	Direct current is an electric current that flows in one direction.
Diagnostic Tool	When using Eldes Utility, you may use an additional section of functions, that allows to monitor real-time zones, view changes of peripheral devices, instantly configure necessary options, for example, enabling/disabling PGM outputs, etc.
Eldes Cloud Services	A cloud-based platform providing a user-friendly graphical interface intended for system status monitoring and control.
Entry Delay	Once the exit delay has expired, the system initiates the entry delay countdown if a Delay type zone is violated. The countdown is indicated by short beeps emitted by keypad buzzer and by steady beep emitted by system's buzzer. The indication is intended to advise the user that the system should be disarmed. When the user presses/touches any key on the keypad during this delay, the buzzer of the keypad will be silenced. If the system is disarmed before the entry delay expires, no alarm will be caused. Default value is 15 seconds.
Event Log	A list of system events that is uploaded from the device's memory to the Eldes Utility software for further analysis. The system logs all information about system configuration, system actions and info messages. By default, the parameter is enabled. The event log is of FIFO (first in, first out) type that allows the system to automatically replace the oldest records with the latest ones.
Exit Delay	A period of time intended for user to leave the secured area. The system begins the countdown after the arming process initiation.
Fault	A specific problem or error that prevents the system from working properly. The system comes equipped with self-diagnostic feature allowing to indicate the presence of any system fault by the keypad as well as by SMS text message notification to the listed user phone number.
Fuse	An element or a protective mechanism, that is destroyed when excessive current flows through a circuit, thereby protecting the circuit.
iButton key	A unique 64-bit ID code containing chip enclosed in a stainless steel tab usually implemented in a small plastic holder. ESIM484 system supports up to 16 iButton keys each holding a unique identity code (ID), which is used for system arming and disarming.
Input	The voltage, current, or power applied to an electrical circuit to produce a desired result.

TERM	DESCRIPTION
Keybus	A circuit (usually 4-wire) which provides power and serial data connection between keypads and other accessories and the alarm panel.
Key fob	A small security hardware device with built-in authentication used for system's security control
LED	Stands for "Light emitting diode", defined as a solid-state light source that emits variable light, or invisible, infrared radiation.
Main Power	The main power source of the system.
Master/User Code	Allows to carry out system arming/ disarming as well as minor system configuration and control by the keypad.
MS mode	is mode that enables data transmission from the ESIM484 alarm system to the monitoring station.
Normally closed (NC)	is a switch that passes current until actuated.
Normally open (NO)	is a switch that must be actuated to pass current.
On-board	is some element that is installed and functional within a device (system).
Partition	System comes equipped with a partitioning feature that can divide the alarm system into a number of independently controlled areas identified as Partition 1 through 4, which are all supervised by one alarm system unit. Partitioning can be used in installations where shared alarm system is more practical, such as a house and a garage or within a single multi-storey building. When partitioned, each system element, like zone, user phone number, keypad, user password, iButton key and EWK2 wireless key fob can be assigned to single or multiple partitions. The user will then be able to arm/disarm the system partition (-s) that the zones and arm/disarm method, except EKB2 keypad, are assigned to.
Periodic Test Event	Provides the following information on alarm system: date & time, status (armed/disarmed), 2G/4G signal strength, mains power supply status, temperature value measured by primary and secondary temperature sensors (if any). The system sends this information to User 1 at the time intervals programmed into the schedule.
Peripheral device	A peripheral device is defined as a device, such as a keyboard, that is not part of the essential system i.e., the memory and microprocessor. These devices are intended to be connected to the system and used.
PGM output	A PGM output is a programmable output that toggles to its set up state when a specific event has occurred in the system, the scheduled weekday and time has come or if the user has initiated the PGM output state change manually.
Ping period	Sets period of time defining how often ESIM484 sends ping data packet to the Cloud Services server.
Protocol	A formal specification for communicating; an IP address the special set of rules that end points in a telecommunication connection use when they communicate. Protocols exist at several levels in a telecommunication connection.
Relay	is an electromagnetic device opted for remote or automatic control that is actuated by variation in conditions of an electric circuit and that operates in turn other devices (as switches) in the same or a different circuit.
Schedule	Through the use of the system's built-in clock, it is possible to schedule automatic operations such as setting and unsetting output state.
Service mode	Mode that should be used when it is necessary to re-install some of the peripheral devices (to change batteries, open/close enclosure and etc.). In this mode, system does not check for tamper faults so it won't start siren alarm or send specified notifications to monitoring station or by SMS text messages to users. Service Mode can be enabled only when system is disarmed.
SMS forward	System can re-sent all incoming SMS messages to the specified users. It is useful if the 2G/4G operator of the inserted SIM card sends some useful information (SIM card validation or payment account status and etc.) or it is necessary to monitor all incoming SMS messages by specified user.
Tamper	The tamper circuit is a single closed loop such that a break in the loop at any point will cause a tamper alarm regardless of the system status - armed or disarmed.
Transformer	A device formed by two or more windings, that are magnetically coupled to each other and provide a transfer of power electromagnetically from one winding to another.

TERM	DESCRIPTION
Trigger	An event which causes another event or action, often initiating a signal generation or acquisition.
Volt	The unit of voltage or electromotive force
Voltage	The amount of energy available to move a certain number of electrons from one point to another in an electric circuit
Wireless device	Devices that communicate without connecting wires or other material contacts.
Zone	Detection devices such as motion detectors and door contacts are connected to the alarm system's zone terminals.
Zone state/status	Zone status is a position of a certain zone being enabled or disabled. Meanwhile, zone state points out the condition of a certain zone, which can either be violated (i.e. In case of alarm) or restored.

38. EKB3/EKB3W/EWKB4 COMMANDS - APPENDIX 2

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
Arm the system in Stay mode	🏠 uumm	uumm - 4-digit user/master code.	🏠1111
Bypass individual zone / Activate Bypassed zone	💡 nn uumm#	nn - zone number, range - [01...144]; uumm - 4-digit user/master code.	💡091111#
Activate/deactivate Configuration mode	✖ iiiii #	ii ii- 4-digit installer code.	✖1470#
Set master code	A) ...0 vvvv 01 mmmm # B) 63 vvvv mmmm # (only when Configuration Mode is activated).	A) vvvv - 4-digit existing master code; mmmm - 4-digit new master code; range - [0000... 9999]. B) vvvv - 4-digit existing master code; mmmm - 4-digit new master code, range - [0000... 9999].	A) ...01111012222# B) 6311112222#
Set user code	...0 mmmm us uuuuu #	mmmm - 4-digit master code; us - user code slot, range - [02... 30].	...0111109#
Delete user code	...0 mmmm us #	us - user code slot, range - [02...10]; mmmm - 4-digit master code.	...3081111#
Set Duress code	...3 us mmmm #	us - user code slot, range - [02...10]; mmmm - 4-digit master code.	...4041111#
Set user/master code partition	User code: ...5 us pv mmmm # Master code: ...5 01 pv mmmm #	us - user code slot, range - [02... 30]; pv - partition value, range - [01... 15]; mmmm - 4-digit master code.	...504081111#
Switch keypad partition (EKB3/ EKB3W/EWKB4)	Hold the [1]... [4] key and release it after 3 short beeps (for EKB3 keypad); Hold the [1]... [2] key and release it after 3 short beeps (for EKB3W/EWKB4 keypads)	[1]... [4] key - partition number 1... 4 respectively. [1]... [2] key - partition number 1... 2 respectively.	
Arm the system/ Dis-arm the system and turn OFF the alarm	uumm	uumm - 4-digit user/master code.	2222

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
ONLY for EKB3! - Arm all 4 partitions simultaneously/ Disarm and turn OFF the alarm in all 4 partitions simultaneously	0 uumm	uumm - 4-digit user/ master code.	0 2222
Set Alarm duration	10 tt #	tt - alarm duration, range - [00...10] minutes.	1007#
Disable Periodic Info SMS	110000#		110000#
Set Periodic Info SMS frequency and time	11it fff #	it - time, range - [01... 23]; fff - frequency, range - [00...125] days	110412#
Disable/ Enable system's remote connection from any phone number	120 #/ 121 #		120 #/ 121 #
Set SMS password	14 ssss #	ssss - 4-digit new SMS password; range - [0001... 9999].	141111#
Set installer code	16 iiiii #	iiii - 4-digit new installer code; range - [0000... 9999]	162538#
Add user phone number	17 up ttteeellnnumm #	up - user phone number slot, range - [01... 10]; ttteeellnnumm - up to 15 digits user phone number.	17010044170911XXXX1#
Enable/Disable Allow adding new iButton keys mode	18 0 #/ 18 1 #		18 0 #/ 18 1 #
Clear tamper fault	22 #		22#
Disable/ Enable MS mode	230# / 231#		230# / 231#
Disable/Enable Burglary alarm/restore data message	24010 #/ 24011 #		24010 #/ 24011 #
Disable/Enable Mains power loss/restore data message	24020 #/ 24021 #		
Disable/Enable Armed/ disarmed by user data message	24030 #/ 24031 #		
Disable/Enable Test event data message	24040 #/ 24041 #		
Disable/Enable Battery failed data message	24050 #/ 24051 #		
Disable/Enable Battery dead or missing/battery connection restore data message	24060 #/ 24061 #		
Disable/Enable Tamper alarm/restore data message	24070 #/ 24071 #		
Disable/Enable Instant Silent zone alarm/restore data message	24080 #/ 24081 #		
Disable/Enable Kronos ping data message	24090 #/ 24091 #		
Disable/Enable System started data message	24100 #/ 24101 #		

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
Disable/Enable 24-Hour zone alarm/restore data message	24130 #/ 24131 #		
Disable/Enable Fire zone alarm/restore data message	24140 #/ 24141 #		
Disable/Enable Low battery data message	24150 #/ 24151 #		
Disable/Enable Temperature risen data message	24160 #/ 24161 #		
Disable/Enable Temperature fallen data message	24170 #/ 24171 #		
Disable/Enable Wireless signal loss/restore data message	24180 #/ 24181 #		
Disable/Enable Disarmed by user (Duress code) data message	24190 #/ 24191 #		
Disable/Enable SGS code entered data message	24200 #/ 24201 #		
Disable/Enable Armed by user (partial arm) data message	24210 #/ 24211 #		
Disable/Enable Siren fail/restore data message	24220 #/ 24221 #		
Disable/Enable RF jammer detected/RF jamming stopped data message	24230 #/ 24231 #		
Disable/Enable Date/time not set data message	24240 #/ 24241 #		
Disable/Enable 2G/4G connection failed data message	24250 #/ 24251 #		
Disable/Enable 2G/4G antenna fail/restore data message	24260 #/ 24261 #		
Disable/Enable System shutdown data message	24270 #/ 24271 #		
Disable/Enable Keypad fail/restore data message	24280 #/ 24281 #		
Disable/Enable 2G/4G connection failed data message	24290 #/ 24291 #		
Disable/Enable Zone bypassed/activated data message	24310 #/ 24311 #		
Disable/Enable CO sensor lifetime exceeded data message	24320 #/ 24321 #		
Disable/Enable CO level critical data message	24330 #/ 24331 #		
Disable/Enable Report/Control zone triggered/restored data message	24340 #/ 24341 #		

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
Disable/Enable Armed/disarmed in STAY mode data message	24350 #/ 24351 #		
Disable/Enable Configuration via remote connection started data message	24360 #/ 24361 #		
Disable/Enable Panic/Silent zone alarm/re-store data message	24370 #/ 24371 #		
Disable/Enable Armed/disarmed automatically data message	24380 # / 24381 #		
Disable/Enable SMS sending limit reached data message	24390 # / 24391 #		24390 # / 24391 #
Disable Arm & Disarm Notification	<p>System armed event User phone number: 25 01 up 0 # SMS text message to all users simultaneously: 21 01 0 # SMS delivery report: 55 01 0 #</p> <p>System disarmed event User phone number: 25 02 up 0 # 25 02 up 0 # SMS text message to all users simultaneously: 21 02 0 # 21 02 0 # SMS delivery report: 25 02 0 # 55 02 0 #</p>	up - user phone number slot, range - [01... 10].	2502040#
Enable Arm & Disarm Notification	<p>System armed event User phone number: 25 01 up 1 # SMS text message to all users simultaneously: 21 01 1 # SMS delivery report: 55 01 1 #</p> <p>System disarmed event User phone number: 25 02 up 1 # 25 02 up 0 # SMS text message to all users simultaneously: 21 02 1 # 21 02 0 # SMS delivery report: 25 02 1 # 55 0</p>	up - user phone number slot, range - [01... 10].	2502061#
Disable SMS text message in case of alarm	User phone number: 25 03 up 0 # SMS text message to all users simultaneously: 21 03 0 # SMS delivery report: 55 03 0 #	up - user phone number slot, range - [01... 10].	2503060#
Enable SMS text message in case of alarm	User phone number: 25 03 up 1 # SMS text message to all users simultaneously: 21 03 1 # SMS delivery report: 55 03 1 #	up - user phone number slot, range - [01... 10].	2503060#

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
Disable Main power loss/restore notification	User phone number: 25 04 up 0 # SMS text message to all users simultaneously: 21 04 0 # SMS delivery report:55 040 #	up - user phone number slot, range - [01... 10].	2504030#
Enable Main power loss/restore notification	User phone number: 2504 up 1 # SMS text message to all users simultaneously: 21041 # SMS delivery report:55041 #	up - user phone number slot, range - [01... 10].	2504031#
Disable Battery failed notification	User phone number: 25 05 up 0 # SMS text message to all users simultaneously: 21 05 0 # SMS delivery report:55 05 0 #	up - user phone number slot, range - [01... 10].	2505060#
Enable Battery failed notification	User phone number: 25 05 up 1 # SMS text message to all users simultaneously: 21 05 1 # SMS delivery report:55 05 1 #	up - user phone number slot, range - [01... 10].	2505061#
Disable Battery dead or missing notification	User phone number: 25 06 up 0 # SMS text message to all users simultaneously: 21 06 0 # SMS delivery report:55 060 #	up - user phone number slot, range - [01... 10].	2506070#
Enable Battery dead or missing notification	User phone number: 25 06 up 1 # SMS text message to all users simultaneously: 21 06 1 # SMS delivery report:55 06 1 #	up - user phone number slot, range - [01... 10].	2506071#
Disable Low battery notification	User phone number: 25 07 up 0 # SMS text message to all users simultaneously: 21 07 0 # SMS delivery report:55 07 0 #	up - user phone number slot, range - [01... 10].	2507030#
Enable Low battery notification	User phone number: 25 07 up 1 # SMS text message to all users simultaneously: 21 07 1 # SMS delivery report:55 07 1 #	up - user phone number slot, range - [01... 10].	2507031#
Disable siren fail/ restore notification	User phone number: 25 08 up 0 # SMS text message to all users simultaneously: 21 08 0 # SMS delivery report:55 080 #	up - user phone number slot, range - [01... 10].	2508030#
Enable siren fail/ restore notification	User phone number: 25 08 up 1 # SMS text message to all users simultaneously: 21 08 1 # SMS delivery report:55 08 1 #	up - user phone number slot, range - [01... 10].	2508041#
Disable RF jammer detected notification	User phone number: 25 09 up 0 # SMS text message to all users simultaneously: 21 09 0 # SMS delivery report:55 090 #	up - user phone number slot, range - [01... 10].	2509040#

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
Enable RF jammer detected notification	User phone number: 25 09 up 1 # SMS text message to all users simultaneously: 21 09 1 # SMS delivery report: 55 09 1 #	up - user phone number slot, range - [01... 10].	2509051#
Disable Date/time not set notification	User phone number: 25 10 up 0 # SMS text message to all users simultaneously: 21 10 0 # SMS delivery report: 55 10 0 #	up - user phone number slot, range - [01... 10].	2510080#
Enable Date/time not set notification	User phone number: 25 10 up 1 # SMS text message to all users simultaneously: 21 10 1 # SMS delivery report: 55 10 1 #	up - user phone number slot, range - [01... 10].	2510081#
Enable 2G/4G connection failed notification	User phone number: 25 11 up 1 # SMS text message to all users simultaneously: 21 11 1 # SMS delivery report: 55 11 1 #	up - user phone number slot, range - [01... 10].	2511091#
Disable 2G/4G connection failed notification	User phone number: 25 11 up 0 # SMS text message to all users simultaneously: 21 11 0 # SMS delivery report: 55 11 0 #	up - user phone number slot, range - [01... 10].	2511020#
Enable 2G/4G/ 2G/4G antenna fail/ restore notification	User phone number: 25 12 up 1 # SMS text message to all users simultaneously: 21 12 1 # SMS delivery report: 55 12 1 #	up - user phone number slot, range - [01... 10].	2512031#
Disable 2G/4G/ 2G/4G antenna fail/ restore notification	User phone number: 25 12 up 0 # SMS text message to all users simultaneously: 21 12 0 # SMS delivery report: 55 12 0 #	up - user phone number slot, range - [01... 10].	2512030#
Disable Tamper alarm Notification	User phone number: 25 13 up 0 # SMS text message to all users simultaneously: 21 13 0 # SMS delivery report: 55 13 0 #	up - user phone number slot, range - [01... 10].	2513030#
Enable Tamper alarm Notification	User phone number: 25 13 up 1 # SMS text message to all users simultaneously: 21 13 1 # SMS delivery report: 55 13 1 #	up - user phone number slot, range - [01... 10].	2513031#
Disable Communication bus fail/restore notification	User phone number: 25 14 up 0 # SMS text message to all users simultaneously: 21 14 0 # SMS delivery report: 55 14 0 #	up - user phone number slot, range - [01... 10].	2514030#
Enable Communication bus fail/restore notification	User phone number: 25 14 up 1 # SMS text message to all users simultaneously: 21 14 1 # SMS delivery report: 55 14 1 #	up - user phone number slot, range - [01... 10].	2514031#

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
Disable Temperature info notification	User phone number: 25 15 up 0 # SMS text message to all users simultaneously: 21 15 0 # SMS delivery report:55 15 0 #	up - user phone number slot, range - [01... 10].	2515030#
Enable Temperature info notification	User phone number: 25 15 up 1 # SMS text message to all users simultaneously: 21 15 1 # SMS delivery report:55 15 1 #	up - user phone number slot, range - [01... 10].	2515031#
Disable System start-ed notification	User phone number: 25 16 up 0 # SMS text message to all users simultaneously: 21 16 0 # SMS delivery report:55 16 0 #	up - user phone number slot, range - [01... 10].	2516030#
Enable System start-ed notification	User phone number: 25 16 up 1 # SMS text message to all users simultaneously: 21 16 1 # SMS delivery report:55 16 1 #	up - user phone number slot, range - [01... 10].	2516031#
Disable Periodical info notification	User phone number: 25 17 up 0 # SMS text message to all users simultaneously: 21 17 0 # SMS delivery report:55 17 0 #	up - user phone number slot, range - [01... 10].	2517030#
Enable Periodical info notification	User phone number: 25 17 up 1 # SMS text message to all users simultaneously: 21 17 1 # SMS delivery report:55 17 1 #	up - user phone number slot, range - [01... 10].	2517031#
Disable wireless signal loss/ restore notification	User phone number: 25 18 up 0 # SMS text message to all users simultaneously: 21 18 0 # SMS delivery report:55 18 0 #	up - user phone number slot, range - [01... 10].	2518030#
Enable wireless signal loss/ restore notification	User phone number: 25 18 up 1 # SMS text message to all users simultaneously: 21 18 1 # SMS delivery report:55 18 1 #	up - user phone number slot, range - [01... 10].	2518031#
Disable Unable to arm notification	User phone number: 25 19 up 0 # SMS text message to all users simultaneously: 21 19 0 # SMS delivery report:55 19 0 #	up - user phone number slot, range - [01... 10].	2519030#
Enable Unable to arm notification	User phone number: 25 19 up 1 # SMS text message to all users simultaneously: 21 19 1 # SMS delivery report:55 19 1 #	up - user phone number slot, range - [01... 10].	2519031#
Disable Zone by-pass notification	User phone number: 25 20 up 0 # SMS text message to all users simultaneously: 21 20 0 # SMS delivery report:55 20 0 #	up - user phone number slot, range - [01... 10].	2520030#

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
Enable Zone by-pass notification	User phone number: 25 20 up 1 # SMS text message to all users simultaneously: 21 20 1 # SMS delivery report:55 20 1 #	up - user phone number slot, range - [01... 10].	2520031#
Disable CO level critical notification	User phone number: 25 21 up 0 # SMS text message to all users simultaneously: 21 21 0 # SMS delivery report:55 21 0 #	up - user phone number slot, range - [01... 10].	2521030#
Enable CO level critical notification	User phone number: 25 21 up 1 # SMS text message to all users simultaneously: 21 21 1 # SMS delivery report:55 21 1 #	up - user phone number slot, range - [01... 10].	2521031#
Disable EWM1 wireless signal loss/ restore notification	User phone number: 25 22 up 0 # SMS text message to all users simultaneously: 21 22 0 # SMS delivery report:55 22 0 #	up - user phone number slot, range - [01... 10].	2522030#
Enable EWM1 wireless signal loss/ restore notification	User phone number: 25 22 up 1 # SMS text message to all users simultaneously: 21 22 1 # SMS delivery report:55 22 1 #	up - user phone number slot, range - [01... 10].	2522031#
Disable Report/Control Zone triggered notification	User phone number: 25 23 up 0 # SMS text message to all users simultaneously: 21 23 0 # SMS delivery report:55 23 0 #	up - user phone number slot, range - [01... 10].	2523030#
Enable Report/Control Zone triggered notification	User phone number: 25 23 up 1 # SMS text message to all users simultaneously: 21 23 1 # SMS delivery report:55 23 1 #	up - user phone number slot, range - [01... 10].	2523031#
Disable Incoming SMS forwarding notification	User phone number: 25 24 up 0 # SMS text message to all users simultaneously: 21 24 0 # SMS delivery report:55 24 0 #	up - user phone number slot, range - [01... 10].	2524030#
Enable Incoming SMS forwarding notification	User phone number: 25 24 up 1 # SMS text message to all users simultaneously: 21 24 1 # SMS delivery report:55 24 1 #	up - user phone number slot, range - [01... 10].	2524091#
Disable Wireless communication failed notification	User phone number: 25 24 up 1 # SMS text message to all users simultaneously: 21 24 1 # SMS delivery report:55 24 1 #	up - user phone number slot, range - [01... 10].	2525080#
Enable Wireless communication failed notification	User phone number: 25 25 up 1 # SMS text message to all users simultaneously: 21 25 1 # SMS delivery report:55 25 1 #	up - user phone number slot, range - [01... 10].	2525011#

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
Set monitoring station phone number (for Voice calls and SMS)	26 ps ttteeeInnuumm #	ps - phone number slot, range - [01... 03]; ttteeeInnuumm - up to 15 digits monitoring station phone number.	26010044170911XXXX1#
Set account (for Monitoring Station)	Main Account: 27 cccc# Server 2 Account: 96 12 cccc# Server 3 Account: 96 13 cccc#	cccc - 4-digit account number.	278853#
Enable/Disable ATZ mode	281/280 #		281/280 #
Enable/Disable Bell squawk	291# / 290#		291# / 290#
Enable / Disable Call in case of alarm	30 us 1 # 30 us 0 #	us - user phone number slot, range - [01... 10].	30091# 30090#
Enable / Disable Chime attribute	321# / 320#		321# / 320#
Set Zone for Arm-Disarm by Zone method	34 z nn #	z - on-board zone slot for Arm-Disarm by Zone method; range - [1... 4]; nn - on-board zone number, range - [01... 16].	34023#
Disable Arm-Disarm by Zone method	34 z 00 #	z - on-board zone slot for Arm-Disarm by Zone method; range - [1... 4].	34200#
Disable/ Enable Event Log	360/ 361 #		360/ 361 #
Set attempts (for Voice Calls and SMS)	37 at #	at - number of attempts, range - [01... 10].	3706#
Set server IP address	Server 1: 40 add add add add # Server 2: 96 02 add add add add # Server 3: 96 03 add add add add #	add add add add - server IP address.	40065082119005#
Set DNS1 server IP address	41 add add add add#	add add add add - DNS1 server IP address.	41065082119001#
Set DNS2 server IP address	42 add add add add#	add add add add - DNS2 server IP address.	42065082119002#
Set protocol	Server 1: 430# - TCP / 431# - UDP Server 2: 96060# - TCP / 96061# - UDP Server 3: 96070# - TCP / 96071# - UDP		431#
Set server port	Server 1: 44 pprtr# Server 2: 96 04 pprtr# Server 3: 96 05 pprtr#	pprtr - server port number, range - [1... 65535].	443365#
Set test period	Server 1: 46 tteessttp# Server 2: 96 10 tteessttp# Server 3: 96 11 tteessttp#	tteessttp - test period, range - [0... 65535] seconds.	46120#

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
Set primary connection	2G/4G network - Server 1 - 480# Voice calls - 481# PSTN - 483# SMS - 484# ELAN3-ALARM - Server 1 - 485# 2G/4G network - Server 2 - 486# 2G/4G network - Server 3 - 487# ELAN3-ALARM - Server 2 - 488# ELAN3-ALARM - Server 3 - 489#		484#
Enable/ Disable Interconnection	501# / 500#		501 # / 500 #
Set keypad partition	EKB3 partition: 51 kk p# EKB3W/EWKB4 partition: 51 kw r#	kk - EKB3 keypad slot, range - [01... 04]; kw - EB3W keypad slot, range - [05... 08]; p - EKB3 partition number, range - [1... 4]; r - EKB3W/EWKB4 partition number, range - [1... 2].	51062#
Enable/ Disable zone	52 nn 1 # 52 nn 0 #	nn - zone number, range - [01... 144].	52151# / 52150#
Set zone type for individual zone	53 nn 1 # - Interior Follower 53 nn 2 # - Instant 53 nn 3 # - 24-Hour 53 nn 4 # - Delay 53 nn 5 # - Fire 53 nn 6 # - Panic/Silent 53 nn 7 # - CO Sensor 53 nn 8 # - Report/Control 53 nn 9 # - Instant Silent	nn - zone number, range - [01... 144]	53125#
Set entry delay for Delay zone	54 nn eeeee #	nn - zone number, range - [01... 144], eeeee - entry delay duration, range - [0... 9999] seconds	5403259#
Enable/ Disable Stay attribute for individual zone	56 nn 1 # 56 nn 0 #	nn - zone number, range - [01... 144].	56041# / 56040#
Set zone partition	57 nn pv#	nn - zone number, range - [01... 144]; pv - partition value, range - [1... 15]	57031#
Set monitoring station phone number (for PSTN)	58 ps ttteeellnnuumm #	ps - phone number slot, range - [01... 03]; ttteeellnnuumm - up to 15 digits monitoring station phone number.	58020044170911XXXX1#
Set user phone number partition	59 us pv #	us - user phone number slot, range - [01... 10]; pv - partition value, range - [1... 15]	59092#
Set iButton key partition	60 is pv #	is - iButton key slot, range - [01... 16]; pv - partition value, range - [1... 15]	60057#

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
Turn ON PGM output/ Set PGM output status as ON	61 oo 1 #	oo - PGM output number, range - [01... 48].	61031#
Turn OFF PGM output/ Set PGM output status as OFF	61 oo 0 #	oo - PGM output number, range - [01... 48].	61030#
Set date and time	66 yyyy mt dd hr mn#	yyyy - year; mt - month, range - [01... 12]; dd - day, range - [01... 31]; hr - hours, range - [00... 23]; mn - minutes, range - [00... 59].	66201405291235#
Set attempts (for 2G/4G Network and Elan3 Alarm)	Server 1: 68 att# Server 2: 96 08 att# Server 3: 96 09 att#	att - number of attempts, range - [01... 255]	6809#
Set delay after last communication attempt	69 aaapp #	aaapp - duration of delay after last attempt, range - [0... 65535] seconds.	69200#
Set mains power loss delay	70 llll #	llll - mains power loss delay duration, range - [0... 65535] seconds.	7043#
Set mains power restore delay	71 rrrrr #	rrrrr - mains power restore delay duration, range - [0... 65535] seconds.	71150#
Set exit delay	72 pp ext #	pp - partition number, range - [01... 04], ext - exit delay duration, range - [0... 600] seconds.	7203259#
Enable/ Disable Siren if Wireless signal is lost	761# 760#		761# / 760#
Enable/Disable key-pad partition switch	771 # / 770 #		771 # / 770 #
Enable/ Disable Force attribute for individual zone	82 nn 1 # 82 nn 0 #	nn - zone number, range - [01... 144]	82061# / 82060#
Set backup connection 1...5	2G/4G network - Server 1 - 83bb0# Voice calls - 83bb1# PSTN - 83bb3# SMS - 83bb4# ELAN3-ALARM - Server 1 - 83bb5# 2G/4G network - Server 2 - 83bb6# 2G/4G network - Server 3 - 83bb7# ELAN3-ALARM - Server 2 - 83bb8# ELAN3-ALARM - Server 3 - 83bb9#	bb - backup connection slot, range - [01... 05].	83024#
Set attempts	84 at #	at - number of attempts, range - [01... 10].	8403#
Enable/ disable EWS2 LED indication	881# / 880#		881# / 880#
Set primary temperature sensor	89 ts #	ts - temperature sensor slot, range - [01... 08].	8903#

COMMAND DEFINITION	CODE	COMMAND VALUE	EXAMPLE
Enable EWS3 LED indication	Burglary/24-hour/tamper alarm LED: 941# Fire alarm LED:931#		931#
Disable EWS3 LED indication	Burglary/24-hour/tamper alarm LED: 940# Fire alarm LED:930#		940#

39. SMS COMMANDS - APPENDIX 3

THEME	SMS EXAMPLE
SMS PASSWORD:	
Set SMS password	0000 PSW 1111
USER PHONE NUMBERS:	
Add user phone number	1111 NR1:+441709111111
View user phone number	1111 HELPNR
Delete user phone number	1111 NR2:DEL
Enable system's remote connection from any phone number	1111 STR:ON
Disable system's remote connection from any phone number	1111 STR:OFF
DATE AND TIME:	
Set date and time	1111 2014.03.16 14:33
IBUTTON KEYS:	
Enable allow adding new iButton keys mode	1111 IBPROG:ON
Disable allow adding new Ibutton keys mode	1111 IBPROG:OFF
Remove all iButton keys from the system	1111 RESETIB
ARMING AND DISARMING:	
Arm the system	1111 ARM1
Disarm the system	1111 DISARM1,2,4
EXIT AND ENTRY DELAY:	
Set exit delay	1111 EXITDELAY:1,20;3,43
Set entry delay for delay zone	1111 ENTRYDELAY:1,25;54,14;12,20
ZONES:	
Set zone name	1111 Z3:Door sensor triggered
View zone names	1111 STATUS
Disable zone	1111 Z13:OFF
Enable zone	1111 Z6:ON
ALARM INDICATIONS AND NOTIFICATIONS:	
View violated zones	1111 INFO
PROGRAMMABLE (PGM) OUTPUTS:	
Set PGM output name	1111 C2:Lights
View PGM output names	1111 STATUS

THEME	SMS EXAMPLE
Turn on PGM output/ Set PGM output start up state as on	1111 Lights:ON
Turn off PGM output/ Set PGM output start up state as off	1111 C2:OFF
Turn on PGM output for time period	1111 C4:ON:10.15.35
Turn off PGM output for time period	1111 Lights:OFF:00.00.23
WIRELESS DEVICES:	
Pair wireless device with the system	1111 SET:5353185D
Remove wireless device from the system	11111 DEL:5353185D
Replace wireless device	1111 REP:5353185D<41286652
View wireless device information	1111 RFINFO:5353185D
View available wireless device slots	1111 STATUS FREE
SIREN/BELL:	
Set alarm duration	1111 SIREN:4
View alarm duration	1111 SIREN
TEMPERATURE SENSORS:	
View real-time temperature values of individual temperature sensor	1111 ITEMp:4
View real-time temperature values of all temperature sensors	1111 ITEMp:?
Set primary temperature sensor	1111 TEMPI:PRIM:4
Set secondary temperature sensor	1111 TEMPI:SEC:3
View primary and secondary temperature sensor slot number	1111 TEMPI:?
View primary and secondary temperature sensor real-time temperature values	1111 INFO
Set MIN and MAX temperature boundaries	1111 TEMP2:MIN:-5,MAX:28
View MIN and MAX temperature boundaries	1111 TEMP4
Set temperature sensor name	1111 TEMP3:NAME:Warehouse
View temperature sensor name	1111 TEMP3
Delete temperature sensor name	1111 TEMP2:NAME:
SYSTEM INFORMATION. INFO SMS:	
Request for system information	1111 INFO
Set periodic info SMS frequency and time	1111 INFO:3.15
Disable periodic info SMS	1111 INFO:00.00
SMSC (short message service center) phone number	1111 SMS +441703111111
MONITORING STATION:	
Enable MS mode	1111 SCNSET:ON
Disable MS mode	1111 SCNSET:OFF
Set server IP address	1111 SET2G/4G:IP:65.82.119.5
Set server port	1111 SET2G/4G:PORT:5521
Set protocol	1111 SET2G/4G:PROTOCOL:UDP


THEME	SMS EXAMPLE
Set APN	1111 SET2G/4G:APN:internet
Set user name	1111 SET2G/4G:USER:mobileusr
Set password	1111 SET2G/4G:PSW:mobilepsw
View IP and 2G/4G network settings	1111 SET2G/4G?
SERVICE MODE:	
Activate service mode	1111 SERVICEMODE:ON
Deactivate service mode	1111 SERVICEMODE:OFF
REMOTE SYSTEM RESTART:	
Restart the system	1111 RESET
TECHNICAL SUPPORT:	
Initiate FOTA manually	1111 FOTA
REMOTE CONFIG:	
Start Remote Config	1111 STCONFIG
End Remote Config	1111 ENDCONFIG
Start Remote Config via ELAN	1111 STCONFIG:ELAN
CLOUD SERVICES:	
Cloud Services ID	1111 SMART ID
Cloud Services settings - Smart On/Off, server, port, ping	1111 SMART:ON,ss.eldes.lt,8082,180
DEVICE TIME SYNCHRONIZATION* (System settings)	
Enable Automatic Time Synchronization	1111 TIMESYNC:AUTO
Enable Time Synchronization from CMS (ARC)	1111 TIMESYNC:CMS
Disable Time Synchronization	1111 TIMESYNC:OFF

*This feature is **NOT available** for old firmware versions (i.e. for FW versions **V01.10.00 and earlier**).

40.RADIO SYSTEM INSTALLATION AND SIGNAL PENETRATION - APPENDIX 4

WHAT YOU MUST KNOW BEFORE INSTALLING THE SYSTEM

Radio signals are electromagnetic waves, hence the signal becomes weaker the further it travels, the range is limited.



The following material shows theoretically evaluated relation between radio signal strength and the distance among devices.

The radio coverage is further decreased by specific materials:

Material	Range reduction vs LoS*
Wood, plaster, glass uncoated, without metal	0 - 10 %
Brick, press board	5 - 35 %
Ferro concrete	10 - 90 %
Metal, aluminium lining	see chapter "How to properly install the system"


* LoS (Short for "line of sight") - a term being used in Radio frequency technologies to describe an unobstructed path between the location of the signal transmitter and the location of the signal receiver.

The following should be accepted as suggestions and evaluated while installing your system:

- During the night time, when there is no movement at all, wireless signal level can decrease up to 17%.
- Furniture and movement can increase or decrease signal level by approximately up to 20%.

So, that means the sensor's signal level can decrease up to about 37% or even increase slightly, depending on individual environmental factors.

Spread of radio signal within a building:




HOW TO PROPERLY INSTALL THE SYSTEM:


NOTE: It is HIGHLY RECOMMENDED to install your system with the Service Mode enabled (using Eldes Utility software). This installation method will ensure a better protection against variable environmental factors (the number of people moving throughout the secured area, material obstacles, etc.).

- Clear RF path of obstructions - Make sure the RF path is clear of obstructions. Antennas should be installed where they can "see" each other as much as possible. Make sure the antennas are high enough above any obstructions in the RF path.
- Pay attention to antenna alignment - Make sure the antennas are aligned correctly. In order to get the best result, you should mount your sensor according to their own manual's instruction, which you'll find at eldesalarms.com
- Know you overall system gain required to meet the distance. The more the distance between the radios, the more the overall system gain needs to be. If the signal level between the system and your wireless device is 30% or less, use a higher gain antenna. Consult your local dealer.


- The longer the antenna cable and the more the number of connections, the more the signal loss. Please be aware that if you use antenna's extension cord or/and any other additional elements of wiring (cables,wires, etc.), then more antenna gain will be lost.
- We recommend that the best place for Alarm System installation is at the approximately estimated centre of all mounted Wireless devices across your premises (house/flat), and it's not necessarily the centre of a room itself, i.e. positioning basically depends on the total of the secured area. For a better visual perception, see the following picture:




- The angle at which the transmitted signal hits the wall is very important. The effective wall thickness - and with it the signal attenuation - varies according to this angle. Signals should be transmitted as directly as possible through the wall.




- When using devices with an internal receiving antenna, the device should not be installed on the same side of the wall as the transmitter. Near a wall, the radio waves are likely to be subject to interfering dispersions or reflections. Consequently, the position of the antenna has to be on the opposite or connecting wall.



- When using Alarm System with an external antenna, the ideal antenna installation place is a central location in the room. Where possible the antenna should be at least 10 - 15 cm away from the wall corner or concrete ceiling.





- Wrong antenna mounting by the ceiling:



- Massive objects made of metal, such as metallic separation walls and metal inserted ceilings, massive wall reinforcements and the metal foil of heat insulations, reflect electromagnetic waves and thus create what is known as radio shadow. However singularized small metal studs, e.g. the metal studs of a gypsum dry wall, don't show a recognizable screening.


- Internal antenna, mounted on metal surfaces (typically 30% loss of range)
- Using any type of antenna inside metallic frames (typically 30% loss of range)




Recommended installation:

- face the front side of the wireless device towards the antenna
- keep the distance: 0,5 to 30m (1.64 to 98.43ft) inside the building, 0,5 to 150m (1.64 to 492.13ft) in open areas

- Keep the distance of at least 20cm (7.87in) or more between your wireless device/Alarm System and the metal box/metal sheet or any object of this material:



- Metal separation walls: It can be noticed that radio transmission even works with metal indoor separation walls. This happens through reflections: Walls made of metal or concrete reflect the electromagnetic waves. The radio waves reach the next room or floor via a non metallic opening.



41. 2-WIRE SMOKE CONNECTION - APPENDIX 5

GENERAL INFORMATION

Starting from firmware version FW V01.06.00, user will be able to connect 2 wire smoke sensors to ESIM484 alarm system. The addition can be defined as a photoelectric-based smoke detector, designed to detect smouldering fire before bursting into flame, to prevent any kind of fire risk.

It is possible to add more than 1 wired smoke sensor of any manufacturer (no matter if it will be 2 wire or 4 wire smoke sensor), thus it all depends on manufacturer's technical aspects of the selected smoke sensor and predetermined accumulative thresholds.

How to make it work properly



In order for 2 wire smoke to operate correctly, first it has to be wired and connected as follows (complies with/according to the Connection Type No 6):

After the wiring process is completed, user has to launch a pre-installed Eldes Utility software: open Zones section, enable the 2-wire smoke sensors compatibility option and save configuration settings (see pic. No2 below):



When the device is attached to the alarm system, the former occupies C2 output and receives a Fire Type zone by default (i.e. zone is always named Fire Alarm). By default, the numeration of the newly added zone will always start from No 17 (if no wireless devices were added beforehand). (see pic. No3 below):

Pic. No 3



SMOKE SENSOR'S MODES

StartUp mode - When SENSOR detectors are powered up they automatically enter a phase known as *StartUp** and in which they stay for x-time (Time for Entering to Standby mode). After this they revert to normal operation. If the detector is reset, ie, if power is disconnected for y-seconds (Smoke Reset time), the detector will always enter StartUp for the x-time after power has been restored.

* What *StartUp* indicates - StartUp is used to check that the positive and negative cables are connected in the correct polarity and that power has been applied to the detector.

WHAT WILL HAPPEN WHEN SMOKE IS DETECTED?

In case of smoke detection, wired smoke sensor will indicate the alarm and notify Eldes system about the event. When the smoke clears, the detector will remain in the alarm state until reset by turning off the power supply from the control panel.

SUGGESTED PLACEMENT:

Place smoke sensor in your premises according to the local rules.


ATTENTION: Incorrect placement will result in a decrease of operational effectiveness.

Please find Table 1 below. It offers information on certain smoke sensors with recommended values indicated:

		Supply V	Standby uA	Alarm mA	Reset Time	Time to enter Standby	Max quantity
Sentec SD 119 - 2/4	BK Grupé	nuo 10.8 iki 33V	80 uA	22 mA/12V; 55 mA/24V			9
Unipos FD 8030	Fima	nuo 10 iki 30V	120 uA prie 22.5 V	8 mA/ 10V 25mA/30V	2 s	up to 40 s	10
NB 338	Sareme	nuo 12 iki 35V	70 uA	70 mA/35V		120 s	5
Apolo Orbis	BK Grupé	nuo 8.5 iki 33V	95 uA	20 mA/12V; 40 mA/24V	1 s	20 s	8
Inim ID100	VS Sistemso	nuo 10 iki 30V	90 uA	40 mA			5

2 WIRE SMOKE DETECTOR WIRING SCHEME (EXAMPLE)

In order to avoid tamper alarm, both 3.3k end-of-line resistor and 5.6k end-of-line resistor must be connected (these are included in the standard contents of ESIM484 pack). These resistors must be connected to the final chain of smoke sensor.



Main options explained:

Smoke Reset time: From 1 sec. to 10 sec. Default value is 2 sec.

Smoke Reset time refers to smoke detector's minimal power down time needed to complete smoke detector's single reset cycle.

Time for Entering to Standby mode: From 10 sec. to 300sec. Default value is 120 sec.

Defines the time from the power up moment, needed for smoke detector's self-testing and to enter the standby mode. During this time period, the alarm system ignores any increase of power consumption. Pay attention, that different sensor models have different time values, thus user should set the Time for Entering to Standby mode according to manufacturer's recommended highest possible value.

The amount of power consumption is measured from the moment of device power up to its entering into StandBy mode and can be equal to power consumption results that accumulates when device is in Alarm state.

Technical restrictions:

- When $I_{SD} \leq 2\text{mA}$ or $I_{SD} > 230\text{mA}$, then tamper alarm will be triggered (if tamper alarm is enabled).
- If $2\text{mA} < I_{SD} < 10\text{mA}$, then smoke sensors operate in StandBy mode, i.e. constantly checking the level of smoke in the surrounding area.
- Either if $14\text{mA} \leq I_{SD} \leq 230\text{mA}$ or when C2 remains in Power On state, then one or few smoke sensors go into ALARM state (each smoke sensor acts accordingly to its zone settings: triggers the alarm, etc.).
- In case your alarm system is configured via USB cable and there is no auxiliary power supply is used, (AC/DC or AKU), then AUX power supply is deactivated and 2-wire smoke sensors won't be powered up.
- All wired sensors' accumulative current flow in ALARM state can't exceed 230mA.
- All wired sensors' accumulative current flow in STANDBY state can't exceed 10mA.

COMMON NOTICES:

- C2 output will always be dedicated for 2-wired smoke sensors connectivity, so it won't be possible to use it as a regular output at all (C2 output will not be available in Output section).
- While reconfigured, C2 output becomes an input, which measures the ongoing level of current, flowing through a unit.
- It is possible to connect both 2 wire and 4 wire wired smoke sensors. The quantity limit depends on manufacturer's technical aspects of the selected smoke sensor and predetermined accumulative thresholds.
- User notifications concerning triggered Fire zones will be send as a regular notification, which will include zone name.

